

[Manuals.plus](#) /

› [Soundcore](#) /

› Soundcore Life A1 True Wireless Earbuds User Manual

Soundcore A3927

Soundcore Life A1 True Wireless Earbuds User Manual

Model: A3927

INTRODUCTION

Thank you for choosing the Soundcore Life A1 True Wireless Earbuds. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and longevity.

WHAT'S IN THE BOX

- Life A1 True Wireless Earbuds
- Wireless Charging Case
- USB-C Cable
- XS/S/M/L/XL EarTips
- S/M/L EarWings

PRODUCT OVERVIEW

The Soundcore Life A1 earbuds are designed for an immersive audio experience with powerful sound and extended battery life. They feature a robust, waterproof design suitable for various activities.



Image: Soundcore Life A1 True Wireless Earbuds and their charging case.

Key Features:

- **Triple-Layer Diaphragm Drivers:** Oversized 8mm drivers deliver 40% deeper bass and 100% crisper treble for a rich audio experience.

40%

MORE BASS

8mm Triple-Layer Driver



100%

MORE TREBLE

Image: Exploded view of the 8mm triple-layer composite driver, highlighting its components for enhanced bass and treble.

- **Extended Playtime:** Enjoy up to 9 hours of listening on a single charge, with the charging case providing an additional 30 hours, totaling 39 hours of playtime.



Image: Visual representation of the 35-hour total playtime, with 9 hours from the earbuds and additional charges from the case.

- **Fast Charging:** A quick 10-minute charge provides 1.5 hours of playtime.
- **Custom Sound Modes:** Easily switch between Soundcore Signature, Bass Booster, and Podcast modes to tailor your audio.

3 CUSTOM SOUND MODES



Signature



Bass Booster



Podcast

Image: A person wearing the Soundcore Life A1 earbuds, illustrating the three custom sound modes: Signature, Bass Booster, and Podcast.

- **Dual Charging Options:** Charge the case using the included USB-C cable or wirelessly on a compatible charging pad.



Image: Depiction of the two convenient charging methods for the Soundcore Life A1 case: via USB-C cable and wirelessly on a charging pad.

- **IPX7 Waterproof:** Protected against sweat, rain, and spills, making them suitable for workouts and outdoor activities.

IPX7

WATERPROOF



Image: Close-up of the earbuds with water droplets, demonstrating their IPX7 waterproof capability.

- **Secure Fit:** Comes with silicone EarWings and EarTips in various sizes to ensure a stable and comfortable fit.

SECURE FIT



S/M/L
EarWings



XS/S/M/L/XL
EarTips




Image: Illustration of the different sizes of EarWings (S/M/L) and EarTips (XS/S/M/L/XL) included for a secure and customized fit.

- **Button Control:** Easy control for volume, EQ mode, track changes, and voice assistant activation.
- **Single Earbud Mode:** Use either earbud independently for calls or music while maintaining awareness of your surroundings.

SETUP

1. Choosing the Right Fit

For optimal sound quality and secure fit, select the EarTips and EarWings that best suit your ears. Experiment with different sizes to find the most comfortable and stable combination.

2. Charging Your Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the USB-C cable to the charging port on the case and a power source, or place the case on a wireless charging pad. The LED indicators on the case will show the charging status.

3. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Soundcore Life A1" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear an audible confirmation, and the earbuds' LED indicators will change.

The earbuds will automatically connect to the last paired device when removed from the case.

Your browser does not support the video tag.

Video: Official Soundcore tutorial on how to use the Soundcore Life A1 earbuds, covering setup and basic functions.

OPERATING

Controls:

The Soundcore Life A1 earbuds feature physical buttons for precise control. The specific functions can be customized via the Soundcore app.

Action	Function (Default)
Single Press (Left/Right)	Play/Pause, Answer/End Call
Double Press (Right)	Next Track
Double Press (Left)	Previous Track
Press and Hold (1 second)	Reject Call
Press and Hold (2 seconds)	Activate Voice Assistant
Triple Press (Left/Right)	Switch EQ Mode

Soundcore App:

Download the Soundcore app to unlock additional features, customize button controls, and access various equalizer settings beyond the default modes. While custom EQ presets are not available, there are 21 pre-configured options including Soundcore Signature and BassUp.

MAINTENANCE

Cleaning:

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. For ear tips, remove them and clean with mild soap and water, then dry thoroughly before reattaching.

Storage:

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from extreme temperatures.

Water Resistance:

The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. However, the charging case is not waterproof. Ensure earbuds are completely dry before placing them back in the

charging case to prevent damage.

TROUBLESHOOTING

Earbuds not charging in case:

Ensure the earbuds are properly seated in the charging case and that the charging pins are clean and free of debris. Verify the charging case itself has sufficient battery or is connected to a power source.

Connection issues:

If earbuds fail to connect or maintain a stable connection, try the following:

- Ensure both earbuds are fully charged.
- Disable and re-enable Bluetooth on your device.
- Forget "Soundcore Life A1" from your device's Bluetooth settings and re-pair.
- Reset the earbuds (refer to the Soundcore app or official support for specific reset instructions).

Low volume or unbalanced sound:

Check the volume levels on both your device and the earbuds. Ensure ear tips are clean and properly fitted. If the issue persists, try cleaning the earbud's mesh filters.

SPECIFICATIONS

Feature	Detail
Model Name	Life A1
Item Model Number	A3927
Connectivity Technology	Wireless (Bluetooth 5.0)
Audio Driver Type	Dynamic Driver (8mm)
Frequency Range	20Hz - 20kHz
Earbud Battery Life	Up to 9 Hours
Total Playtime (with case)	Up to 39 Hours
Water Resistance Level	IPX7
Charging Time (Fast Charge)	10 min charge = 1.5 hours playtime
Charging Options	USB-C, Wireless Charging
Control Type	Button Control
Item Weight	2.08 ounces
Product Dimensions	3.21 x 1.44 x 1.3 inches
Manufacturer	Anker
UPC	194644062507

WARRANTY AND SUPPORT

Soundcore products typically come with a warranty. For detailed warranty information and customer support, please visit the official Soundcore website or contact their customer service. Many users have reported excellent customer support from Anker/Soundcore for warranty claims and product assistance.

You can find more information and support at the [Soundcore Store on Amazon](#).