

[manuals.plus](#) /

› [Hk Audio](#) /

› [HK Audio Premium PR:O Move 8 Powered Full Range Speaker User Manual](#)

Hk Audio MOVE 8

HK Audio Premium PR:O Move 8 Powered Full Range Speaker User Manual

1. INTRODUCTION

Welcome to the user manual for your HK Audio Premium PR:O Move 8 Powered Full Range Speaker. This manual provides essential information for the safe and efficient operation of your new audio system. Please read it thoroughly before initial use and retain it for future reference. The PR:O Move 8 is a versatile, battery-powered speaker designed for various applications, offering high-quality sound and integrated mixing capabilities.

2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, observe the following safety precautions:

- **Power Source:** Only use the power adapter supplied with the unit. Ensure the voltage matches your local power supply.
- **Battery Safety:** Do not expose the battery to excessive heat, direct sunlight, or fire. Do not attempt to open or modify the battery. Dispose of batteries according to local regulations.
- **Placement:** Place the speaker on a stable, level surface. Ensure adequate ventilation around the unit to prevent overheating. Avoid placing it near heat sources or in direct sunlight.
- **Moisture:** Do not expose the unit to rain, moisture, or any liquids. This product is not waterproof.
- **Cleaning:** Disconnect the power before cleaning. Use a dry, soft cloth. Do not use liquid cleaners or aerosols.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Hearing Protection:** Prolonged exposure to high volume levels can cause permanent hearing damage. Use caution when setting volume levels.

3. PACKAGE CONTENTS

Please check that all items are present in your package:

- HK Audio Premium PR:O Move 8 Powered Full Range Speaker
- Power Adapter
- User Manual (this document)

If any items are missing or damaged, please contact your dealer immediately.

4. PRODUCT OVERVIEW

The HK Audio PR:O Move 8 is a compact and powerful battery-powered speaker featuring an 8-inch bass/midrange speaker and a 1-inch driver with horn. It includes a 4-channel mixer with Bluetooth 5.0 audio streaming.



Figure 4.1: Front and Side View. This image displays the speaker from the front and a slight side angle, highlighting the protective metal grille covering the speaker components and a recessed handle on the top side for portability.



Figure 4.2: Rear and Side View with Controls. This image shows the rear panel of the speaker, which houses the integrated 4-channel mixer. Visible elements include input jacks, volume and tone controls, reverb knobs, and the HK Audio branding.



Figure 4.3: Detailed Rear Panel. A closer look at the rear panel, detailing the various input/output connections, the DC power input, battery status indicators, and the removable battery compartment cover.



Figure 4.4: Mixer Control Panel Detail. This image provides a detailed view of the mixer section, illustrating the individual controls for each of the four channels, including volume, treble, bass, and reverb adjustments, along with the master volume knob.



Figure 4.5: Floor Monitor Position. The speaker is shown lying on its side, angled upwards, demonstrating its capability to function as a floor monitor for stage or practice use.



Figure 4.6: Pole Mount Socket. This image highlights the integrated pole mount socket located on the bottom of the speaker,

allowing it to be mounted on a standard speaker stand for elevated sound projection.

5. SETUP

5.1 Initial Charging

1. Connect the supplied power adapter to the DC IN port on the rear panel of the speaker.
2. Plug the power adapter into a suitable electrical outlet.
3. The battery indicator LEDs on the rear panel will show the charging status. A full charge is indicated when all LEDs are lit and stable.
4. Allow the speaker to fully charge before its first battery-powered use.

5.2 Placement Options

- **Vertical Stand Mount:** Use the integrated pole mount socket on the bottom of the speaker to place it on a standard speaker stand.
- **Floor Monitor:** The speaker can be placed horizontally on the floor, angled upwards, to serve as a stage monitor.
- **Tabletop/Floor:** Place the speaker vertically on a stable, flat surface.

5.3 Powering On/Off

Locate the power switch on the rear panel. Press it to turn the speaker ON or OFF. The power LED will illuminate when the unit is on.

6. OPERATING INSTRUCTIONS

6.1 Connecting Devices

The PR:O Move 8 features a 4-channel mixer:

- **Channels 1 & 2 (Mic/Line):** These channels feature XLR/TRS combo jacks, suitable for microphones or line-level instruments. Adjust the input sensitivity using the respective switch.
- **Channel 3 (Instrument):** This channel is optimized for instruments like acoustic guitars, featuring a 1/4-inch jack and a switchable cabinet simulation for authentic sound.
- **Channel 4 (Aux/Bluetooth):** This channel handles auxiliary input via a 3.5mm jack or Bluetooth audio streaming.

6.2 Bluetooth Pairing

To connect a Bluetooth device:

1. Ensure the speaker is powered on.
2. Activate Bluetooth on your audio device (smartphone, tablet, etc.).
3. Press and hold the 'Pairing' button on Channel 4 of the speaker's mixer until the Bluetooth indicator LED flashes.
4. On your device, search for 'HK Audio MOVE 8' in the Bluetooth settings and select it to pair.
5. Once successfully paired, the Bluetooth indicator LED on the speaker will glow solid.

6.3 Mixer Controls

Each channel (1-3) includes:

- **Volume:** Adjusts the input level for the respective channel.
- **Treble:** Controls the high-frequency response.
- **Bass:** Controls the low-frequency response.
- **Reverb:** Adds a reverberation effect to the channel's signal.

Channel 4 has a single Volume control for both Aux and Bluetooth inputs.

The **Master** knob controls the overall output volume of the speaker.

6.4 Battery Operation

The PR:O Move 8 is designed for extended battery operation. The battery status LEDs on the rear panel indicate the remaining charge:

- Green LED: 100% - 50% charge
- Yellow LED: 50% - 20% charge
- Red LED: Below 20% charge (recharge soon)

When the battery is critically low, the speaker may automatically reduce output or shut down to protect the battery.

7. MAINTENANCE

7.1 Cleaning

Regularly clean the speaker's exterior with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or waxes. Ensure no moisture enters the speaker grille or control panel.

7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. For optimal battery health, ensure the battery is charged to approximately 50% before long-term storage and recharge it every few months.

8. TROUBLESHOOTING

If you encounter issues with your PR:O Move 8 speaker, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
No sound output	Speaker not powered on; Master volume too low; Input channel volume too low; Incorrect input selected; Cable issue.	Check power switch and power adapter; Increase Master volume; Increase individual channel volume; Verify correct input connection; Test with different cables.
Poor sound quality / Distortion	Input signal too high (clipping); Volume levels too high; Damaged cable; Speaker placed too close to a wall.	Reduce input gain or source volume; Lower Master or channel volume; Replace faulty cables; Adjust speaker placement.

Problem	Possible Cause	Solution
Bluetooth not connecting	Speaker not in pairing mode; Device too far; Interference; Previously paired device connected.	Press and hold 'Pairing' button; Move device closer to speaker; Turn off other Bluetooth devices; Disconnect from other devices.
Battery not charging	Power adapter not connected properly; Faulty power outlet; Damaged power adapter.	Ensure power adapter is securely connected; Test outlet with another device; Contact support for adapter replacement if suspected faulty.

If the problem persists after trying these solutions, please contact HK Audio customer support or your dealer.

9. SPECIFICATIONS

Feature	Specification
Model Name	MOVE 8
Speaker Type	Portable Speaker, Full Range
Mounting Type	Floor Standing, Pole Mount
Speaker Size	8 Inches (Woofer/Subwoofer Diameter)
Audio Driver Type	Dynamic Driver
Speaker Maximum Output Power	60 Watts
Frequency Response	Up to 20 KHz
Signal-to-Noise Ratio	60 dB
Power Source	Battery Powered
Connectivity Technology	Auxiliary, Bluetooth
Wireless Communication Technology	Bluetooth 5.0
Bluetooth Range	10 Meters
Audio Output Mode	Stereo
Compatible Devices	Smartphone, Tablet, MP3 Player, Desktop, Laptop
Item Weight	8.5 Kilograms (18.7 pounds)
Product Dimensions	0.39 x 0.39 x 0.39 inches (Note: These dimensions appear to be placeholder values and may not reflect the actual product size.)
Indoor/Outdoor Usage	Indoor
Control Method	Touch (Knobs/Buttons)


Feature	Specification
Water Resistance Level	Not Water Resistant

10. WARRANTY AND SUPPORT

The HK Audio Premium PR:O Move 8 speaker comes with a limited warranty. Please refer to the warranty card included with your product or visit the official HK Audio website for detailed warranty terms and conditions.

For technical support, service inquiries, or replacement parts, please contact your authorized HK Audio dealer or visit the HK Audio official support page. When contacting support, please have your product model number (MOVE 8) and serial number available.

Related Documents - MOVE 8

	<p>HK Audio SONAR Xi Series Full-Range Cabinets User Manual User manual for HK Audio SONAR Xi series active full-range speaker cabinets (110 Xi, 112 Xi, 115 Xi). Covers safety, features, operation, connectivity, DSP, Bluetooth, and technical specifications.</p>
	<p>HK Audio POLAR 12 User Manual Comprehensive user manual for the HK Audio POLAR 12 powered column array system, covering setup, operation, features, and technical specifications.</p>
	<p>HK Audio TB-45N Tilt Bracket Installation Instructions Comprehensive installation guide for the HK Audio TB-45N 2x Tilt bracket, detailing compatibility with HK Audio speaker series like Linear 3, Linear 5, Linear 7, and Premium PR:O D2. Includes a parts list, step-by-step assembly instructions with textual descriptions of diagrams, and workload limit specifications.</p>
	<p>Guida alle Misure Bracciali Messika Trova la Tua Taglia Perfetta Scopri la guida ufficiale alle misure dei bracciali Messika. Impara come misurare il tuo polso e trovare la taglia perfetta per il tuo bracciale Messika, dalle collezioni Move Uno a Move Classique.</p>
	<p>2017 Sea-Doo MOVE Trailer Operator's Guide Comprehensive operator's guide for the 2017 Sea-Doo MOVE Trailer, covering safety, operation, maintenance, and specifications. Essential reading for owners of Sea-Doo personal watercraft trailers.</p>



[Uživatelská příručka Move Eco P1-00 EEC Elektrická Tříkolka](#)

Podrobná uživatelská příručka pro elektrickou tříkolku Move Eco P1-00 EEC, pokrývající provoz, bezpečnost, údržbu a technické specifikace.