Arcchio 9968038

Arcchio LED Jolinda Desk Lamp Instruction Manual

Model: 9968038

Introduction

Thank you for choosing the Arcchio LED Jolinda Desk Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before installation and operation, and retain them for future reference.

Safety Information

- Ensure the power supply is disconnected before installation, cleaning, or maintenance.
- This product is designed for indoor use only (IP20 rating).
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.
- Keep the lamp away from water and high humidity.
- The integrated LED light sources are not replaceable.

Setup

1. Unpacking

Carefully remove all components from the packaging. Inspect the lamp for any signs of damage. Retain packaging materials for potential future transport or returns.

2. Mounting the Lamp

The Arcchio Jolinda lamp features a screw clamp for secure attachment to a desk or table surface.

1. Identify a suitable, stable surface for mounting. The clamp requires a sturdy edge.
2. Loosen the screw on the clamp mechanism by turning it counter-clockwise until the clamp opens sufficiently.
3. Position the clamp onto the edge of your desk or table.
4. Tighten the screw by turning it clockwise until the lamp is firmly secured. Ensure it does not wobble. Do not overtighten.



Image: The screw clamp mechanism for secure desk attachment.



Image: The Arcchio Jolinda lamp mounted on a desk, providing illumination.

3. Connecting to Power

Once the lamp is securely mounted, connect it to a suitable power outlet.

1. Ensure the power outlet matches the lamp's voltage requirements (230 Volts).
2. Insert the power plug firmly into the wall socket.



Image: The power cable and plug for connecting the lamp to an electrical outlet.

Operating Instructions

The Arcchio Jolinda lamp features integrated touch controls for easy operation.



Image: The touch control panel with power, brightness, and mode icons.

1. Power On/Off

- To turn the lamp **ON**, gently touch the **Power icon** (top icon).
- To turn the lamp **OFF**, gently touch the **Power icon** again.

2. Brightness Adjustment (Dimmer)

The lamp is equipped with a touch dimmer function, allowing you to adjust the light intensity.

- While the lamp is on, touch and hold the **Brightness icon** (middle icon, typically a sun symbol) to gradually increase or decrease the brightness.
- Release your finger when the desired brightness level is reached.
- The lamp will remember the last brightness setting when turned off and on again.



Image: Illustration of different brightness levels achievable with the touch dimmer.

3. Light Mode Selection (Direct/Indirect)

The lamp offers a direct-indirect light effect. The third icon on the touch panel controls this feature.

- Touch the **Mode icon** (bottom icon) to switch between direct lighting, indirect lighting, or a combination of both.
- Cycle through the available modes by repeatedly touching the icon.

Maintenance

Cleaning

- Always disconnect the lamp from the power supply before cleaning.
- Wipe the lamp with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- Ensure the lamp is completely dry before reconnecting to power.

LED Light Source

The Arcchio Jolinda lamp uses integrated LED light sources that are designed for a long lifespan. These

LEDs are not user-replaceable. If the light source fails, the entire luminaire must be replaced.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Faulty power outlet. Lamp malfunction.	Check if the power plug is fully inserted. Test the outlet with another device. If the problem persists, contact customer support.
Dimmer function not working.	Incorrect operation. Touch sensor issue.	Ensure you are touching and holding the brightness icon. Clean the touch panel. If still not working, contact support.
Light flickers.	Unstable power supply. Internal component issue.	Ensure the power connection is stable. If flickering continues, disconnect and reconnect. If persistent, contact support.

Specifications

Feature	Detail
Brand	Arcchio
Model Number	9968038
Dimensions (L x W x H)	105.6 x 6.4 x 131.4 cm
Weight	4.6 Kilograms
Material	Aluminum, Plastic (Shade), Other metals (Base)
Color	White (RAL 9003)
Voltage	230 Volts
Wattage	70 Watts (1 x 21W LED + 1 x 49W LED)
Luminous Flux	9458 Lumen
Area Lighting Classification	IP20 (Indoor use)
Special Features	Dimmable, Touch Control, Direct-Indirect Effect, UGR<6, Flicker-free
Beam Angle (Up/Down)	Up 110°, Down 50°
Energy Efficiency Class	D (New EU Label)



Image: EU Energy Label for the lamp. For more details, visit the EPREL database.

Warranty and Support

Arcchio products are manufactured to high-quality standards. For information regarding warranty terms and conditions, please refer to the documentation provided with your purchase or contact your retailer.
If you encounter any issues or require technical assistance, please contact the retailer where you purchased the product or visit the official Arcchio website for support information.

© 2023 Arcchio. All rights reserved.