Arcchio Hinka

Arcchio Hinka Ceiling Lamp Instruction Manual

Model: Hinka | Brand: Arcchio

1. Introduction

Thank you for choosing the Arcchio Hinka Ceiling Lamp. This modern ceiling lamp, featuring a sleek black aluminum design and a GU10 bulb fitting, is designed to provide effective illumination in various indoor spaces such as hallways, living rooms, and dining areas. This manual provides essential information for the safe installation, operation, and maintenance of your new lamp.

2. Safety Instructions

- **Electrical Safety:** Always disconnect the main power supply before installation, maintenance, or bulb replacement. Installation should be performed by a qualified electrician if you are unsure.
- **Voltage:** Ensure the power supply voltage matches the lamp's requirements.
- **Bulb Type:** Use only GU10 bulbs with a maximum wattage of 50W. Exceeding the maximum wattage can cause overheating and damage.
- **Environment:** This lamp is designed for indoor use only (IP20 rating). Do not expose it to moisture or extreme temperatures.
- **Heat:** Lamps and bulbs can become hot during operation. Allow them to cool before handling.
- **Cleaning:** Do not use abrasive cleaners or solvents. Refer to the maintenance section for proper cleaning instructions.

3. Package Contents

Please check that all components are present and undamaged:

- Arcchio Hinka Ceiling Lamp Body
- Mounting Bracket
- Screws and Wall Plugs (for mounting)

- Terminal Block (for electrical connection)
- Instruction Manual

4. Specifications

Brand	Arcchio
Model Name	Hinka
Part Number	4251096582147
Style	Modern
Color	Black (exterior), Gold (interior reflector)
Material	Metal (Aluminum)
Special Features	Dimmable (with compatible GU10 bulb and dimmer switch)
Power Source	Mains Powered (Note: Product data incorrectly states 'Battery powered')
Bulb Type	GU10
Max Wattage	50 Watts
Energy Efficiency Label	A++
Dimensions (Approx.)	Diameter: 97mm, Height: 140mm
IP Rating	IP20 (Indoor use only)



Image: Lamp dimensions (Diameter 97mm, Height 140mm).

5. Setup Instructions

5.1 Mounting the Lamp

1. **Turn off Power:** Before starting, ensure the main power supply to the installation area is switched off at the circuit breaker.
2. **Mark Drilling Points:** Hold the mounting bracket against the ceiling at the desired installation location. Use a pencil to mark the positions for drilling holes.
3. **Drill Holes:** Drill holes at the marked positions. Insert the provided wall plugs into the drilled holes.
4. **Attach Mounting Bracket:** Secure the mounting bracket to the ceiling using the provided screws. Ensure it is firmly attached.
5. **Connect Electrical Wires:** Connect the household electrical wires to the terminal block on the lamp's mounting plate. Ensure correct connection of Live (L), Neutral (N), and Earth (E) wires. If your lamp has a separate earth wire, connect it to the earth terminal on the bracket.
6. **Secure Lamp Body:** Carefully align the lamp body with the mounting bracket and secure it using the screws provided. Ensure all connections are tight and the lamp is stable.



Image: Mounting bracket and internal wiring connections.



Image: GU10 bulb socket and interior reflector.

6. Operating Instructions

6.1 Bulb Installation

1. Ensure power is off.
2. Insert a GU10 bulb into the socket by aligning the two pins with the holes and twisting clockwise until it locks into place.
3. Do not force the bulb.

6.2 Powering On/Off

Once installed and the bulb is in place, restore power at the circuit breaker. Use your standard wall switch to turn the lamp on and off.

6.3 Dimming Function

The Arcchio Hinka lamp is dimmable, provided you use a compatible dimmable GU10 bulb and a suitable dimmer switch. Follow the instructions provided with your dimmable bulb and dimmer switch for proper operation.



Image: Arcchio Hinka lamp installed and illuminated.

7. Maintenance

7.1 Cleaning

- Always disconnect power before cleaning.
- Wipe the lamp's exterior with a soft, dry, lint-free cloth.
- Do not use liquid or abrasive cleaners, as they may damage the finish.

7.2 Bulb Replacement

- Ensure the power is off and the bulb has cooled completely.
- Gently push the GU10 bulb upwards and twist it counter-clockwise to remove it from the socket.
- Insert a new GU10 bulb (max 50W) by aligning the pins and twisting clockwise until it locks.
- Restore power.

8. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Faulty bulb. Incorrect wiring.	Check circuit breaker and wall switch. Replace bulb with a new, working GU10 bulb. Verify wiring connections (consult an electrician if needed).
Dimming function not working.	Non-dimmable bulb. Incompatible dimmer switch.	Ensure a dimmable GU10 bulb is installed. Verify that your dimmer switch is compatible with LED or halogen GU10 bulbs.
Lamp flickers.	Loose bulb. Incompatible dimmer/bulb. Power fluctuations.	Ensure bulb is securely seated. Check compatibility of bulb and dimmer. Consult an electrician if power fluctuations are suspected.

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly through your Amazon distributor profile. Keep your proof of purchase for any warranty claims.

© 2026 Arcchio. All rights reserved. Information in this manual is subject to change without notice.