

[Manuals.plus](#) /

› [Fire-Boltt](#) /

› Fire-Boltt BE1100 True Wireless Earbuds User Manual

Fire-Boltt BE1100

Fire-Boltt BE1100 True Wireless Earbuds User Manual

Model: BE1100

1. INTRODUCTION

Thank you for choosing the Fire-Boltt BE1100 True Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read it carefully before use.

Package Contents

- Fire-Boltt BE1100 True Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual



Automatic Pairing



Bluetooth V 5.0



For Sports



Powerful Battery



Image 1.1: Fire-Boltt BE1100 Earbuds and Charging Case.

2. SAFETY INFORMATION

To prevent damage to your device or injury to yourself and others, please observe the following precautions:

- Do not disassemble, repair, or modify the product.
- Do not expose the product to extreme temperatures, humidity, or corrosive environments.
- Keep the product away from water and other liquids.
- Avoid prolonged listening at high volume levels to prevent hearing damage.
- Dispose of batteries and electronic components responsibly according to local regulations.

3. PRODUCT OVERVIEW

Familiarize yourself with the components and features of your Fire-Boltt BE1100 earbuds.

CRISP HIGH-FIDELITY WIRELESS MUSIC



Touch the earbud
once to play



Touch the earbud
once to pause



Touch the R earbud
2secs for next song



Touch the L earbud
2secs for previous song

Image 3.1: Overview of Earbud Components and Charging Case. Key features include Touch Operation area, Indicator Light/Microphone, and Charging Touch Points.

6D STEREO SOUND



Balanced
Tri-Frequency


Image 3.2: Internal structure of the earbud, highlighting the 8mm speaker driver for balanced tri-frequency sound.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB charging cable to the charging port on the case and a power source. The indicator lights on the case will show the charging status.

- **Charging Case:** The case has a 400mAh battery, providing up to 20 hours of total playtime with multiple charges.
- **Earbuds:** Each earbud provides over 6 hours of playtime on a single charge.



6H
POWERFUL
PLAYTIME

20H
PLAYTIME WITH
CHARGING CASE



Image 4.1: Battery life indication for earbuds and charging case.

4.2 Pairing with a Device

The Fire-Boltt BE1100 earbuds feature automatic pairing for convenience.

1. **Step 1:** Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
2. **Step 2:** On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. **Step 3:** Select "Fire-Boltt BE1100" from the list of found devices to connect. Once connected, you will hear a confirmation tone.

The earbuds will automatically reconnect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.

BREATHTAKING MUSIC QUALITY



Truely Wireless



Easy Pairing



In Built Mic



Voice Assistant



Image 4.2: Features including Automatic Pairing and Bluetooth V5.0 connectivity.

5. OPERATING INSTRUCTIONS

The Fire-Boltt BE1100 earbuds feature intuitive touch controls for managing music, calls, and voice assistant.



ONE TOUCH OPERATION

Image 5.1: The earbuds support one-touch operation for various functions.

5.1 Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically.
- **Power Off:** Place earbuds back into the charging case. They will power off automatically and begin charging.

5.2 Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.

5.3 Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

5.4 Voice Assistant

Activate your device's voice assistant (e.g., Siri, Google Assistant) directly from the earbuds.

- **Activate Voice Assistant:** Triple tap on either earbud.



CONVENIENT TOUCH CONTROLS

-  Automatic Power On
-  Automatic Left Right Pairing
-  Large Capacity Battery Charge on the go
-  Superior Sound Quality
-  Clear Voice Calls

Image 5.2: The earbuds offer high-quality music and voice assistant functionality.

6. MAINTENANCE

6.1 Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure charging contacts are clean and free of debris for proper charging.

6.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.

6.3 Battery Care

- Charge the earbuds and case regularly, even if not used for extended periods, to maintain battery health.
- Avoid fully discharging the battery frequently.

7. TROUBLESHOOTING

If you encounter issues with your Fire-Boltz BE1100 earbuds, refer to the following common solutions:

Problem	Solution
---------	----------

Problem	Solution
Earbuds not powering on	Ensure earbuds are charged. Place them in the charging case and then remove them.
Earbuds not pairing	Make sure Bluetooth is enabled on your device. Forget the device in your Bluetooth settings and try pairing again. Ensure earbuds are out of the case.
Only one earbud working	Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them. This should re-sync them.
Low volume or poor sound quality	Adjust volume on your device. Ensure earbuds are clean and properly seated in your ears. Check for obstructions in the earbud mesh.
Charging case not charging	Check the USB cable and power adapter. Ensure the charging port is clean and free of debris.

8. SPECIFICATIONS

Feature	Detail
Model Name	BE1100
Brand	Fire-Boltt
Connectivity	Bluetooth 5.0
Ear Placement	In Ear
Speaker Driver Size	8mm
Earbud Playtime	Up to 6 hours (single charge)
Total Playtime (with case)	Up to 20 hours
Charging Case Battery	400mAh
Control Type	Touch, Voice
Weight	80 Grams (total product)
Material	Plastic

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The Fire-Boltt BE1100 True Wireless Earbuds come with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

For technical assistance, warranty claims, or any other inquiries, please contact Fire-Boltt customer support. Refer to the official Fire-Boltt website or your purchase documentation for the most up-to-date contact information.

© 2026 Fire-Boltt. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question