Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arcchio 9928030

Arcchio Kubika Ceiling Light Instruction Manual

Model: 9928030

1. Safety Instructions

Please read these instructions carefully before installation and use. Keep this manual for future reference.

- **Electrical Safety:** Always switch off the main power supply at the fuse box or circuit breaker before commencing any installation, maintenance, or bulb replacement.
- **Qualified Electrician:** Installation should only be performed by a qualified electrician or competent person in accordance with local wiring regulations.
- **Voltage:** Ensure the voltage supply matches the requirements specified on the product label (230 Volt).
- **Indoor Use Only:** This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- **Bulb Type:** Use only GU10 LED bulbs as specified. Do not exceed the maximum wattage of 10 watts per bulb.
- **Handling:** Handle the light fixture with care to avoid damage.

2. Package Contents

Verify that all components are present before beginning installation:

- Arcchio Kubika Ceiling Light Fixture (Model 9928030)
- Mounting Bracket
- Screws and Wall Plugs for mounting
- Instruction Manual

Note: Light bulbs (GU10) are not included and must be purchased separately.

3. Specifications


Feature	Specification
Brand	Arcchio
Model Name	Kubika

Model Number	9928030
Dimensions (L x W x H)	18.6 cm x 9.3 cm x 9.4 cm
Material	Aluminum
Color	White
Voltage	230 Volt
Wattage (Max per bulb)	10 Watt
Lamp Fitting	GU10
Light Source	LED (not included)
Brightness (Max)	1600 Lumen
Special Features	Dimmable (requires compatible dimmer switch and dimmable GU10 bulbs)
Control Method	Touch (via compatible wall switch)
Mounting Type	Ceiling Mounting
Usage Environment	Indoor

4. Setup and Installation


Follow these steps for safe and correct installation:

1. **Power Off:** Before starting, ensure the main power supply to the installation area is switched off at the circuit breaker or fuse box.
2. **Prepare Mounting Surface:** Identify a suitable location on the ceiling. Consider the dimensions of the fixture for placement.



Technical drawing showing the dimensions of the Arcchio Kubika Ceiling Light: 186mm length, 93mm width, 94mm height.

3. **Mark Drilling Points:** Use the mounting bracket as a template to mark the precise drilling points on the ceiling.
4. **Drill Holes:** Drill holes at the marked positions and insert the appropriate wall plugs (if required for your ceiling type).
5. **Attach Mounting Bracket:** Secure the mounting bracket to the ceiling using the provided screws.
6. **Wiring Connections:** Connect the household electrical wires to the terminal block inside the light fixture. Ensure correct polarity (Live, Neutral, Earth) according to local electrical codes.



Internal view of the Arcchio Kubika Ceiling Light showing wiring connections. Ensure all connections are secure and properly insulated.

7. **Attach Fixture:** Carefully attach the light fixture body to the mounting bracket, ensuring all wires are safely tucked away and not pinched. Secure the fixture using the provided screws.
8. **Install Bulbs:** Insert GU10 LED bulbs (not included) into the lamp fittings. Twist gently to secure them in place.



The Arcchio Kubika Ceiling Light fully installed on a ceiling, showcasing its modern design with two adjustable light sources.

9. **Power On:** Restore power at the circuit breaker. Test the light fixture to ensure it functions correctly.

5. Operating Instructions

5.1 Turning On/Off

The Arcchio Kubika Ceiling Light is operated via a standard wall switch connected to your household electrical system.

5.2 Dimming Function

This light fixture is dimmable. To utilize the dimming feature, you must:

- Install dimmable GU10 LED bulbs (not included).
- Connect the fixture to a compatible external dimmer switch (not included) in your wall.

Consult the instructions for your specific dimmer switch for proper operation and compatibility with LED bulbs.

6. Maintenance

6.1 Cleaning

To clean the light fixture, ensure the power is off. Use a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish and electrical components.

6.2 Bulb Replacement

When a bulb needs replacement:

1. **Power Off:** Switch off the main power supply to the fixture at the circuit breaker.
2. **Cool Down:** Allow the bulb to cool completely before touching it to prevent burns.
3. **Remove Old Bulb:** Gently twist and pull out the old GU10 bulb from its fitting.
4. **Insert New Bulb:** Insert a new GU10 LED bulb (max 10W) into the fitting and twist to secure. Ensure it is fully seated.
5. **Power On:** Restore power and test the new bulb.

7. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power supply. Bulb is faulty or not installed correctly. Wiring error.	Check circuit breaker and wall switch. Ensure bulbs are correctly inserted and functional. Replace if necessary. Verify wiring connections (consult a qualified electrician if unsure).
Dimming function does not work.	Non-dimmable bulbs installed. Incompatible dimmer switch. Dimmer switch faulty.	Ensure dimmable GU10 LED bulbs are used. Verify dimmer switch compatibility with LED bulbs. Test dimmer switch or consult an electrician.
Light flickers.	Loose bulb connection. Incompatible dimmer or bulb. Voltage fluctuations.	Ensure bulbs are securely seated. Check dimmer and bulb compatibility. Consult an electrician if voltage issues are suspected.

8. Warranty and Support

Arcchio products are manufactured to high-quality standards. For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official Arcchio website.

Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KHG9WQP

More documents and user manuals: **https://manuals.plus/**