Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arcchio 9928031

Arcchio Cubic Ceiling Light Instruction Manual

Model: 9928031 | Brand: Arcchio

1. Introduction

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your Arcchio Cubic Ceiling Light, Model 9928031. Please read these instructions carefully before proceeding with installation or use, and retain them for future reference.

The Arcchio Cubic Ceiling Light is designed for indoor use, featuring a modern aesthetic with two GU10 light sources. It is suitable for various indoor environments such as hallways, living rooms, and dining areas.

2. Safety Information

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement.
- **Voltage:** Ensure the supply voltage matches the specified operating voltage of 230 Volts.
- **Bulb Type:** Use only GU10 bulbs, with a maximum wattage of 50W per bulb.
- **Environment:** This product has an IP20 rating, indicating protection against solid objects larger than 12.5mm. It is not protected against water and should only be used in dry indoor locations.
- **Heat:** Light sources can become hot. Allow bulbs to cool before handling or replacing.
- **Cleaning:** Do not use abrasive cleaners or solvents. Refer to the Maintenance section for cleaning instructions.

3. Package Contents

Verify that all components are present and undamaged before installation. If any parts are missing or damaged, contact your retailer.

- Arcchio Cubic Ceiling Light fixture (1 unit)
- Mounting hardware (screws, wall plugs)
- Instruction Manual (this document)

Note: GU10 bulbs are typically sold separately and are not included with the fixture.

4. Product Overview

The Arcchio Cubic Ceiling Light features a rectangular housing made of aluminum, designed to hold two GU10 light

sources. The light sources are recessed within the fixture, providing a focused illumination.



Figure 4.1: Front view of the Arcchio Cubic Ceiling Light when unlit.



Figure 4.2: The Arcchio Cubic Ceiling Light installed on a ceiling, with both bulbs illuminated.




Figure 4.3: Dimensions of the Arcchio Cubic Ceiling Light: Length 186mm, Width 93mm, Height 94mm.



Figure 4.4: Close-up view of a GU10 bulb socket inside the fixture.

5. Specifications

Feature	Specification
Model Number	9928031
Brand	Arcchio
Material	Aluminum / Other metals
Color	Black
Dimensions (L x W x H)	18.6 cm x 9.3 cm x 9.4 cm
Weight	0.97 kg

Feature	Specification
Light Source Type	GU10
Number of Light Sources	2
Max Wattage per Bulb	50 W
Operating Voltage	230 Volts
Housing Rating (IP)	IP20
Protection Class	I
Special Features	Dimmable (with compatible bulbs and dimmer switch)
EU Energy Efficiency Label	A++

6. Setup and Installation

Warning: Installation should only be carried out by a qualified electrician. Ensure power is disconnected at the main circuit breaker before beginning installation.

1. **Prepare the Installation Area:** Choose a suitable location on the ceiling. Ensure the ceiling material can support the weight of the fixture.
2. **Disconnect Power:** Turn off the electricity supply to the installation area at the main circuit breaker. Verify that the power is off using a voltage tester.
3. **Mount the Bracket:** The fixture includes a mounting plate. Position the mounting plate on the ceiling where the light is to be installed. Mark the drilling points. Drill holes and insert appropriate wall plugs (if necessary). Secure the mounting plate to the ceiling using the provided screws.



Figure 6.1: Rear view of the fixture showing the mounting plate and terminal block for electrical connections.

4. **Electrical Connection:** Connect the household electrical wires to the terminal block on the fixture's mounting plate. Ensure correct polarity: Live (L), Neutral (N), and Earth (⚡). Double-check all connections for security.
5. **Attach the Fixture:** Carefully align the main body of the ceiling light with the mounting plate and secure it using the provided screws or locking mechanism.
6. **Install Bulbs:** Insert two GU10 bulbs (max 50W each) into the sockets by pushing them in and twisting clockwise until secure.
7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the main circuit breaker.

7. Operating Instructions

The Arcchio Cubic Ceiling Light is operated via a standard wall switch connected to your household electrical circuit.

- **Turning On/Off:** Flip the wall switch to the 'ON' position to illuminate the light. Flip it to the 'OFF' position to turn the light off.
- **Dimmability:** If you have installed dimmable GU10 bulbs and connected the fixture to a compatible dimmer switch,

you can adjust the light intensity using the dimmer control.

8. Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling light.

- **Cleaning:** Before cleaning, ensure the power is disconnected. Allow the fixture to cool completely. Wipe the exterior surfaces with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Bulb Replacement:** Disconnect power before replacing bulbs. Allow old bulbs to cool. Gently push the old GU10 bulb into its socket and twist counter-clockwise to remove. Insert a new GU10 bulb (max 50W) by pushing it in and twisting clockwise until secure.
- **Inspection:** Periodically inspect the fixture for any signs of damage, loose connections, or wear. If any issues are found, disconnect power and consult a qualified electrician.

9. Troubleshooting

If you encounter issues with your Arcchio Cubic Ceiling Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power supply Faulty bulb Loose wiring connection	Check circuit breaker. Ensure wall switch is ON. Replace bulb. Disconnect power and check wiring connections. Consult an electrician if unsure.
Light flickers	Loose bulb Incompatible dimmer switch/bulb Fluctuating power supply	Ensure bulb is securely twisted into socket. Verify dimmer and bulbs are compatible and rated for LED/dimmable use. Consult an electrician to check household wiring.
One bulb not working	Faulty bulb Loose connection to one socket	Replace the non-working bulb. Disconnect power and check the connection to the specific bulb socket.

If the problem persists after attempting these solutions, disconnect power and contact a qualified electrician or the retailer for assistance.

10. Warranty and Support

For warranty information, please refer to the terms and conditions provided by your retailer or the manufacturer, Arcchio. Typically, a warranty covers defects in materials and workmanship under normal use.

If you require technical support or have questions not covered in this manual, please contact your point of purchase or visit the official Arcchio website for customer service contact details.

© 2023 Arcchio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KHGBCYT

More documents and user manuals: **https://manuals.plus/**