

## VIZIO V Series 2018

# VIZIO V-Series 43-inch 4K HDR Smart TV (Model V Series 2018) Instruction Manual

Your Guide to Setup, Operation, and Features

## INTRODUCTION

---

Welcome to your VIZIO V-Series 43-inch 4K HDR Smart TV, Model V Series 2018. This television delivers stunning 4K Ultra HD resolution, vibrant Dolby Vision HDR, and smart features for an immersive entertainment experience. Equipped with the VIZIO IQ Active 4K HDR Processor and Full Array Backlight, it ensures superior picture quality and uniform brightness. This product is part of the Amazon Renewed program, professionally inspected and tested to work and look like new.

*Please note: The SmartCast feature is no longer available for use outside of the USA, as the Vizio manufacturer has disabled this feature for international use.*

## SETUP

---

### 1. Unpacking and Stand Assembly

Carefully remove your VIZIO TV from its packaging. Ensure all included components are present: Power Cable, Remote Control, and Stand.



Figure 1: Rear view of the VIZIO V-Series TV with the stand attached. The stand feet are designed for easy slide-in installation at the bottom of the TV.

To attach the stand, align each stand leg with the corresponding slots at the bottom of the TV. Slide the legs into place and secure them with the provided screws. Alternatively, the TV is wall-mountable (mounting hardware sold separately).

## 2. Connecting Peripherals

Your VIZIO TV offers multiple connectivity options for your devices.



Figure 2: Detailed view of the TV's input/output ports. These include multiple HDMI ports, a USB port, composite video/audio inputs, and an Ethernet port.

- **HDMI Ports:** Connect your cable box, gaming console, Blu-ray player, or other HDMI-enabled devices.
- **USB Port:** Insert a USB flash drive to view photos, play music, or watch videos directly on your TV.
- **Ethernet Port:** For a stable wired internet connection.
- **Antenna/Cable Input:** Connect an antenna for over-the-air broadcasts or a cable TV connection.
- **Audio Out (Optical/RCA):** Connect to external sound systems or soundbars for enhanced audio.

## 3. Initial Power On and Network Connection

Plug the power cable into the TV and a wall outlet. Press the power button on the TV or the remote control.

Follow the on-screen prompts to select your language, connect to your Wi-Fi network, and complete the initial setup.

## OPERATING YOUR TV

---

### 1. Remote Control

The included remote control provides full functionality for navigating your VIZIO Smart TV.



Figure 3: The VIZIO remote control features dedicated buttons for popular streaming apps like Netflix, Prime Video, and Hulu, along with standard navigation and volume controls.

- **Power Button:** Turns the TV on/off.
- **Navigation Pad (OK button):** Use to move through menus and select items.
- **Volume Up/Down:** Adjusts the audio level.
- **Input Button:** Cycles through available input sources.
- **Dedicated App Buttons:** Quick access to popular streaming services.
- **Menu Button:** Accesses the main settings menu for picture, sound, network, and more.

For added convenience, you can also download the VIZIO SmartCast Mobile app on your smartphone to use it as a remote control.

### 2. Smart TV Features (SmartCast)

Your VIZIO Smart TV comes with SmartCast built-in, offering a wide array of streaming content and apps. The home screen provides easy access to trending shows, movies, and live TV options.

Video 1: This video demonstrates the VIZIO Smart TV interface, showcasing the ease of navigation and the variety of streaming apps available directly on the home screen. It highlights the TV's smart capabilities for accessing entertainment.

- **Pre-installed Apps:** Enjoy immediate access to services like Netflix, Prime Video, Hulu, Disney+, YouTube, and more.
- **Add Apps:** Explore the app store to download additional streaming services and content.
- **Content Discovery:** The SmartCast interface helps you discover new content based on your viewing habits and preferences.
- **Voice Control:** Integrate your VIZIO TV with Google Home or Alexa for hands-free control.

### 3. Picture Settings

Optimize your viewing experience by adjusting the picture settings:

Video 2: This video highlights the VIZIO TV's excellent picture quality and high-quality display. It demonstrates various picture modes and settings that can be adjusted to enhance the visual experience for different content types.

- **Picture Mode:** Select from presets like Standard, Vivid, Calibrated, Game, or Sports to suit your content.
- **Dolby Vision HDR:** Experience incredible brightness, contrast, and color. The TV also supports HDR10+ and HLG formats.
- **4K Ultra HD:** Enjoy breathtaking detail with over 8 million pixels.
- **Full Array Backlight:** LEDs are evenly distributed for superior light uniformity and performance.
- **VIZIO IQ Active 4K HDR Processor:** Delivers superior picture processing and intelligent 4K upscaling.

### 4. Audio Settings

Access the audio settings through the main menu to adjust volume, sound mode, and other audio enhancements.

### 5. Voice Control

Your VIZIO Smart TV is compatible with popular voice assistants. You can use voice commands through devices like Google Home or Alexa to control your TV, change channels, launch apps, and more.

## MAINTENANCE

---

### 1. Cleaning the Screen

To clean the screen, gently wipe it with a soft, dry microfiber cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.

### 2. General Care

Keep the TV in a well-ventilated area. Avoid exposing it to direct sunlight, extreme temperatures, or high humidity. Ensure cables are securely connected and not under strain.

## TROUBLESHOOTING

---

If you encounter any issues with your VIZIO TV, refer to the built-in User Manual for detailed troubleshooting steps. You can access it via the TV's settings menu.

For common issues like no power, no picture, or network connectivity problems, try the following:

- **No Power:** Ensure the power cable is securely plugged into both the TV and a working electrical outlet.
- **No Picture:** Verify the correct input source is selected. Check all cable connections to external devices.
- **Network Issues:** Restart your router and modem. Reconnect the TV to your Wi-Fi network through the settings menu.

For more advanced assistance, scan the QR code provided in the TV's user manual section or visit [vizio.com/manuals](https://vizio.com/manuals) and enter your TV model (V Series 2018) to view or download the full manual.

## SPECIFICATIONS

Feature	Detail
Brand Name	VIZIO
Model Number	V Series 2018
Screen Size	42.5 Inches (43-inch Diag.)
Display Technology	LED
Resolution	4K Ultra HD
Refresh Rate	120 Hz
Special Feature	Flat, Dolby Vision HDR, HDR10+, HLG, Full Array Backlight, IQ Active Processor
Connectivity Technology	Bluetooth, Ethernet, USB, WiFi
Item Weight	21.3 pounds
Product Dimensions	8.35"D x 38.31"W x 24.52"H



Figure 4: Dimensional overview of the VIZIO V-Series 43-inch TV.

## WARRANTY AND SUPPORT

As an Amazon Renewed product, your VIZIO V-Series TV is backed by the [Amazon Renewed Guarantee](#). This means if you are not satisfied with your purchase, renewed products are eligible for replacement or refund within 90 days of receipt under the Amazon Renewed Guarantee. For customer support, please refer to the Amazon Renewed support channels or the VIZIO official website for product-specific assistance.