Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Cecotec /
- > Cecotec Juice&Live 2500 EasyClean Cold Press Juicer Instruction Manual

Cecotec 04276

Cecotec Juice&Live 2500 EasyClean Cold Press Juicer

Model: 04276 | Brand: Cecotec

INTRODUCTION

The Cecotec Juice&Live 2500 EasyClean is an advanced cold press juicer designed for efficient and nutrient-rich juice extraction from various fruits and vegetables. Utilizing a slow juicing system, it operates at a low speed of 70 RPM, which helps to preserve the natural vitamins, minerals, and enzymes by minimizing oxidation and heat generation. Its innovative EasyClean filter, designed without stainless steel mesh, significantly simplifies the cleaning process. The appliance also features an extra-large feeding chute, allowing for the processing of whole fruits and vegetables, and a quiet motor for a more pleasant user experience.



Image: The Cecotec Juice&Live 2500 EasyClean Cold Press Juicer, showcasing its compact design and included collection cups.

IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage to the appliance, please read and adhere to the following safety guidelines:

- Always read all instructions before using the appliance.
- Keep the appliance out of reach of children and individuals with reduced physical, sensory, or mental capabilities.
- Do not immerse the motor unit, power cord, or plug in water or any other liquid.
- Unplug the appliance from the power outlet before cleaning, assembling, or disassembling any parts.
- Do not operate the juicer if the power cord or plug is damaged, or if the appliance malfunctions or has been dropped.
- Use only original Cecotec replacement parts and accessories to avoid voiding the warranty and ensure proper function.
- Never push food into the feeding chute with your fingers or other utensils. Always use the provided food pusher.
- Ensure all parts are correctly and securely assembled before turning on the appliance. The safety system prevents

operation if not properly assembled.

- Avoid placing the appliance near hot surfaces, such as stoves or ovens.
- Do not process frozen fruits or vegetables directly without thawing them first, as this can damage the auger and filter.

PRODUCT COMPONENTS

Familiarize yourself with the various parts of your Cecotec Juice&Live 2500 EasyClean juicer:

- 1. Motor Unit: The base containing the motor and control switch.
- 2. Feeding Chute (XL): The wide opening for inserting fruits and vegetables.
- 3. **Pusher:** Used to guide ingredients into the feeding chute.
- 4. Drum: The transparent chamber where juicing takes place.
- 5. Auger (Pressing Screw): The spiral component that crushes and presses ingredients.
- 6. **EasyClean Filter:** The strainer that separates juice from pulp.
- 7. Juice Outlet: Spout from which the extracted juice flows.
- 8. Pulp Outlet: Opening for the expelled pulp.
- 9. Anti-drip Cap: A stopper for the juice outlet to prevent drips.
- 10. Juice Carafe: Container for collecting the extracted juice (500 ml capacity).
- 11. Pulp Carafe: Container for collecting the separated pulp.
- 12. Cleaning Brush: Tool for assisting with cleaning, especially the filter.

SETUP AND ASSEMBLY

Follow these steps to correctly assemble your juicer before first use:

- 1. Place the motor unit on a clean, stable, and flat surface. Ensure it is away from the edge of the counter.
- 2. Align the drum with the motor unit base and rotate it clockwise until it locks securely into place.
- 3. Insert the EasyClean filter into the drum, ensuring it sits firmly.
- 4. Place the auger (pressing screw) into the center of the filter, pushing it down until it clicks into position.
- 5. Attach the feeding chute assembly onto the top of the drum, aligning the arrows and twisting until it locks. The safety system will prevent operation if not correctly aligned.
- 6. Position the juice carafe under the juice outlet and the pulp carafe under the pulp outlet.
- 7. Ensure the anti-drip cap on the juice outlet is in the closed position before starting to juice.



Image: Demonstrating the large feeding chute, capable of accommodating whole fruits like an apple.

OPERATING INSTRUCTIONS

Follow these steps to extract juice from your ingredients:

- 1. **Prepare Ingredients:** Wash all fruits and vegetables thoroughly. For ingredients with hard pits (e.g., peaches, cherries) or large seeds (e.g., apples), remove them before juicing. While the XL chute can handle whole items, cutting larger or fibrous ingredients into smaller pieces (e.g., celery, leafy greens) can improve efficiency and juice yield.
- 2. Position Containers: Ensure the juice carafe is placed under the juice outlet and the pulp carafe under the pulp outlet.
- 3. Plug In: Connect the power cord to a suitable electrical outlet.
- 4. **Start Juicing:** Turn the control switch to the "ON" position. The motor will start.
- 5. **Feed Ingredients:** Slowly feed the prepared fruits and vegetables into the feeding chute. Use the provided pusher to gently guide the ingredients down. Do not force ingredients or apply excessive pressure, as this can strain the motor.
- 6. **Reverse Function:** If ingredients become jammed or the juicer appears to be struggling, switch the control to the "REVERSE" position for a few seconds. This will rotate the auger in the opposite direction to clear blockages. Then,

- switch back to "ON" to resume juicing.
- 7. **Collect Juice:** The fresh juice will flow into the juice carafe, and the dry pulp will be expelled into the pulp carafe.
- 8. **Finish Juicing:** Once all ingredients have been processed, turn the control switch to the "OFF" position and unplug the appliance from the power outlet.



Image: The juicer in operation, producing fresh orange juice.



Image: The juicer processing green ingredients to create a vibrant green juice.



Image: The juicer producing a rich red juice from various fruits.



Image: A detailed view of the juice extraction process, showing the clear juice flowing.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your juicer. The EasyClean filter design makes this process simpler:

- 1. **Immediate Cleaning:** After each use, unplug the appliance and disassemble all removable parts (feeding chute, drum, filter, auger, juice/pulp carafes).
- 2. Rinsing: Rinse all disassembled parts under running water.
- 3. **Filter Cleaning:** Use the provided cleaning brush to remove any pulp residue from the EasyClean filter. Its design without fine mesh makes it easier to clean compared to traditional filters.
- 4. **Dishwasher Safe:** All removable parts are dishwasher safe, making cleaning even more convenient. Place them on the top rack of your dishwasher.
- 5. **Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or spray it with water.
- 6. Drying and Storage: Ensure all parts are completely dry before reassembling or storing the appliance. Store the juicer



Image: The EasyClean filter being rinsed, highlighting its simplified cleaning process.

TROUBLESHOOTING

If you encounter any issues with your Cecotec Juice&Live 2500 EasyClean, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Parts not assembled correctly. Power outage.	Ensure the power cord is securely plugged into a working outlet. Disassemble and reassemble all parts, ensuring they lock into place. The safety system prevents operation if not correctly assembled. Check your household's power supply.

Problem	Possible Cause	Solution
Low juice yield or wet pulp.	Ingredients are too hard or fibrous. Feeding ingredients too quickly. Filter is clogged.	Cut hard or fibrous ingredients into smaller pieces. Feed ingredients slowly and allow the juicer to process them completely before adding more. Clean the filter thoroughly after each use.
Motor stops during operation.	Overload protection activated. Ingredients jammed.	Turn off the appliance, unplug it, and let the motor cool down for at least 30 minutes before resuming. Use the "REVERSE" function to clear the blockage. If persistent, disassemble and clear manually.
Loud noise or vibration.	Parts not assembled correctly. Foreign object inside.	Disassemble and reassemble all parts carefully, ensuring they are securely locked. Unplug the appliance and check for any foreign objects that may have fallen into the chute or drum.

SPECIFICATIONS

Brand:	Cecotec		
Model Number:	04276		
Color:	Black		
Dimensions (L x W x H):	37 x 21 x 31.5 cm		
Weight:	3.94 Kilograms		
Juice Carafe Capacity:	500 Milliliters		
Power:	200 Watts (DC Motor)		
Rotation Speed:	70 RPM (Slow Juicing)		
Material:	Stainless Steel (parts), Tritan (drum & carafes), BPA-Free		
Special Features:	EasyClean Filter, XL Feeding Chute, Anti-drip Cap, Compact Design		

WARRANTY AND SUPPORT

Cecotec is committed to providing quality products. This appliance is designed for household use and comes with a commitment to spare parts availability for 10 years.

For warranty claims, technical support, or inquiries regarding spare parts, please contact your retailer or the official Cecotec customer service in your region. Keep your proof of purchase for any warranty-related requests.

For more information, visit the official Cecotec website or refer to the contact details provided with your purchase.

Related Documents - 04276





Cecojuicer Zitrus Instruction Manual - Cecotec Citrus Juicer Setup, Operation, and Safety Guide

Official instruction manual for the Cecojuicer Zitrus by Cecotec. This guide provides detailed information on setup, operation, safety precautions, cleaning, maintenance, technical specifications, and warranty for the Cecojuicer Zitrus turbo-juicer.

Bederungsrichten Massisch sterne Menselde Entrade



Cecotec ToothCare EasyClean: Manual de Instrucciones y Especificaciones Técnicas

Descubra el manual de instrucciones y especificaciones técnicas para el limpiador ultrasónico Cecotec ToothCare EasyClean. Aprenda sobre su funcionamiento, mantenimiento y características.



Cecotec GrandHeat 2500 Flatbed Touch White Microwave Oven User Manual

Comprehensive user manual for the Cecotec GrandHeat 2500 Flatbed Touch White microwave oven, covering installation, operation, features, maintenance, troubleshooting, and warranty.



Manual de Instrucciones Conga Rockstar 2500 Thunder Jalisco

Guía completa de instrucciones para el aspirador vertical Conga Rockstar 2500 Thunder Jalisco de Cecotec. Aprenda a usar, limpiar y mantener su aspirador para un rendimiento óptimo.



Cecotec BAKE&FRY 2500 TOUCH Air Fryer Oven - User Manual

Comprehensive user manual for the Cecotec BAKE&FRY 2500 TOUCH and BAKE&FRY 2500 TOUCH WHITE hot air fryer oven. Includes safety instructions, operation guide, cleaning, troubleshooting, and technical specifications.



Manual de Usuario Motocicleta Eléctrica Cecotec Halo

Guía completa para la motocicleta eléctrica Cecotec Halo. Aprenda sobre su funcionamiento, seguridad, mantenimiento y especificaciones técnicas para un uso óptimo y seguro.

Documents - Cecotec - 04276



[pdf] User Manual Instructions Troubleshooting Guide Specifications Warranty

JUICE LIVE 2500 EASYCLEANKoд продукту 04276 Потужність 200 Вт Вольтаж і напруга 220 Service

of Cecotec in order to avoid any type danger Always turn 04276 juicelive easyclean manual yv 01200402

1i citrus world files 1 |||

JUICE LIVE 2500 EASYCLEAN //Juicer Instruction manual 1. 3 2. 6 3. 6 4. 6 ... 3-5 , . , 15 . . , , , ... 8. : Juice Live 2500 EasyClean : $\bf 04276$: 200 : 220-240 , 50 9. 2012/19 / eu weee , . , ...

lang:en score:37 filesize: 2.28 M page_count: 27 document date: 2021-03-26



[pdf] User Manual Instructions Troubleshooting Guide Specifications Warranty Инструкции по эксплуатации руководство пользователя Соковыжималка Cecotec Juice Live 2500 EasyClean купить низкой цене в Киеве Украине Официальный сайт 922f63568e17447fd689549420039145 cecotec ua upload medialibrary 922 |||

JUICE LIVE 2500 EASYCLEAN //Juicer Instruction manual 1. 3 2. 6 3. 6 4. 6 ... 3-5 , . , 15 . . , , , ... 8. : Juice Live 2500 EasyClean : **04276** : 200 : 220-240 , 50 9. 2012/19 / eu weee , . , ...

lang:en score:24 filesize: 2.28 M page_count: 27 document date: 2021-03-26



[pdf] User Manual Instructions Accessories Label

JUICE LIVE 2500 EASYCLEAN Appliance HubDo not place the device close to heat sources flammable or explosive substances Slowly introduce fruit pieces ensure no damage occursUser Manualappliancehub mt content docs products 26673 web User Manual |||

JUICE LIVE 2500 EASYCLEAN Licuadora de prensa fra / Cold-press juicer Manual de instrucciones Instru ... iance to emit louder sounds than soft ingredients. 7. TECHNICAL SPECIFICATIONS Product reference: **04276** Product: Juice Live 2500 EasyClean Rated voltage: 220-240 V- Frequency: 50-60Hz Rated power: 2... lang:en score:22 filesize: 542.61 K page_count: 12 document date: 2024-09-02



[pdf] User Manual Instructions Troubleshooting Guide Specifications Warranty

JUICE LIVE 2500 EASYCLEAN juicelive easyclean vectorial image cdn cecotec cloud media files |||

JUICE LIVE 2500 EASYCLEAN Licuadora de prensa fra / Cold-press juicer Manual
de instrucciones Instru ... rato emite un sonido y vibra mientras funciona 7.


ESPECIFICACIONES TCNICAS Referencia del producto: 04276 Producto: Juice Live
2500 EasyClean Voltaje: 220-240 V- Frecuencia: 50-60Hz Potencia nominal: ...
lang:it score:21 filesize: 806.73 K page_count: 48 document date: 2020-10-07



Cecotec Product Catalogue - February 2022

Explore the comprehensive Cecotec product catalogue for February 2022, featuring a wide range of household appliances including robot vacuum cleaners, kitchen appliances, personal care items, and more. Discover innovative technology and value from Cecotec brands like Conga, Mambo, and Bongo.

lang:en score:20 filesize: 137.82 M page_count: 1196 document date: 2022-03-07



[pdf] Accessories Catalog

Catalogo Licuadoras de prensa fr\u00eda 2023 CECOTEC ENcdn cecotec cloud s3 amazonaws media IFA2023 EN |||

lang:en score:19 filesize: 20.99 M page_count: 11 document date: 2023-04-03



[pdf] Catalog

Cecotec Tienda Oficial Envío Gratis Mejor Precio Catalogo Licuadoras de prensa friia CECOTEC EN cdn cecotec cloud media IFA2022 en |||

CECOJUICER JUICE LIVE Cold-press juicer EasyClean enjoy it Index EasyClean filter EasyClea ... 3 kg 42.5 x 38.5 x 64.4 cm 18.8 kg 18.2 x 16.4 x 46.3 cm 3.94 kg 220-240 V -, 50/60 Hz 200 W 8435484**04276**5 Box 18435484**04276**2 Master **04276** 18 Discover the range 19 Juice Live 3000 EasyClean 1...

lang:en score:19 filesize: 21.72 M page_count: 13 document date: 2022-08-23



[pdf] User Manual Instructions Troubleshooting Guide Specifications Warranty
CECOFRY DELUXE RAPID SUN MOON04266 04276 Cecofry Si el cable presenta daños debe ser
reparado por Servicio de Asistencia Técnica oficial Cecotec para evitar cualquier tipo de A1Fw4RwT cLm
media amazon images I A1Fw4RwT cL |||

CECOFRY DELUXE RAPID SUN / MOON Freidora diettica / Air fryer 04266_04276_Cecofry Deluxe Rapid Sun_Moon_Manual_YV_01200403.indd 1 Manual de instrucciones Instruction manual Manuel d instructions Bedienungsanleitung Manuale di istruzioni Manual de instrues 6/4/20 11:02 Instrucciones de seguridad ...

lang:it score:17 filesize: 1.16 M page_count: 82 document date: 2020-04-06



Cecotec General Catalog February 2021

Explore the comprehensive Cecotec General Catalog from February 2021, featuring a wide range of home appliances including vacuum cleaners, kitchen robots, coffee makers, and more. Discover innovative technology and quality products designed to enhance everyday living.

lang:es score:12 filesize: 49.86 M page count: 886 document date: 2021-03-31