

[Manuals.plus](#) /

› [BoomPods](#) /

› BoomPods Zero Bluetooth Speaker User Manual

BoomPods ZERO

BoomPods Zero Bluetooth Speaker User Manual

Model: ZERO

INTRODUCTION

The BoomPods Zero is an ultra-compact, portable Bluetooth speaker designed for on-the-go audio. It features a high-quality driver, supports Bluetooth connectivity for various devices, and includes functions like volume control, call handling, and a remote camera shutter for selfies. The speaker is built with an IPX6 waterproof rating and a rugged, drop-proof design, making it suitable for diverse environments.

This manual provides instructions for setting up, operating, maintaining, and troubleshooting your BoomPods Zero speaker.




Image: The BoomPods Zero speaker, highlighting its compact design.

SETUP

Package Contents

Ensure all items are present in the package:

- BoomPods Zero Bluetooth Speaker
- Type C to USB charging cable

Charging the Speaker

Before first use, fully charge the BoomPods Zero speaker. The speaker can be charged via the included USB-C cable or wirelessly using a compatible charging pad.

1. **USB-C Charging:** Connect the Type C to USB charging cable to the speaker's charging port and a USB power source (e.g., wall adapter, computer USB port).
2. **Wireless Charging:** Place the speaker on a compatible wireless charging pad. The charging indicator light will illuminate.

A full charge takes approximately 5 hours and provides up to 5 hours of playback time.



Image: The BoomPods Zero speaker being charged wirelessly.

the tiny speaker with a lot on its mind



Image: The BoomPods Zero speaker with its USB-C charging port.

Powering On/Off

- **To Power On:** Press and hold the power button (location typically on the base or side) until you hear an audible cue or see an indicator light.
- **To Power Off:** Press and hold the power button again until the speaker powers down.

Bluetooth Pairing

To connect your BoomPods Zero speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing LED light, typically blue). If not, press and hold the Bluetooth button (if available) or power button to initiate pairing mode.
2. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
3. Search for available devices and select "BoomPods Zero" from the list.

4. Once connected, the speaker will provide an audible confirmation, and the LED light will typically turn solid.

The speaker has a Bluetooth range of up to 10 meters (33 feet).

OPERATING INSTRUCTIONS

Basic Controls

The BoomPods Zero speaker features integrated controls for media playback and calls:

- **Play/Pause:** Press the main button once to play or pause audio.
- **Volume Control:** Use the volume controls on your connected device.
- **Answer/End Call:** Press the main button once to answer an incoming call or end an ongoing call.
- **Reject Call:** Press and hold the main button to reject an incoming call.

Dual Pairing (True Stereo Sound)

Two BoomPods Zero speakers can be paired together to create a true stereo sound experience:

1. Ensure both BoomPods Zero speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker, press and hold the pairing button (refer to speaker diagram if available) until it enters dual pairing mode.
3. The two speakers will automatically connect to each other.
4. Once paired, connect your device to one of the speakers via Bluetooth as described in the "Bluetooth Pairing" section. Both speakers will now play audio in stereo.

Selfie Function

The BoomPods Zero can act as a remote shutter for your smartphone camera:

1. Ensure your BoomPods Zero is connected to your smartphone via Bluetooth.
2. Open your phone's camera application.
3. Press the main button on the BoomPods Zero speaker to remotely trigger your phone's camera shutter and take a photo.



universally compatible

Image: Illustration of the selfie control function using the speaker.

MAINTENANCE

Cleaning

To clean your BoomPods Zero speaker, use a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the speaker's finish or internal components.

Water Resistance

The BoomPods Zero has an IPX6 waterproof rating, meaning it is protected against high-pressure water jets from any direction. While it is resistant to splashes and rain, it is not designed for submersion. Ensure the charging port cover is securely closed before exposing the speaker to water.



SELFIE CONTROL



Image: The BoomPods Zero speaker demonstrating its waterproof and drop-proof design.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to maintain its health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the provided USB-C cable or a wireless charging pad.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode. Turn Bluetooth off and on on your device. Move device closer to speaker (within 10 meters).

Problem	Possible Cause	Solution
No sound or low volume.	Volume on speaker or device is too low; speaker not connected.	Increase volume on both the speaker and your connected device. Verify Bluetooth connection.
Dual pairing not working.	Speakers already connected to other devices; incorrect pairing procedure.	Ensure both speakers are disconnected from other devices. Follow the dual pairing instructions carefully.

SPECIFICATIONS

Feature	Detail
Brand	BoomPods
Model Number	ZERO
Speaker Maximum Output Power	10 Watts
Connectivity Technology	Bluetooth, USB
Audio Output Mode	Stereo
Additional Features	Portable, Selfie Function, Dual Pairing
Control Method	Remote Control
Color	White
Battery Average Life	5 Hours (Playback)
Battery Charge Time	5 Hours
Waterproof Rating	IPX6
Bluetooth Range	10 Meters
Item Dimensions (D x W x H)	2.2"D x 4.3"W x 3.9"H
Item Weight	83 Grams
Power Source	Battery Powered (1 Lithium Ion battery included)

WARRANTY INFORMATION

The BoomPods Zero Bluetooth Speaker comes with a limited warranty. The warranty period is 1 month from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries, please contact BoomPods customer service. Refer to the product packaging or the official BoomPods website for the most current contact information.

You can visit the official BoomPods store on Amazon for more product information:[BoomPods Store](#)

