

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sauder](#) /

› [Sauder Select Storage Cabinet Instruction Manual](#)

Sauder 426125

Sauder Select Storage Cabinet Instruction Manual

Model: 426125

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Sauder Select Storage Cabinet. Designed for versatile storage in various rooms, this cabinet features adjustable shelves and a durable construction. Please read all instructions carefully before beginning assembly to ensure proper setup and safe use.





Image: The Sauder Select Storage Cabinet, showcasing its two-door design and Silver Sycamore finish.

SAFETY INFORMATION

- Always use caution when adjusting shelves to avoid injury.
- Follow assembly and mounting instructions carefully to prevent tipping.
- Keep heavy items away from the edges of shelves to maintain stability.
- Ensure the cabinet is placed on a level surface to prevent instability.
- Do not allow children to climb on or play with the cabinet.

PARTS LIST

Before assembly, verify that all components are present and undamaged. Refer to the included hardware pack for specific quantities.

Component	Description
-----------	-------------

Component	Description
Side Panels	Main vertical supports of the cabinet.
Top & Bottom Panels	Horizontal panels forming the top and base.
Adjustable Shelves	Four movable shelves for customizable storage.
Fixed Shelf	One full-width upper shelf for structural integrity.
Back Panel	Rear panel for stability and enclosure.
Doors	Two front doors with frame and panel detailing.
Hardware Pack	Includes cam locks, cam dowels, screws, hinges, handles, and shelf pins.

ASSEMBLY INSTRUCTIONS (SETUP)

Assembly typically requires two adults. Lay out all parts on a soft, clean surface to prevent scratching. Follow the numbered steps in your detailed assembly guide provided with the product. Below are general steps and key considerations:

Step 1: Attach Cam Dowels and Cam Screws

Insert cam dowels into pre-drilled holes on the edges of panels. Ensure they are fully seated. Screw cam screws into the corresponding panels. Do not overtighten.

Step 2: Connect Panels

Align panels with cam dowels and cam screws. Insert the cam dowels into the cam lock holes. Ensure the arrow on the cam lock points towards the edge of the board where the cam dowel is inserted.



Image: Interior view of the cabinet, demonstrating the adjustable shelves and ample storage space for various items like books, baskets, and blankets.

Step 3: Secure Cam Locks

Using a Phillips head screwdriver, turn the cam locks approximately 210 degrees clockwise to secure the panels together. The cam lock should firmly grip the cam dowel, creating a strong joint.

Step 4: Install Back Panel

Carefully attach the back panel using the provided small nails or screws. Ensure the cabinet frame is square before securing the back panel, as this adds significant stability.

Step 5: Attach Doors and Hardware

Mount the door hinges to the cabinet frame and then attach the doors. Adjust hinges as needed to ensure doors are level and close properly. Install the door handles.



Image: A detailed view of the cabinet doors, highlighting the frame and panel design and the black metal handles.

Step 6: Install Adjustable Shelves

Insert shelf pins into the desired holes on the side panels. Place the adjustable shelves onto the pins. The cabinet features four adjustable shelves and one full-width upper shelf.




Image: A close-up of the cabinet's interior, displaying various items neatly organized on the adjustable shelves, including decorative boxes and woven baskets.

16 1/8"

40,9 cm

29 5/8"

75,2 cm



Upper Portion
Behind Doors

28" (71,0 cm) W

15 5/8" (39,6 cm) D

11 1/8" (28,2 cm) H

Lower Portion
Behind Doors

28" (71,0 cm) W

15 5/8" (39,6 cm) D

53 1/8" (135,0 cm) H

Image: A technical diagram illustrating the overall dimensions of the cabinet, including height, width, and depth, along with internal compartment measurements.

OPERATING INSTRUCTIONS

Your Sauder Select Storage Cabinet is designed for straightforward use.

- **Opening/Closing Doors:** Gently pull the handles to open the doors. Push the doors firmly until the magnetic closures engage to ensure they remain shut.

- **Adjusting Shelves:** To adjust the height of the adjustable shelves, remove all items from the shelf. Lift the shelf off its pins. Remove the shelf pins and reinsert them into the desired set of holes. Carefully place the shelf back onto the pins, ensuring it is level and secure.
- **Weight Capacity:** Adhere to the recommended weight limits for each shelf to prevent damage or instability. The upper shelves have a limit of 25 lbs, and the bottom shelf has a limit of 50 lbs.

Maintenance

Proper care will extend the life of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent moisture damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and cam locks to ensure they remain tight. Retighten if necessary to maintain stability.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.

Troubleshooting

If you encounter issues with your cabinet, try the following solutions:

Problem	Possible Cause / Solution
Cabinet is wobbly or unstable.	<ul style="list-style-type: none"> • Ensure all cam locks and screws are fully tightened. • Verify the cabinet is on a level surface. Use shims if necessary. • Check if the back panel is properly installed and secured, as it provides structural rigidity.
Doors do not align or close properly.	<ul style="list-style-type: none"> • Adjust the door hinges. Most hinges have screws for vertical, horizontal, and depth adjustments. • Ensure the cabinet frame is square. If not, loosen connections slightly, square the frame, and retighten.
Shelves sag or are not level.	<ul style="list-style-type: none"> • Check that shelf pins are fully inserted into all four holes for the shelf. • Ensure the weight on the shelf does not exceed the recommended capacity. Redistribute heavy items.

Specifications

- **Brand:** Sauder
- **Model Number:** 426125
- **Color:** Silver Sycamore
- **Product Dimensions:** 16.34"D x 29.61"W x 71.1"H

- **Material:** Engineered Wood
- **Number of Shelves:** 4 adjustable, 1 fixed
- **Item Weight:** 79.2 Pounds
- **Assembly Required:** Yes

WARRANTY INFORMATION

Your Sauder Select Storage Cabinet is backed by a **5-year limited warranty**. This warranty protects your investment and ensures lasting peace of mind. For detailed terms and conditions, please refer to the warranty documentation included with your product or contact Sauder customer support.

CUSTOMER SUPPORT

For any questions, assistance with assembly, or to order replacement parts, please contact Sauder customer support:


- **Website:** sauder.com/service
- **Phone:** 800-523-3987
- A domestic call center is ready to assist you.



Image: A Sauder customer service representative wearing a headset, ready to provide assistance.

© 2024 Sauder Woodworking. All rights reserved.

Related Documents - 426125

 <p>Storage Cabinet HomePlus Collection Model 422427</p> <p>View instructions Print instructions Customer Service Feedback Report a defect Share this page Print this page</p>	<p>Sauder Storage Cabinet HomePlus Collection Model 422427 Assembly Guide</p> <p>Comprehensive assembly instructions for the Sauder Storage Cabinet, HomePlus Collection, Model 422427. Includes step-by-step guidance, parts identification, hardware details, safety warnings, and warranty information.</p>
 <p>User Manual of Product 1: Sauder Homeplus Base Cabinet, Dakota Oak Finish</p>	<p>Sauder Homeplus Base Cabinet 411591 Assembly Manual - Dakota Oak Finish</p> <p>Comprehensive user manual for the Sauder Homeplus Base Cabinet, Model 411591, in Dakota Oak Finish. Includes detailed assembly instructions, part and hardware identification, safety guidelines, and warranty information for proper setup and use.</p>
 <p>Storage Cabinet Harbor View Collection 416797</p> <p>View instructions Print instructions Customer Service Feedback Report a defect Share this page Print this page</p>	<p>Sauder Storage Cabinet Assembly Instructions</p> <p>Step-by-step assembly guide for the Sauder Harbor View Collection Storage Cabinet (Model 416797), including parts identification, hardware list, safety information, and warranty details.</p>
 <p>Storage Cabinet Model 419188</p> <p>View instructions Print instructions Customer Service Feedback Report a defect Share this page Print this page</p>	<p>Sauder Storage Cabinet Model 419188 Assembly Instructions</p> <p>Comprehensive assembly instructions for the Sauder Storage Cabinet, Model 419188. This guide details part identification, hardware, and step-by-step assembly procedures, including safety information and warranty details.</p>
 <p>Night Stand Model 423434</p> <p>View instructions Print instructions Customer Service Feedback Report a defect Share this page Print this page</p>	<p>Sauder Night Stand Model 423434 Assembly Instructions</p> <p>Detailed assembly instructions for the Sauder Night Stand, Model 423434, including part identification, hardware details, step-by-step guidance, safety information, and warranty details.</p>
 <p>Computer Desk with Hutch Harbor View Collection 415109</p> <p>View instructions Print instructions Customer Service Feedback Report a defect Share this page Print this page</p>	<p>Sauder Computer Desk with Hutch - Assembly Instructions</p> <p>Assembly instructions for the Sauder Harbor View Collection Computer Desk with Hutch (Model 415109). This guide provides detailed steps, part identification, and hardware details for building the furniture.</p>