

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Swatch](#) /
- › [Swatch Sistem51 SO30B400 Automatic Watch Instruction Manual](#)

## Swatch SO30B400

# Swatch Sistem51 SO30B400 Automatic Watch Instruction Manual

Model: SO30B400

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &  
Support](#)

## INTRODUCTION

This instruction manual provides essential information for the proper use and care of your Swatch Sistem51 SO30B400 automatic watch. The Sistem51 is a unique automatic mechanical watch, powered by the motion of your wrist, eliminating the need for a battery.

The Swatch Sistem51 SO30B400 is part of the SISTEM 51 collection, featuring a 51 mm round case made from biosourced materials. Its design includes a distinctive green seconds hand, a nod to the 1983 collection.



*Image: Front view of the Swatch Sistem51 SO30B400 automatic watch, showcasing its black dial, white hour markers, and green-tipped seconds hand.*

## SETUP

### Setting the Time and Date

1. **Unscrew the Crown:** The watch features a push/pull crown. Gently pull the crown outwards to the first or second position.
2. **Setting the Date (if applicable):** If your model includes a date function, pull the crown to the first position and rotate it either clockwise or counter-clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
3. **Setting the Time:** Pull the crown to the second position. Rotate the crown to move the hour and minute hands to the correct time. Ensure you account for AM/PM if setting the date.

4. **Push in the Crown:** Once the time and date are set, push the crown back into its original position to secure it and ensure water resistance.

## Winding the Watch

The Sistem51 is an automatic watch, meaning it is powered by the natural motion of your wrist. It does not require manual winding in the traditional sense, nor does it use a battery. To ensure it runs continuously:

- Wear the watch regularly. Consistent wrist movement will keep the mainspring wound.
- If the watch stops due to lack of wear, gently shake it side-to-side for about 30 seconds to initiate movement. Then, set the time as described above.

## OPERATING YOUR SWATCH SISTEM51 WATCH

---

### Timekeeping

Your Swatch Sistem51 watch displays time using hour, minute, and seconds hands. The unique design of the Sistem51 allows for a view of the intricate mechanical movement through the transparent case back.



*Image: Rear view of the Swatch Sistem51 SO30B400, revealing the automatic mechanical movement through its transparent case back.*

## **Water Resistance**

The Swatch Sistem51 SO30B400 is water-resistant up to 100 feet (30 meters). This means it is suitable for splashes, rain, and brief immersion in water, but it is not recommended for swimming, diving, or prolonged water activities. Ensure the crown is fully pushed in before any contact with water.

## MAINTENANCE AND CARE

### Cleaning Your Watch

- Wipe the watch regularly with a soft, dry cloth to remove dust and smudges.
- For more thorough cleaning, especially the biosourced strap, use a damp cloth with mild soap and water. Ensure the watch is completely dry before wearing.
- Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish and materials.

### Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight and extreme temperatures. While the Sistem51 is an automatic watch, prolonged periods of inactivity may cause it to stop. Simply shake it gently to restart.

### Battery Information Clarification

The Swatch Sistem51 is an **automatic mechanical watch** and does not require a battery for its primary timekeeping function. It is powered by the movement of your wrist. Any mention of "batteries required" or "battery exchange" in general product listings typically refers to quartz watches. For your Sistem51, no battery replacement is needed.

## TROUBLESHOOTING

- **Watch Not Running:** As an automatic watch, it needs motion to operate. If the watch has stopped, gently shake it for about 30 seconds to wind the mainspring. If it still doesn't run, ensure the crown is fully pushed in.
- **Time Inaccuracy:** Automatic watches can have slight variations in timekeeping. If the watch is consistently running too fast or too slow, it may require adjustment by a professional watchmaker.
- **Water Inside the Watch:** If you notice condensation or water inside the watch, immediately take it to an authorized Swatch service center. Do not attempt to open the watch yourself.

## SPECIFICATIONS

<b>Model Name</b>	Sistem51 Biosourced Unisex Watch
<b>Model Number</b>	SO30B400
<b>Movement Type</b>	Automatic Mechanical (SISTEM 51)
<b>Case Material</b>	Bioceramic
<b>Case Size</b>	51 mm (round)
<b>Water Resistance</b>	100 feet (30 meters)
<b>Strap Material</b>	Biosourced material
<b>Department</b>	Unisex-Adult
<b>Approximate Weight</b>	1.55 ounces

## WARRANTY & SUPPORT

### Manufacturer Warranty




Your Swatch Sistem51 SO30B400 watch comes with a **2-year international warranty** from the manufacturer. This warranty covers manufacturing defects under normal use. Please refer to the warranty card included with your purchase for full terms and conditions.

### Service and Repairs

For any service, repairs, or warranty claims, please contact an authorized Swatch retail location or service center. While the Sistem51 is an automatic watch and does not require traditional battery changes, Swatch offers various services for their products. For specific service inquiries, please consult your local Swatch store or the official Swatch website.

© 2023 Swatch. All rights reserved. Information in this manual is subject to change without notice.

### Related Documents - SO30B400

	<p><a href="#">Swatch Watch User Manual: Functions, Settings, and Operation Guide</a></p> <p>Comprehensive user manual for Swatch watches, detailing time setting, date/day adjustment, Loomi function, Pop features, Touch Alarm, Touch Game, and Scuba elapsed time functions. Learn how to operate and maintain your Swatch watch.</p>
	<p><a href="#">Swatch Chronograph User Manual</a></p> <p>A comprehensive user manual for Swatch chronograph watches, detailing display functions, time setting, date setting, split time, timing modes, add functions, tachymeter usage, and readjustment procedures for various models.</p>
	<p><a href="#">Swatch Watch Battery Replacement Guide and Comprehensive Battery List</a></p> <p>Detailed instructions for changing batteries in Swatch watches, including Standard, Skin, Touch, Fun Scuba, and Chrono models. Features a complete list of Swatch watch collections with their corresponding Renata battery designations, dimensions (mm), and voltage.</p>




### [Swatch Watch Battery Replacement Guide and Specifications](#)

Comprehensive guide to replacing batteries in Swatch watches, including detailed instructions for various models like Chrono, Irony, Skin, and a complete list of battery types and specifications.



### [Swatch i Flik Flak - Formularz Zgłoszenia Naprawy i Instrukcja Pakowania](#)

Kompletny formularz zgłoszenia naprawy oraz szczegółowe instrukcje pakowania zegarków i biżuterii Swatch i Flik Flak dla klientów w Polsce.



### [Swatch MoonSwatch Strap Sizing Guide: Measure Your Wrist](#)

Learn how to accurately measure your wrist for the perfect Swatch MoonSwatch strap fit using this printable ruler and sizing guide from Swatch.