

USARMT EDEN TVOEM1900

Eden TV Remote Control TVOEM1900 User Manual

Model: EDEN TVOEM1900 | Brand: USARMT

1. INTRODUCTION

This user manual provides essential information for the proper setup, operation, and maintenance of your Eden TV Remote Control, model TVOEM1900. This remote is specifically designed for use with EDEN Prison TVs and comes pre-programmed for immediate use.

2. PRODUCT FEATURES

- Designed for EDEN Prison TVs.
- Clear Transparent casing.
- Pre-programmed: No setup or programming required.
- Ergonomic design for comfortable handling.
- Supports one device (Television).

3. SETUP

3.1. Battery Installation

The Eden TV Remote Control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: Batteries are not included with the remote control. Please dispose of used batteries responsibly.

3.2. Initial Use

This remote control is pre-programmed for EDEN Prison TVs. No additional setup or programming is required. Once batteries are installed, the remote is ready for immediate use with compatible TV models. Compatible TV Models: TVOEM1900 (This list may not be complete).

4. OPERATING INSTRUCTIONS

The Eden TV Remote Control provides standard functions for controlling your television. Ensure a clear line of sight between the remote control and the TV's infrared receiver.



Button	Function
Colored Buttons (Red, Green, Yellow, Blue)	Functions vary depending on the TV model or on-screen prompts.
ASPECT	Adjusts screen aspect ratio.
TTX	Teletext function.
INDEX	Teletext index.
I/II	Audio language selection.
MIX	Mix teletext with TV picture.
SUBPAGE	Selects teletext subpages.
HOLD	Holds teletext page.
SUBTITLE	Activates or deactivates subtitles.
CANCEL	Cancels teletext or other functions.
REVEAL	Reveals hidden teletext information.
SIZE	Changes teletext display size.
FAV	Accesses favorite channels.

5. MAINTENANCE

5.1. Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface and internal components.

5.2. Storage

When not in use for extended periods, store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for more than a few weeks to prevent leakage.





Figure 5.1: Back view of the Eden TVOEM1900 remote control. This image highlights the transparent back casing and the battery compartment cover.

6. TROUBLESHOOTING

- **Remote not responding:**
 - Ensure batteries are installed correctly with the correct polarity (+/-).
 - Replace old or depleted batteries with new ones.
 - Check for any obstructions between the remote control and the TV's infrared sensor.
 - Ensure you are within the effective range of the TV's sensor.
- **Specific buttons not working:**
 - This remote is pre-programmed for EDEN Prison TVs. Ensure your TV is a compatible model.
 - Clean the remote control surface, especially around the non-working buttons, to remove any dirt or debris.

7. SPECIFICATIONS

Brand	USARMT
Model Number	EDEN TVOEM1900
Product Dimensions	6 x 2 x 0.5 inches
Color	Transparent
Max Number of Supported Devices	1 (Television)
Compatible Devices	Television (Specifically EDEN Prison TVs)
Special Feature	Ergonomic
Manufacturer	USARMT

8. WARRANTY AND SUPPORT

8.1. Return Policy

This product is covered by a 30-Day Hassle-Free Return Policy. Please refer to your purchase documentation for specific terms and conditions regarding returns.

8.2. Customer Support

For any questions or assistance, customer questions are responded to within 1 business day. Please contact the seller or manufacturer through the platform where the product was purchased.