

[Manuals.plus](#) /

> [WorWoder](#) /

> WorWoder W-915 Wireless Over-Ear Headphones User Manual

WorWoder W-915

WorWoder W-915 Wireless Over-Ear Headphones User Manual

Model: W-915 | Brand: WorWoder

INTRODUCTION

Thank you for choosing the WorWoder W-915 Wireless Over-Ear Headphones. This manual provides detailed instructions on how to set up, operate, and maintain your headphones to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact customer support.

- WorWoder W-915 Wireless Over-Ear Headphones
- USB Type-C Charging Cable
- 3.5mm Audio Cable
- Storage Pouch
- User Manual (this document)



Image: The WorWoder W-915 headphones, the main product.

PRODUCT OVERVIEW AND CONTROLS

EASY AND WIRE FREE



Image: Detailed diagram showing the location and function of buttons and ports on the WorWoder W-915 headphones.

Control Layout:

- 1. Power Button / Play/Pause / Call Button:** Used to power the headphones on/off, play/pause music, and answer/end calls.
- 2. Volume +:** Increases volume.
- 3. Volume -:** Decreases volume.
- 4. EQ Mode Key:** Cycles through different equalizer sound modes.
- 5. Bluetooth Status and Charging Status Indicator Light:** Displays connection status and charging status.
- 6. Type-C Charging Socket:** Port for charging the headphones.
- 7. Audio Jack:** 3.5mm port for wired connection.
- 8. Microphone:** Built-in microphone for calls.

SETUP

1. Charging the Headphones

Before first use, fully charge the headphones. Connect the supplied USB Type-C charging cable to the charging socket on the headphones and the other end to a USB power source (e.g., computer USB port, wall adapter). The indicator light will show charging status.

- A full charge provides up to 80 hours of playtime.
- A quick 10-minute charge provides approximately 5 hours of playtime.



The illustration features a pair of black over-ear headphones with a leather-like texture on the earcups. The background is a cityscape at dusk. Overlaid on the headphones are several key features:

- Bluetooth 5.3** logo in the top left corner.
- A large **80** in the top center, representing 80 hours of playtime.
- A circular icon with **24 HOURS** and **X3.3** next to it, indicating a 3.3x faster charge rate.
- A white pill-shaped box with the text **80-Hours playtime** in the center.
- At the bottom left, the text **1215 SONGS** is displayed.
- At the bottom right, a white pill-shaped box contains the text **10 Mins Charging = 5 Hours playtime**.

Image: Illustration highlighting the 80-hour battery life and the quick charge feature of the WorWoder W-915 headphones.

2. Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the indicator light flashes and you hear a power-on prompt.
- **Power Off:** Press and hold the Power button for approximately 3 seconds until the indicator light turns off and you hear a power-off prompt.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button for about 5 seconds until the indicator light flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "WorWoder W-915" from the list of devices.
5. Once connected, the indicator light will turn solid blue or flash slowly, and you will hear a "connected" prompt.
6. The headphones will automatically attempt to reconnect to the last paired device when powered on.

4. Wired Connection (Aux Mode)

You can use the headphones in wired mode even if the battery is depleted. Connect one end of the supplied 3.5mm audio cable to the audio jack on the headphones and the other end to the 3.5mm audio output of your device.

- In wired mode, the headphone's power and Bluetooth functions are disabled.
- Volume and playback control will be managed directly from your connected device.



SPACE SAVING DESIGN

Foldable design with a carrying pouch provide maximum portability



Image: Depiction of the WorWoder W-915 headphones being used in both wired mode (with cable) and wireless mode (via

Bluetooth).

OPERATING INSTRUCTIONS

Music Playback and Call Management (Wireless Mode)

| Function | Action |
|------------------|----------------------------------|
| Play/Pause Music | Short press the Power button. |
| Volume Up | Short press the Volume + button. |
| Volume Down | Short press the Volume - button. |
| Next Track | Long press the Volume + button. |
| Previous Track | Long press the Volume - button. |
| Answer/End Call | Short press the Power button. |
| Reject Call | Long press the Power button. |

EQ Modes

The WorWoder W-915 headphones feature multiple equalizer (EQ) modes to optimize your listening experience for different types of audio. Press the EQ Mode Key to cycle through the available modes:

- **Pop Mode:** Enhanced vocals and bright sound.
- **Bass Mode:** Deep and powerful bass for rhythmic music.
- **Vocal Mode:** Clear and crisp voice reproduction, ideal for podcasts or audiobooks.



Image: Visual representation of the three distinct EQ music modes (Pop, Bass, Vocal) available on the WorWoder W-915 headphones.

Voice Assistant Activation

To activate your device's voice assistant (e.g., Siri, Google Assistant), double-press the Power button. The microphone on the headphones will be used for voice input.

MAINTENANCE

Cleaning

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Keep the charging port and audio jack free of dust and debris.

Storage

When not in use, store the headphones in the provided storage pouch to protect them from dust and scratches. The headphones feature a foldable design for compact storage and portability.

WIRED

 okay Google, play music



WIRELESS


 Hey Siri, call Jason



Image: The WorWoder W-915 headphones demonstrating their foldable design and how they fit into the included carrying pouch for space-saving storage.

Battery Care

- Avoid exposing the battery to extreme temperatures.
- Charge the headphones regularly, even if not used frequently, to maintain battery health.

TROUBLESHOOTING

| Problem | Possible Solution |
|-----------------------------|---|
| Headphones do not power on. | Ensure the headphones are charged. Connect to a power source and try again. |

| Problem | Possible Solution |
|--|---|
| Cannot pair with Bluetooth device. | <ul style="list-style-type: none"> ◦ Ensure headphones are in pairing mode (flashing red and blue light). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to the device. ◦ Forget "WorWoder W-915" from your device's Bluetooth list and try pairing again. ◦ Restart both headphones and your device. |
| No sound or low volume. | <ul style="list-style-type: none"> ◦ Increase volume on both headphones and your connected device. ◦ Ensure headphones are properly connected (Bluetooth or wired). ◦ If using wired mode, ensure the 3.5mm cable is fully inserted. |
| Sound distortion or intermittent connection. | <ul style="list-style-type: none"> ◦ Move closer to your Bluetooth device, avoiding obstacles. ◦ Avoid strong electromagnetic interference. ◦ Disconnect and reconnect the Bluetooth connection. |
| Microphone not working. | <ul style="list-style-type: none"> ◦ Ensure headphones are connected via Bluetooth (microphone does not work in wired mode). ◦ Check privacy settings on your device to ensure microphone access is granted to the headphones. |

SPECIFICATIONS

| Feature | Detail |
|--------------------|--|
| Model | W-915 |
| Connectivity | Bluetooth 5.0, 3.5mm Audio Jack (Wired) |
| Bluetooth Range | Up to 10 meters (33 feet) (typical) |
| Driver Diameter | 40mm |
| Frequency Response | 20 Hz - 20,000 Hz |
| Battery Life | Up to 80 hours (music/call time) |
| Charging Time | Approx. 10 minutes for 5 hours playtime (quick charge) |
| Microphone | Built-in |
| Material | Memory protein earcup, Stainless steel slider |

| Feature | Detail |
|---------|--------------|
| Weight | Approx. 360g |

WARRANTY AND SUPPORT

WorWoder provides a lifetime warranty for the W-915 headphones. If you encounter any issues or have questions regarding your product, please contact WorWoder customer service directly. We aim to respond to all inquiries within 24 hours.

For customer support, please refer to the contact information provided on the product packaging or the official WorWoder website.