

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Philips Audio](#) /

› [Philips Audio BT2003 Portable Bluetooth Speaker User Manual](#)

Philips Audio BT2003

Philips Audio BT2003 Portable Bluetooth Speaker User Manual

Model: BT2003

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Philips Audio BT2003 Portable Bluetooth Speaker. Please read these instructions carefully before using the device and retain them for future reference.

WHAT'S IN THE BOX

- Philips Audio BT2003 Portable Bluetooth Speaker
- USB cable for PC charging
- Quick install guide
- 3.5mm stereo line-in cable

PRODUCT FEATURES

The Philips Audio BT2003 speaker is designed for portability and versatile audio playback.


- **Compact and Lightweight Design:** Weighing only 140 grams, it is easy to carry.
- **Carrying Strap:** For enhanced portability, allowing attachment to bags or wrists.
- **3W Sound Output:** Delivers clear audio for personal listening.
- **Multi-Connectivity:** Supports Bluetooth 5.0, USB Type-C, Audio-in (AUX), and MicroSD card playback.
- **Built-in Microphone:** Enables hands-free phone calls.
- **Rapid Charging:** USB Type-C port allows for quick battery replenishment.
- **FM Radio:** Integrated FM tuner for radio listening.



Bluetooth 5.0




Built-in Mic



USB Type-C
charging



Audio-in



Carrying strap

Image: Overview of Philips BT2003 speaker features including Bluetooth, built-in mic, USB-C charging, audio-in, and carrying strap.

SETUP

1. Charging the Speaker

1. Connect the supplied USB Type-C cable to the charging port on the speaker.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a PC USB port.
3. The charging indicator light will illuminate during charging and turn off when fully charged.
4. A full charge takes approximately 45 minutes and provides up to 3 hours of playback time.



Audio-in

Image: Side view of the speaker showing the USB Type-C charging port, AUX input, microphone, and MicroSD card slot.

2. Powering On/Off

- To power on, press and hold the power button until the indicator light illuminates.
- To power off, press and hold the power button again until the indicator light turns off.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on. The Bluetooth indicator light will flash, indicating it's in pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Philips BT2003" from the list.
4. Once paired, the Bluetooth indicator light will stop flashing and remain solid.
5. You can now play audio wirelessly from your device.



Bluetooth wireless streaming

Image: The Philips BT2003 speaker used outdoors, highlighting its Bluetooth wireless streaming capability.

Hands-Free Calling

- When connected via Bluetooth, the built-in microphone allows you to answer phone calls directly through the speaker.
- Press the call button (often indicated by a phone icon) to answer or end a call.

Audio-in (AUX) Connection

- Connect one end of the 3.5mm stereo line-in cable to the AUX port on the speaker.
- Connect the other end to the audio output jack of your external audio device.
- The speaker will automatically switch to AUX mode.

MicroSD Card Playback

- Insert a MicroSD card with audio files into the designated slot on the speaker.
- The speaker will automatically detect the card and begin playing music.

FM Radio

- Switch the speaker to FM radio mode (refer to the quick install guide for specific button functions).
- Use the control buttons to scan for and select radio stations.

Controls

The speaker features several control buttons:

- **Power Button:** Press and hold to turn on/off.
- **Play/Pause Button:** Press to play or pause music.
- **Volume Up/Next Track:** Short press for next track, long press for volume up.
- **Volume Down/Previous Track:** Short press for previous track, long press for volume down.
- **Mode Button:** To switch between Bluetooth, AUX, MicroSD, and FM modes.
- **Call Button:** To answer or end phone calls.

MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or moisture.
- Store the speaker in a cool, dry place when not in use.

TROUBLESHOOTING

Problem	Solution
Speaker does not turn on.	Ensure the battery is charged. Connect to a power source using the USB Type-C cable.
Cannot pair via Bluetooth.	<ul style="list-style-type: none">• Ensure the speaker is in pairing mode (flashing Bluetooth indicator).• Make sure Bluetooth is enabled on your device.• Move the speaker closer to your device.• Forget "Philips BT2003" from your device's Bluetooth list and try pairing again.
No sound or low volume.	<ul style="list-style-type: none">• Adjust the volume on both the speaker and your connected device.• Ensure the correct input mode (Bluetooth, AUX, MicroSD) is selected.• Check if the audio cable is securely connected (for AUX mode).
Poor FM radio reception.	Reposition the speaker to improve signal reception.

SPECIFICATIONS

Feature	Detail
Model Name	BT2003GY/94
Speaker Type	Woofer
Special Feature	Portable

Feature	Detail
Compatible Devices	Laptop, Smartphone, Tablet
Product Dimensions	72D x 41W x 41H Millimeters
Item Weight	140 Grams
Control Method	Touch
Wireless Communication Technology	Bluetooth
Hardware Interface	USB Type C
Audio Input Compatible	Auxiliary
Speaker Amplification Type	Active
Speaker Maximum Output Power	3 Watts
Battery Average Life	3 Hours
Charging Time	45 Minutes
Battery Cell Composition	Lithium Polymer

WARRANTY AND SUPPORT

This Philips Audio BT2003 speaker comes with a 1-year warranty from the date of purchase. For warranty claims, technical support, or service inquiries, please refer to the contact information provided in the quick install guide or visit the official Philips Audio support website.

Please retain your proof of purchase for warranty validation.

PRODUCT VIDEOS

Philips Audio BT2003 Speaker Demo

Your browser does not support the video tag.

Video: A demonstration of the Philips Audio BT2003 speaker, showcasing its features and portability. This video highlights the compact design, lightweight nature, carrying strap, 3W sound output, USB Type-C quick charging, built-in microphone for calls, Bluetooth 5.0 connectivity, and MicroSD card slot for easy music playback.

Philips Audio BT2003 Unboxing

Your browser does not support the video tag.

Video: An unboxing of the Philips Audio BT2003 portable Bluetooth speaker. The video shows the contents of the box, including the speaker, USB Type-C charging cable, and user manual. It also details the various ports and buttons on the speaker, such as the AUX input, microphone, USB-C charging port, and TF card slot.

Philips Audio BT2003 Overview

Your browser does not support the video tag.

Video: A quick overview of the Philips Audio BT2003 portable Bluetooth speaker. This video highlights the speaker's camouflage design, portability with a carrying strap, Bluetooth 5.0 connectivity, 3W sound output, built-in microphone for phone calls, and battery life of up to 3 hours on a single charge via USB Type-C.

© 2023 Philips Audio. All rights reserved.
For more information, visit [Philips Audio Store](#)