

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [UBISHENG](#) /

› [UBISHENG Digital TV Converter Box with Antenna \(Model 753326608008\) - Instruction Manual](#)

UBISHENG 753326608008

UBISHENG Digital TV Converter Box with Antenna - Instruction Manual

Model: 753326608008

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your UBISHENG Digital TV Converter Box with Antenna. Please read this manual thoroughly before using the device to ensure optimal performance and safety. This converter box allows older analog televisions to receive digital broadcast signals (ATSC) and offers features such as PVR recording, playback, and timer settings.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- Digital TV Converter Box
- Digital TV Antenna with Amplifier
- Remote Control
- Power Adapter
- AV Cable (RCA)
- User Manual (this document)



Image 2.1: Included items: Digital TV Converter Box, Antenna, Remote Control, AV Cable, and Power Adapter.

3. SETUP INSTRUCTIONS

Follow these steps to connect your Digital TV Converter Box to your television and begin receiving digital channels.

3.1. Antenna Connection

1. Connect the coaxial cable from the digital TV antenna to the 'ANT IN' port on the back of the converter box.
2. Connect the antenna amplifier's USB cable to the USB port on the converter box or a separate USB power adapter.
3. Position the antenna for optimal signal reception. Consider placing it near a window or high on a wall.



Image 3.1: Digital TV antenna with amplifier and coaxial connector.



Image 3.2: Various placement options for the digital TV antenna to optimize signal reception.

3.2. Connecting to Your Television

The converter box supports both HDMI and AV (RCA) connections to your television.

HDMI Connection (Recommended for HD TVs):

1. Connect an HDMI cable (not included) from the 'HDMI OUT' port on the converter box to an available HDMI input on your television.
2. Select the corresponding HDMI input on your TV using your TV's remote control.

AV (RCA) Connection (For older TVs):

1. Connect the supplied AV cable to the 'CVBS', 'AR', and 'AL' ports on the converter box (Yellow for Video, Red for Right Audio, White for Left Audio).
2. Connect the other end of the AV cable to the corresponding 'Video In', 'Audio R', and 'Audio L' ports on your television.

3. Select the corresponding AV input on your TV using your TV's remote control.




Image 3.3: Connection options for the converter box to a television using AV (RCA) or HDMI cables.



Image 3.4: Full connection diagram illustrating how to connect the digital antenna, amplifier, converter box, and television.

3.3. Power Connection

1. Connect the power adapter to the 'DC IN' port on the converter box.
2. Plug the power adapter into a standard electrical outlet.
3. Turn on the converter box using the power button on the front panel or the remote control.

3.4. Initial Channel Scan

After all connections are made and the devices are powered on, you will need to perform an initial channel scan.

1. On your TV remote, select the correct input source (HDMI or AV) where the converter box is connected.
2. On the converter box remote, press the 'MENU' button.
3. Navigate to the 'Channel Search' or 'Auto Scan' option in the menu.
4. Select 'Start Scan' to begin searching for available digital channels. This process may take several minutes.
5. Once the scan is complete, the converter box will save the found channels, and you can begin watching TV.

4. OPERATING INSTRUCTIONS

This section covers the basic functions and features of your UBISHENG Digital TV Converter Box.

4.1. Channel Navigation

- Use the 'CH+' and 'CH-' buttons on the remote control to change channels sequentially.
- Enter a channel number directly using the numeric keypad on the remote control.
- Press the 'OK' button to view the channel list and select a channel.



Image 4.1: Example of multiple digital channels available through the converter box.

4.2. PVR Recording and Playback

The converter box supports Personal Video Recorder (PVR) functionality, allowing you to record live TV programs to a USB storage device (not included).

1. **Connect USB Device:** Insert a USB flash drive or external hard drive (formatted to FAT32 or NTFS) into the USB port on the front of the converter box.
2. **Instant Recording:** While watching a program, press the 'REC' button on the remote control to start recording. Press 'STOP' to end the recording.
3. **Scheduled Recording (Timer):** Access the 'Timer Setting' or 'PVR Schedule' menu to set up recordings for future programs. You can specify channel, start time, end time, and frequency (once, daily, weekly).
4. **Playback:** Press the 'USB' or 'Media' button on the remote control to access the media player. Navigate to the 'PVR' folder to find and play your recorded programs.



Image 4.2: Visual representation of the PVR recording feature.



Image 4.3: Icons indicating media playback capabilities, including recorded content.

4.3. Electronic Program Guide (EPG)

Press the 'EPG' button on the remote control to view the Electronic Program Guide, which displays upcoming program information for available channels.

4.4. Media Player

In addition to PVR playback, the converter box can play various media files (video, audio, photos) stored on a connected USB device. Access this feature via the 'USB' or 'Media' button on the remote.

5. MAINTENANCE

Proper care and maintenance will extend the lifespan of your converter box.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the converter box. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the converter box has adequate ventilation. Do not block the ventilation slots.
- **Storage:** When not in use for extended periods, disconnect the power adapter and store the device in a cool, dry place.
- **Power:** Always disconnect the power before cleaning or moving the device.

6. TROUBLESHOOTING

If you encounter issues with your converter box, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No picture or sound	Incorrect TV input selected; Loose cable connections; Power not connected.	Ensure TV is on correct input (HDMI/AV). Check all cable connections. Verify power adapter is plugged in.
No channels found during scan	Antenna not connected; Poor antenna signal; Antenna amplifier not powered.	Ensure antenna is connected. Adjust antenna position. Check if amplifier USB is powered. Rescan channels.
Remote control not working	Batteries depleted; Obstruction between remote and box; Remote not pointed at IR sensor.	Replace batteries. Remove any obstructions. Point remote directly at the converter box's IR sensor.
PVR recording issues	USB device not connected; Insufficient storage space; USB device not formatted correctly.	Ensure USB device is properly inserted. Check available storage. Format USB device to FAT32 or NTFS.

Problem	Possible Cause	Solution
Poor picture quality / Signal pixelation	Weak antenna signal; Interference.	Adjust antenna position for better reception. Try rescanning channels. Minimize interference from other electronic devices.

7. SPECIFICATIONS

Technical details for the UBISHENG Digital TV Converter Box.

- **Model Number:** 753326608008
- **Connectivity Technology:** HDMI
- **Controller Type:** IR Remote Control
- **Special Features:** PVR Recording & Playback, Digital Signal Conversion
- **Compatible Devices:** Television
- **Connector Types:** HDMI, 3.5mm Jack (for AV output)
- **Audio Output Mode:** Stereo, Surround
- **Surround Sound Channel Configuration:** 5.1
- **Video Encoding:** H.264, H.265/HEVC
- **Color:** Black
- **Item Weight:** 1.06 pounds
- **Package Dimensions:** 12.48 x 4.45 x 2.13 inches



Image 7.1: The converter box supports various resolutions up to 1080P.

8. WARRANTY INFORMATION

UBISHENG products are covered by a limited warranty from the date of purchase. This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, please refer to the documentation provided with your product or contact customer support.

9. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue, please contact UBISHENG customer

support. Our team is available to help you with any inquiries regarding your Digital TV Converter Box.

Contact Information:

Website: www.ubisheng.com (Placeholder - please refer to actual product documentation for official website)

Email: support@ubisheng.com (Placeholder - please refer to actual product documentation for official email)