

Playmobil 70612

Playmobil Paddle Boat Rental (Model 70612)

Official Instruction Manual

1. INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your Playmobil Paddle Boat Rental set, Model 70612. This set allows for imaginative play centered around a water-based activity, featuring paddle boats and a juice bar.

The Playmobil Paddle Boat Rental set includes one adult figure, two child figures, two paddle boats, a juice bar, pineapples, watermelons, glasses, and other accessories to enhance the play experience.



Image 1.1: Playmobil Paddle Boat Rental Set (Model 70612) packaging.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD. This product contains a small ball and small parts. It is not suitable for children under 3 years of age. Adult supervision is recommended during play to ensure safety and proper use of all components.

Please keep all packaging materials, including plastic bags and protective films, away from children to prevent suffocation hazards. Dispose of packaging responsibly.

3. SETUP AND ASSEMBLY

Detailed assembly instructions are provided within the product packaging. Please refer to the illustrated guide included in the box for step-by-step instructions on how to assemble the paddle boats, juice bar, and other accessories.

- Carefully unpack all components from the box.
- Identify all figures and accessories.
- Follow the numbered steps in the included instruction booklet to connect the various parts of the juice bar and paddle boats.
- Ensure all connections are secure before play.

If any parts are missing or damaged, please refer to the 'Warranty and Support' section for assistance.



Image 3.1: Assembled Playmobil Paddle Boat Rental set ready for play.

4. OPERATING INSTRUCTIONS

The Playmobil Paddle Boat Rental set is designed for interactive play, simulating a day at a water park or beach. The paddle boats are designed to float and can be manually propelled by the figures.

4.1 Using the Paddle Boats

- Place a child figure into each paddle boat.
- The boats can be floated in water (e.g., a bathtub or small pool) for realistic play.
- Figures can be positioned to 'pedal' the boats, encouraging imaginative movement.

4.2 Using the Juice Bar

- Position the adult figure behind the juice bar counter.
- Use the included accessories like pineapples, watermelons, and glasses to simulate preparing and serving refreshments.
- Figures can 'order' and 'enjoy' drinks at the bar or on the dock.

The set encourages storytelling and role-playing, allowing children to create various scenarios around the water activities.

5. MAINTENANCE

Proper care will ensure the longevity of your Playmobil set.

5.1 Cleaning

- To clean the plastic components, wipe them with a damp cloth.

- For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water.
- Ensure all parts are completely dry before storing to prevent mold or mildew, especially if used in water.
- Do not use abrasive cleaners or harsh chemicals, as these can damage the plastic.

5.2 Storage

- Store the set in a clean, dry place away from direct sunlight and extreme temperatures.
- Keep small parts in a designated container to prevent loss.

6. TROUBLESHOOTING

This section addresses common issues you might encounter.

6.1 Missing or Damaged Parts

- If you find any parts missing or damaged upon opening the box, please contact Playmobil customer support immediately. Refer to the 'Warranty and Support' section for contact details.

6.2 Assembly Difficulties

- If you encounter difficulties during assembly, re-examine the included instruction booklet carefully.
- Ensure all pieces are oriented correctly and that you are using the correct parts for each step.
- Do not force parts together, as this may cause damage.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	11.18 x 7.36 x 3.66 inches
Item Weight	9.9 ounces
Model Number	70612
Manufacturer Recommended Age	4 - 10 years
Manufacturer	PLAYMOBIL

8. WARRANTY AND SUPPORT

Playmobil products are manufactured to high-quality standards. For any questions, concerns, or assistance with your Paddle Boat Rental set (Model 70612), please contact Playmobil customer support.

Please visit the official Playmobil website for the most current contact information and support resources:

www.playmobil.com

When contacting support, please have your product model number (70612) and purchase details available.

