

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Micro Touch](#) /

› [Micro Touch Titanium Trim User Manual](#)

Micro Touch MTTTTR

Micro Touch Titanium Trim User Manual

Model: MTTTTR

INTRODUCTION


The Micro Touch Titanium Trim is an innovative at-home hair cutting tool and body groomer designed for ease of use. It allows you to shape and trim your hair and body hair with precision and convenience, eliminating the need for traditional clippers or scissors. Its comb-like design and extendable arm make it versatile for various grooming needs.

SAFETY INFORMATION

For external use only. Use only as directed. This product is hypoallergenic. Use with care on sensitive skin. Keep out of reach of children.

PACKAGE CONTENTS

- 1 x Micro Touch Titanium Trim Device
- 5 x Comb Attachments (various lengths)
- 2 x AA Batteries (included)



The Micro Touch Titanium Trim device and its various comb attachments.

SETUP

Battery Installation

The Micro Touch Titanium Trim requires 2 AA batteries for operation, which are included in the package. To install, locate the battery compartment on the device, open it, and insert the batteries, ensuring correct polarity (+/-). Close the compartment securely.

Attaching and Detaching Comb Attachments

The device comes with five comb attachments to achieve different hair lengths. To attach a comb, align it with the trimmer head and slide it firmly until it clicks into place. To detach, gently slide the comb off the trimmer head.

OPERATING INSTRUCTIONS

General Hair Trimming

The Micro Touch Titanium Trim is designed to be used like a comb. For general hair trimming, select the desired comb attachment to achieve your preferred length. Turn on the device and gently comb through your hair, allowing the blades to cut evenly. Move the trimmer slowly and steadily against the direction of hair growth for best results.



Easily trim hair on hard-to-reach areas like the back of your neck.

Precision Trimming and Shaping

For precision trimming and shaping of areas such as beards, sideburns, or necklines, remove all comb attachments. Use the bare blade to define clean lines and edges. Hold the trimmer at an angle that allows for precise control.


Remove combs and use as a trimmer and shaper for beards, sideburns and more.



Remove comb attachments for precision trimming and shaping of beards and sideburns.

Using the Extendable Arm

The trimmer features a built-in extendable arm that can extend up to an additional 2 inches. This feature is particularly useful for reaching difficult areas such as the back of your head, shoulders, and back. To extend the arm, gently pull the handle outwards until it locks into position. To retract, press the release button and push the handle back in.



The Micro Touch Titanium Trim features a built-in extension handle for extended reach.



The extendable arm makes it convenient for grooming body hair, including the back.

Official Product Videos

Microtouch Titanium TRIM: Your at home hair cut solution!

This video provides a comprehensive overview of how to use the Micro Touch Titanium Trim for various at-home hair cutting and grooming solutions.

Microtouch Titanium TRIM - How to: TRIM Hair Cutting Tool

Watch this video for detailed instructions and tips on how to effectively trim hair using your Micro Touch Titanium Trim tool.

MAINTENANCE

Cleaning the Trimmer

To ensure optimal performance and hygiene, clean your Micro Touch Titanium Trim after each use. Remove any hair clippings from the blades and comb attachments. A small cleaning brush (not included) can be used to clear debris. The blades can be detached for a more thorough cleaning if necessary.

Battery Replacement

When the motor of your trimmer begins to slow down or the cutting performance diminishes, it indicates that the batteries are low. Replace the two AA batteries with new ones, ensuring they are inserted with the correct polarity.

TROUBLESHOOTING


Problem	Possible Cause	Solution
Trimmer not turning on or weak power.	Low or incorrectly installed batteries.	Check battery installation and replace with fresh AA batteries if needed. Ensure the power switch is fully engaged.
Ineffective cutting or pulling hair.	Blades are clogged with hair or comb attachment is not secure.	Ensure blades are clean and free of hair buildup. If using a comb attachment, ensure it is securely attached. For thick hair, make slower passes or consider removing the comb for closer trimming.

SPECIFICATIONS

Feature	Detail
Product Dimensions	10 x 1.75 x 5.25 inches
Item Model Number	MTTTTR
Batteries	2 AA batteries required (included)
UPC	754502045648
Manufacturer	AmazonUs/IDFIT
Recommended Uses	Beard, Back, Neck, Body
Color	Black
Hair Type	All
Item Weight	6.4 ounces

WARRANTY AND SUPPORT

For product support, warranty inquiries, or to purchase replacement parts, please contact the manufacturer, Micro Touch, directly. Refer to the product packaging or the official Micro Touch website for the most current contact information and warranty details.

	<p><u>Lifelong Soft Touch Rechargeable Multi-Trimmer for Women - User Manual and Warranty</u></p> <p>Comprehensive user manual and warranty details for the Lifelong Soft Touch Rechargeable Multi-Trimmer for Women. Includes product features, operating instructions, cleaning, maintenance, and warranty terms and conditions.</p>
	<p><u>Micro Touch Titanium Head Shaver User Manual</u></p> <p>Comprehensive user manual for the Micro Touch Titanium Head Shaver, covering cleaning, shaving, charging, travel lock, replacement heads, and important safety instructions for optimal performance and maintenance.</p>
	<p><u>Micro-Mark Powered Nibbler #81556 Operating Instructions</u></p> <p>Comprehensive operating instructions for the Micro-Mark Powered Nibbler #81556, detailing safety precautions, usage guidelines for various cutting types (straight, radius, freehand), material compatibility, maintenance, and replacement parts.</p>
	<p><u>Rowenta Easy Touch Epilator User Manual and Safety Guide</u></p> <p>Comprehensive user manual and safety instructions for the Rowenta Easy Touch epilator (models EP111xxx, EP112xxx). Learn about safe usage, maintenance, and environmental disposal.</p>
	<p><u>Vera Hair Co Ordering Guide and Install Instructions</u></p> <p>Comprehensive guide for Vera Hair Co extensions, detailing weft weights and installation steps for single and double row applications.</p>
	<p><u>Wahl Clipper Corporation Important Safeguards and Instructions</u></p> <p>This document provides essential safety precautions and usage instructions for Wahl Clipper Corporation appliances, covering both rechargeable and non-rechargeable battery units. It includes warnings regarding electrical shock, burns, and proper battery handling, along with FCC compliance information.</p>