

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Tognana](#) /

> [Tognana Stovetop Coffee/Espresso Maker Moka Pot Instruction Manual](#)

Tognana V443006MGRW

Tognana Stovetop Coffee/Espresso Maker Moka Pot Instruction Manual

Model: V443006MGRW

Brand: Tognana

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Tognana Stovetop Coffee/Espresso Maker Moka Pot. Designed with a natural stone and wood style, this 6-cup Moka pot is crafted from durable aluminum. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The Tognana 6-Cup Stovetop Coffee/Espresso Maker Moka Pot in gray, featuring a wooden handle and knob, is shown on a kitchen counter alongside white coffee cups and chocolate-drizzled pastries. A wooden cutting board and a metal canister are also

visible in the background.

COMPONENTS

Your Tognana Moka Pot consists of three main parts:

1. **Bottom Chamber:** Holds the water. Features a safety release valve.
2. **Filter Basket:** Sits inside the bottom chamber and holds the ground coffee.
3. **Top Chamber (Carafe):** Collects the brewed coffee. Includes a spout, lid, and a stay-cool ergonomic handle.

SETUP AND FIRST USE

Before using your Moka Pot for the first time, disassemble all parts and wash them thoroughly with warm water. Do not use soap, as it can leave residue that affects coffee flavor. Allow all parts to air dry completely.

Assembly:

1. Unscrew the top chamber from the bottom chamber.
2. Remove the filter basket from the bottom chamber.

OPERATING INSTRUCTIONS

Follow these steps to brew rich, heavy-bodied coffee with your Tognana Moka Pot:

1. **Fill with Water:** Fill the bottom chamber with cold water up to the level of the safety valve. Do not overfill.
2. **Add Coffee Grounds:** Place the filter basket into the bottom chamber. Fill the filter basket with your favorite finely ground coffee. Gently shake the basket to evenly settle the grounds, but do not tamp them down.
3. **Assemble the Pot:** Carefully screw the top chamber onto the bottom chamber, ensuring a tight seal.
4. **Place on Stovetop:** Place the assembled Moka Pot on a stovetop burner set to medium heat. Ensure the flame or heating element does not extend beyond the base of the pot to protect the handle.
5. **Brew Coffee:** As the water in the bottom chamber heats and approaches a boil, pressure will build, pushing a stream of coffee slowly and methodically through the filter basket and up into the top chamber. You will hear a gurgling sound as the coffee brews.
6. **Serve:** Once the top chamber is full of brewed coffee and the gurgling sound subsides, remove the Moka Pot from the heat. Pour and enjoy your freshly brewed coffee.

MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and optimal performance of your Moka Pot:

- **After Each Use:** Allow the Moka Pot to cool completely before disassembling. Discard used coffee grounds.
- **Rinse Thoroughly:** Rinse all parts (bottom chamber, filter basket, top chamber) with warm water.
- **Avoid Soap:** Do not use soap or harsh detergents, as they can damage the aluminum and leave a soapy residue that affects the coffee's taste.
- **Air Dry:** Let all components air-dry completely in an upright position to prevent oxidation and water spots.
- **Not Dishwasher Safe:** This Moka Pot is not dishwasher safe. Hand washing is required.

TROUBLESHOOTING

If you encounter issues with your Moka Pot, consider the following:

- **Coffee Not Brewing:** Ensure the water level is below the safety valve and the pot is tightly screwed together. Check that the heat source is adequate.
- **Weak Coffee:** The coffee grounds might be too coarse, or not enough coffee was used. Ensure the filter basket is full but not overly tamped.
- **Bitter Coffee:** The heat might be too high, causing the coffee to brew too quickly or burn. Reduce the heat to medium.
- **Leaking:** Ensure the top and bottom chambers are securely screwed together and the rubber gasket is properly seated and not damaged.

SPECIFICATIONS

Brand:	Tognana
Model Name:	Wood and Stone Stovetop Coffee/Esspresso Maker Moka Pot
Item Model Number:	V443006MGRW
Coffee Maker Type:	Moka Pot
Capacity:	6-Cup
Color:	Gray
Material:	Durable Aluminum
Special Feature:	Gas Stovetop Compatible (Note: Not suitable for induction)
Operation Mode:	Manual
Product Dimensions:	4.13 x 7.09 x 7.68 inches
Item Weight:	15.5 ounces
Dishwasher Safe:	No

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Tognana customer service directly. Contact details can typically be found on the manufacturer's official website or on the product's retail page.

INSTRUCTIONAL VIDEOS

No official seller instructional videos are available for this product at this time. Please refer to the written instructions provided in this manual for guidance.