

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [De'Longhi](#) /

› [De'Longhi Primadonna Soul ECAM610.75.MB Fully Automatic Coffee Machine Instruction Manual](#)

De'Longhi ECAM610.75.MB

De'Longhi Primadonna Soul ECAM610.75.MB Fully Automatic Coffee Machine Instruction Manual

Comprehensive guide for setup, operation, and maintenance of your De'Longhi Primadonna Soul ECAM610.75.MB espresso and cappuccino maker.

[Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#)

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your De'Longhi Primadonna Soul ECAM610.75.MB fully automatic bean-to-cup coffee machine. Please read all instructions carefully before operating the appliance and retain this manual for future reference.



Image: The De'Longhi PrimaDonna Soul ECAM610.75.MB fully automatic coffee machine, featuring a touchscreen display and integrated milk carafe.

1. SETUP AND FIRST USE

1.1 Unpacking and Component Identification

Carefully remove all packaging materials. Ensure all components are present and undamaged. Refer to the diagram below for component identification.



Image: Included accessories for the coffee machine, such as the LatteCrema milk carafe, coffee pot, descaler, water filter, measuring scoop, and cleaning brush.

1.2 Initial Preparation

- Water Tank:** Fill the water tank with fresh, clean water.
- Bean Hopper:** Fill the bean hopper with whole coffee beans.
- Power Connection:** Plug the appliance into a suitable power outlet.
- First Rinse Cycle:** Follow the on-screen instructions for the initial rinse cycle to prepare the internal circuits.

1.3 Water Filter Installation

Install the water filter as instructed on the display to ensure optimal water quality and reduce descaling frequency.

2. OPERATING INSTRUCTIONS

2.1 Touchscreen Interface

The machine features a 4.3" full-color TFT touch screen for intuitive interaction. Beverages are displayed on the homepage, adapting to your usage for quick access to frequently prepared drinks.



Image: A hand selecting a coffee beverage from the touchscreen display of the De'Longhi Primadonna Soul coffee machine.

2.2 Preparing Coffee Beverages

- Select Beverage:** From the main screen, select your desired coffee beverage (e.g., Espresso, Cappuccino, Long Black). The machine offers 21 one-touch recipes.
- Bean Adapt Technology:** The machine's Bean Adapt Technology automatically adjusts grinding, dose, and temperature parameters based on the specific coffee beans used. This ensures optimal extraction.
- Customization:** You can customize strength, volume, and temperature for most beverages via the touchscreen.



Image: The touchscreen display showing "Machine Settings" with options to "Adjust mill" and "Coffee temperature," illustrating the Bean Adapt Technology.

2.3 Preparing Milk-Based Beverages (LatteCrema System)

The LatteCrema System ensures perfectly textured milk for your preferred milk-based drinks.

- 1. Fill Milk Carafe:** Fill the LatteCrema milk carafe with fresh milk. Ensure the carafe is securely attached to the machine.
- 2. Select Milk Beverage:** Choose a milk-based beverage from the display (e.g., Cappuccino, Latte Macchiato).
- 3. Dispensing:** The machine will automatically prepare and dispense the coffee and frothed milk.



Image: A hand pouring milk into the LatteCrema System carafe, which is attached to the De'Longhi Primadonna Soul coffee machine.





Image: The De'Longhi Primadonna Soul dispensing coffee and perfectly frothed milk into a glass, creating a layered beverage.

2.4 Coffee Link App Connectivity

Connect your machine to the De'Longhi Coffee Link app via Wi-Fi for infinite personalization options, remote control, and access to additional recipes and advice.



Image: A smartphone displaying the De'Longhi Coffee Link app interface, with the coffee machine visible in the background, demonstrating remote control capabilities.

2.5 User Profiles

The machine supports multiple user profiles, allowing each user to save their preferred beverage settings and customizations.



Image: The touchscreen display showing a list of user profiles, indicating the machine's personalization features.

3. MAINTENANCE AND CLEANING

Regular cleaning and maintenance are crucial for the longevity and optimal performance of your coffee machine.

3.1 Daily Cleaning

- **Drip Tray and Grounds Container:** Empty and clean the drip tray and coffee grounds container daily. These components are dismountable and dishwasher safe.
- **Milk Carafe:** After each use, perform the automatic cleaning cycle for the LatteCrema System. The milk carafe components are also dishwasher safe.
- **Coffee Spout:** Clean the coffee spout regularly with a damp cloth.



Image: Exploded view of the De'Longhi Primadonna Soul showing its removable components, including the drip tray, coffee grounds container, and water tank, for easy cleaning.

3.2 Descaling

The machine will prompt you when descaling is required. Use only De'Longhi descaling solution and follow the on-screen instructions precisely. Regular descaling prevents limescale buildup and ensures efficient operation.

3.3 Water Filter Replacement

Replace the water filter approximately every two months, or as indicated by the machine, to maintain water quality.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your De'Longhi Primadonna Soul coffee machine.

| Problem | Possible Cause | Solution |
|--|---|--|
| Coffee is not hot enough. | Cups are cold; machine not preheated; low coffee temperature setting. | Preheat cups; allow machine to complete preheating cycle; increase coffee temperature setting via the menu. |
| No coffee is dispensed. | Water tank empty; coffee beans empty; brewing unit blocked. | Fill water tank; fill bean hopper; clean the brewing unit as per maintenance instructions. |
| Milk does not froth correctly. | Milk carafe dirty; milk type unsuitable; milk too warm. | Clean the LatteCrema System thoroughly; use cold, fresh, semi-skimmed or whole milk; ensure milk is chilled. |
| "Descaling required" message appears frequently. | High water hardness; water filter not installed or expired. | Perform descaling cycle; install or replace water filter; adjust water hardness setting in the machine menu. |

For further assistance, please consult the full user manual or contact De'Longhi customer support.

5. TECHNICAL SPECIFICATIONS

Brand: De'Longhi

Model Number: ECAM610.75.MB

Color: Silver and Black

Product Dimensions (D x W x H): 26.2 x 48.5 x 39 cm

Item Weight: 13 Kilograms

Water Tank Capacity: 2.2 Liters

Power / Wattage: 1450 watts

Voltage: 220 Volts

Material: Stainless Steel

Coffee Maker Type: Fully Automatic Bean-to-Cup Espresso Machine

Special Features: Bean Adapt Technology, LatteCrema System, 4.3" TFT Touch Display, Wi-Fi Connectivity (Coffee Link App), Water Filter, 21 One-Touch Recipes, User Profiles.

Specific Uses: Cappuccino, Espresso, and other coffee beverages.

6. WARRANTY INFORMATION

Your De'Longhi Primadonna Soul ECAM610.75.MB coffee machine is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. Additionally, De'Longhi offers a 100-day money-back guarantee. For details on this offer, please consult the official De'Longhi website or your retailer.



Image: De'Longhi 100 Day Money Back Guarantee emblem.

7. CUSTOMER SUPPORT

For technical support, service, or spare parts, please visit the official De'Longhi website or contact your local authorized service center. Keep your model number (ECAM610.75.MB) and purchase date ready when contacting support.

De'Longhi Official Website: www.delonghi.com

© 2024 De'Longhi. All rights reserved. This manual is for informational purposes only.