

[Manuals.plus](#) /

> [Wappa Baby](#) /

> Child Safety Door Knob Cover Instruction Manual

## Wappa Baby KnobCovW4

# Wappa Baby Child Safety Door Knob Cover Instruction Manual

Model: KnobCovW4

## PRODUCT OVERVIEW

The Wappa Baby Child Safety Door Knob Cover is designed to prevent young children from opening doors and accessing unsupervised areas. This product features a dual-lock system for enhanced security and is compatible with standard round doorknobs. Made from durable, BPA-free plastic, these covers are reusable and require no tools for installation. Each pack contains 4 white door knob covers.

## SETUP AND INSTALLATION

Follow these steps to properly install your Wappa Baby Child Safety Door Knob Covers:

1. Separate the two halves of the door knob cover.
2. Place one half around the doorknob, ensuring the screw thread is facing you.
3. Align the second half and attach it to the first, snapping them together around the doorknob.
4. Screw the top piece until it is tight enough to prevent a child from unscrewing it.

## Easy to Install



Attach halves together ensuring  
crew thread is facing you



Screw top piece until it's tight enough  
so your child cannot unscrew it

## Easy to Remove



Unscrew top piece



Press side buttons and separate halves

Figure 1: Installation steps for the Wappa Baby Door Knob Cover. The cover consists of two halves that snap together and are then secured by screwing a top piece.

### OPERATING INSTRUCTIONS

The Wappa Baby Door Knob Cover is designed for easy adult operation while remaining secure against children.

- To open the door, insert your fingers into the holes on the cover and grasp the doorknob.
- Turn the doorknob as usual to open the door. The cover will spin freely, preventing small hands from gaining purchase on the knob itself.



**Easy for Adults**



**Has Holes That Let Adults  
Open Doors As Usual**

Figure 2: Adult operation of the Wappa Baby Door Knob Cover. The design allows adults to easily access and turn the doorknob through the integrated finger holes.

## Compatible with most Door Knobs




Figure 3: A child attempting to open a door with the Wappa Baby Door Knob Cover, illustrating how the cover prevents small hands from gripping the doorknob.

### MAINTENANCE

To maintain the cleanliness and functionality of your door knob covers:

- The covers can be hand washed with mild soap and water.
- They are also dishwasher safe for convenient cleaning.
- Ensure the covers are completely dry before re-installing them on doorknobs.

# New & Improved

## REUSABLE

Due to our proprietary locking system, you can remove and install the product multiple times.



## Other Brands

Poor design and low quality materials means covers get stuck, and easily broken. There's no value in one-time use covers.

Figure 4: The internal design of the Wappa Baby Door Knob Cover, emphasizing its durable construction and reusability for multiple installations.

## TROUBLESHOOTING

If you encounter any issues with your Wappa Baby Child Safety Door Knob Covers, consider the following:

- **Cover spins freely but doorknob still turns:** Ensure the two halves are securely snapped together and the top piece is screwed on tightly. The cover should not allow direct grip on the doorknob.
- **Difficulty for adults to open:** Make sure your fingers are fully inserted into the access holes to get a firm grip on the doorknob. If the cover is too tight, slightly loosen the top screw piece, but ensure it remains child-proof.
- **Cover comes off easily:** This indicates the cover is not installed correctly or is not tightened sufficiently. Re-install the cover, ensuring both halves are fully engaged and the top piece is screwed on firmly.
- **Compatibility issues:** These covers are designed for standard round doorknobs. They may not fit all non-standard or lever-style handles. Refer to the product dimensions for verification.



Figure 5: Product dimensions and examples of compatible doorknob types. The covers are designed for standard round doorknobs.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	2.5 x 1.9 x 2.2 inches
Item Model Number	KnobCovW4
Material Type	Plastic (BPA-free)
Care Instructions	Hand Wash, Dishwasher Safe
Number Of Items	4
Item Weight	6.1 ounces

## WARRANTY AND SUPPORT

---

For any questions, concerns, or support regarding your Wappa Baby Child Safety Door Knob Covers, please contact Wappa Baby customer service through the retailer's platform or visit the official Wappa Baby store online. While specific warranty details are not provided in this manual, Wappa Baby is committed to customer satisfaction.

You can visit the Wappa Baby Store for more information:[Wappa Baby Store](#)

## SAFETY INFORMATION

---

This product is intended as a child safety device. Always supervise children, even when safety devices are in place. Regularly inspect the door knob covers for any signs of wear or damage. Discontinue use if the product becomes damaged or ineffective. Keep packaging materials away from children.

