

Delkin Devices Fat Gecko Dual Suction Mount & Tablet/iPad Bracket

Delkin Devices Fat Gecko Dual Suction Camera Mount and Tablet/iPad Bracket User Manual

Models: DDMOUNT-Suction (Fat Gecko Dual Suction Mount), DDMNT-UTAB1 (Fat Gecko Tablet and iPad Bracket)

1. INTRODUCTION

This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your Delkin Devices Fat Gecko Dual Suction Camera Mount and Fat Gecko Tablet and iPad Bracket. Please read this manual thoroughly before use to ensure safe and effective operation of the product.

The Delkin Devices Fat Gecko Dual Suction Camera Mount is designed to securely attach cameras to smooth, non-porous surfaces using two industrial-grade suction cups. It features a double knuckle design and an extension tube for versatile positioning. The Fat Gecko Tablet and iPad Bracket is an accessory designed to hold tablets and iPads between 7 and 10.5 inches, allowing them to be mounted to any standard 1/4"-20 photography accessory, including the Fat Gecko mounts.

2. PACKAGE CONTENTS

- 1 x Delkin Devices Fat Gecko Dual Suction Camera Mount (DDMOUNT-Suction)
- 1 x Delkin Devices Fat Gecko Tablet and iPad Bracket (DDMNT-UTAB1)

Please inspect all components upon receipt. If any items are missing or damaged, contact Delkin Devices customer support.

3. SAFETY INFORMATION

- Ensure the mounting surface is clean, smooth, and non-porous before attaching the suction cups.
- Always test the suction strength by gently pulling on the mount before attaching any valuable equipment.
- Do not exceed the maximum recommended weight capacity of 8 pounds (3.6 kg) for the camera mount.

- Regularly check the suction cups for secure attachment, especially during prolonged use or in changing environmental conditions.
- Avoid mounting on surfaces that are excessively hot or cold, as this may affect suction performance.
- When used in moving vehicles, consider using a safety tether for your camera or tablet as an additional precaution.
- Do not obstruct the driver's view or interfere with vehicle controls when mounting in a car.

4. SETUP AND ASSEMBLY

4.1 Attaching the Fat Gecko Dual Suction Camera Mount

1. **Prepare the Surface:** Clean the desired mounting surface thoroughly to remove any dust, dirt, or moisture. The surface must be smooth and non-porous.
2. **Position the Mount:** Place the two suction cups of the Fat Gecko mount onto the clean surface.
3. **Engage Suction:** Press down firmly on each suction cup while simultaneously flipping the gray levers down until they lock into place. You should hear a click and see the suction cups flatten against the surface.
4. **Verify Security:** Gently pull on the mount to ensure both suction cups are securely attached.



Image 1: The Delkin Devices Fat Gecko Dual Suction Camera Mount. This image shows the dual suction cups and the adjustable arm with a 1/4"-20 screw for camera attachment.



Image 2: A close-up view of the Fat Gecko suction cups with their locking levers. The levers are shown in the engaged position, indicating a secure attachment.

4.2 Attaching the Fat Gecko Tablet and iPad Bracket

1. The Tablet and iPad Bracket features a standard 1/4"-20 female thread on its back.
2. Align the 1/4"-20 screw on the Fat Gecko Dual Suction Mount with the female thread on the back of the Tablet Bracket.
3. Rotate the bracket clockwise onto the screw until it is finger-tight and securely attached. Do not overtighten.



Image 3: The rear view of the Delkin Devices Tablet and iPad Bracket, highlighting the central 1/4"-20 female thread for mounting to compatible accessories.

5. OPERATING INSTRUCTIONS

5.1 Mounting a Camera

1. Ensure the Fat Gecko Dual Suction Mount is securely attached to your desired surface.
2. Locate the 1/4"-20 screw at the top of the mount's adjustable arm.
3. Align the camera's tripod socket with this screw.
4. Rotate the camera clockwise onto the screw until it is finger-tight.
5. Adjust the camera angle using the double knuckle joints and extension tube. Loosen the adjustment knobs, position the camera, then tighten the knobs firmly to lock the position.

5.2 Mounting a Tablet/iPad with the Bracket

1. Ensure the Fat Gecko Tablet and iPad Bracket is securely attached to the Fat Gecko Dual Suction Mount.
2. Gently pull apart the retractable arms of the bracket to create an opening for your tablet or iPad.
3. Insert your tablet or iPad into the bracket, ensuring it sits firmly within the custom-molded corners. The retractable arms will secure the device.
4. Verify that the tablet is held securely and that all buttons and ports remain accessible.
5. Adjust the tablet angle using the double knuckle joints on the Fat Gecko mount. Loosen the adjustment knobs, position the tablet, then tighten the knobs firmly to lock the position.



Image 4: The Delkin Devices Tablet and iPad Bracket shown in an extended position, demonstrating its retractable arms designed to accommodate various tablet sizes.

5.3 Removing the Mount from a Surface

1. First, remove your camera or tablet from the mount.
2. Flip the gray levers on each suction cup upwards to release the vacuum seal.
3. Gently lift the mount from the surface. Do not force it, as this may damage the suction cups or the surface.

6. MAINTENANCE

- **Cleaning:** Clean the suction cups and mounting surfaces with a damp cloth and mild soap if necessary. Ensure they are completely dry before re-attaching. Do not use abrasive cleaners.
- **Storage:** Store the mount in a clean, dry place away from direct sunlight and extreme temperatures. Avoid storing with the suction cups pressed against uneven surfaces to prevent deformation.
- **Inspection:** Periodically inspect the mount for any signs of wear, damage, or loose components. Ensure all knobs and joints function smoothly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Mount does not adhere securely.	Surface is dirty, porous, or uneven. Suction cups are dirty or damaged. Levers not fully engaged.	Clean surface and suction cups. Ensure surface is smooth and non-porous. Fully engage both levers. Inspect suction cups for damage.
Camera/Tablet angle shifts after adjustment.	Adjustment knobs not tightened sufficiently. Equipment weight exceeds capacity.	Ensure all adjustment knobs are firmly tightened. Verify equipment weight is within the 8 lb (3.6 kg) limit.
Tablet does not fit in the bracket.	Tablet size is outside the bracket's range.	The bracket supports tablets/iPads between 7 and 10.5 inches. Ensure your device falls within this range.

8. SPECIFICATIONS

- **Product Name:** Delkin Devices Fat Gecko Dual Suction Camera Mount & Tablet and iPad Bracket
- **Model Numbers:** DDMOUNT-Suction (Mount), DDMNT-UTAB1 (Bracket)
- **Mounting Type:** Dual Suction Cup
- **Material:** Steel frame (mount), Durable plastic (bracket)
- **Camera Mount Thread:** Standard 1/4"-20
- **Tablet Bracket Compatibility:** Tablets and iPads 7 to 10.5 inches
- **Weight Capacity (Mount):** Up to 8 lbs (3.6 kg)
- **Adjustability:** 360-degree tilt, 360-degree turn, 360-degree rotation (mount)
- **Color:** Black, Grey

9. WARRANTY AND SUPPORT

Delkin Devices products are designed for durability and performance. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Delkin Devices website. For technical support, troubleshooting assistance, or replacement parts, please contact Delkin Devices customer service through their official channels.

Delkin Devices Official Website: www.delkindevices.com