Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Link2Home /
- > Link2Home Outdoor WiFi Pan & Tilt Security Camera User Manual

Link2Home LTHODRCAMPT

Link2Home Outdoor WiFi Pan & Tilt Security Camera User Manual

Model: LTHODRCAMPT

1. Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Link2Home Outdoor WiFi Pan & Tilt Security Camera. Please read this manual thoroughly before using the product to ensure correct setup and optimal performance. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The Link2Home Outdoor WiFi Pan & Tilt Security Camera is a weatherproof surveillance device designed for home security. It offers 1080p HD video, night vision, two-way audio, and smart detection features, all controllable via a mobile application.

Key Features:

- Weatherproof Design: Suitable for outdoor use in various conditions.
- Pan & Tilt Functionality: Manually adjustable 355° pan and 10°-75° tilt for wide area coverage.
- Full HD 1080p Video: Clear and detailed video streaming.
- Night Vision: Infrared LEDs provide clear visibility up to 15 meters in low-light conditions.
- Two-Way Audio: Built-in microphone and speaker for real-time communication.
- Motion & Sound Detection: Sends instant activity alerts to your device.
- Voice Control: Compatible with Amazon Alexa and Google Assistant.
- Local Storage: Supports internal storage for event recording.

Package Contents:

- 1x Link2Home Outdoor WiFi Pan & Tilt Camera
- Mounting Bracket
- Power Adapter

- Mounting Screws and Wall Plugs
- User Manual



Figure 2.1: Front view of the Link2Home Outdoor WiFi Pan & Tilt Security Camera.



WiFi Outdoor Weatherproof Camera with Pan & Tilt

A wide-angle view for connected surveillance.

- Pan and tilt: Tilt your camera from -10° to 75° and pan through 355°.
- Weatherproof and reliable in moisture, heat, or wind.
- Features an operating temperature from -20°C to 50°C.
- Mains powered device plugs into a standard UK outlet.
- Full HD video is ultra-clear for a detailed view.
- Local device storage.*
- (C) Night vision lets you monitor day or night.
- Mear and respond in real time with two-way audio.

*Event recording requires no additional purchase and is included in the product and app free of charge with your Link2Home device.







Figure 2.2: The camera mounted outdoors, highlighting its weatherproof design and pan & tilt capabilities.

3. SETUP GUIDE

Follow these steps to install and configure your camera.

3.1. Physical Installation

- 1. **Choose a Location:** Select an outdoor location that provides the desired viewing angle and is within range of your 2.4GHz Wi-Fi network. Ensure the location allows for easy access to a power outlet.
- 2. **Mount the Bracket:** Use the provided screws and wall plugs to securely attach the mounting bracket to a wooden or masonry surface.
- 3. Affix the Camera: Attach the camera to the mounted bracket. Ensure it is firmly secured.
- 4. **Connect Power:** Plug the power adapter into the camera and then into a standard mains power outlet. The camera requires continuous power for 24/7 operation.



Figure 3.1: All included components for installation.

Easy Installation & Fast Setup An outdoor WiFi camera that can be placed anywhere, over your front door, garage, driveway, or another area. Secure the included mount. The mount can be fixed to wood or masonry using the screws provided. Affix the camera to the mount. Plug into mains electricity to ensure it never runs out of power, for security 24/7. The outdoor camera can be moved through 355(degrees) through the app and the wide 110(degrees) viewing angle lens gives you the best view of your property and desired viewing area. Install the app and set up your personalised monitoring plan.

Figure 3.2: Visual guide for easy installation and setup.

3.2. App Installation & Wi-Fi Connection

- 1. **Download the App:** Search for "Link2Home Pro" in the Apple App Store (for iOS devices) or Google Play Store (for Android devices) and install it.
- 2. Create an Account: Open the app and follow the on-screen instructions to create a new user account.
- 3. **Add Device:** In the app, select the option to add a new device. Follow the in-app prompts to connect your camera to your home Wi-Fi network.
- 4. **Wi-Fi Requirement:** The camera supports **2.4GHz Wi-Fi networks only**. Ensure your mobile device is connected to a 2.4GHz network during the setup process. 5GHz Wi-Fi networks are not compatible.

4. OPERATION

Learn how to use the various features of your Link2Home camera.

4.1. Live View & Pan/Tilt Control

Once connected, open the Link2Home Pro app and select your camera to view the live feed. Use the on-screen controls to manually pan the camera horizontally up to 355 degrees and tilt vertically from 10 to 75 degrees to adjust your viewing area.

4.2. Two-Way Audio

The camera features a built-in microphone and speaker. In the live view interface of the app, tap the microphone icon to speak through the camera and the speaker icon to listen to audio from the camera's location.

4.3. Night Vision

The camera automatically switches to night vision mode in low-light conditions, providing clear black and white video up to 15 meters using infrared LEDs.

4.4. Motion and Sound Detection

Enable motion and sound detection in the app settings. When activity is detected, the camera will send an instant alert to your mobile device and capture an image or video clip, which can be reviewed in the app's message center.

4.5. Voice Control Integration

The camera is compatible with Amazon Alexa and Google Assistant. To enable voice control, link your Link2Home Pro account within the Alexa or Google Home app. You can then use voice commands to access your camera feed on compatible smart displays (e.g., Alexa Echo Show, Google Screen devices).

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your camera.

- Cleaning: Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Firmware Updates:** Periodically check the Link2Home Pro app for available firmware updates to ensure your camera has the latest features and security enhancements.
- Power Supply: Ensure the power cable and adapter are free from damage and properly connected.

6. TROUBLESHOOTING

If you encounter issues with your camera, refer to the following common problems and solutions.

· Camera not connecting to Wi-Fi:

- Ensure your Wi-Fi network is 2.4GHz. The camera does not support 5GHz networks.
- Check that your Wi-Fi password is entered correctly.
- Move the camera closer to your Wi-Fi router to improve signal strength.
- · Restart your router and the camera.

• Slow or delayed pan/tilt response:

- Ensure a stable Wi-Fi connection. Poor signal can affect control responsiveness.
- If the camera reaches its maximum tilt position and is slow to return, this may be a characteristic of the mechanism. Allow a moment for the motor to reset before attempting further adjustments.

No video feed or poor image quality:

- · Check your internet connection speed.
- Clean the camera lens if it appears dirty or smudged.
- Ensure the camera has adequate power.

· Motion/Sound alerts not received:

- Verify that motion and sound detection are enabled in the app settings.
- · Check your phone's notification settings to ensure the Link2Home Pro app is allowed to send

notifications.

• Ensure the camera is online and connected to Wi-Fi.

• Internal storage fills up quickly:

- The camera uses internal storage for recordings. This storage is designed to loop, overwriting the oldest footage when full. There is no slot for an external, upgradable SIM card.
- Adjust motion detection sensitivity or recording schedules in the app to manage storage usage.

7. SPECIFICATIONS

Feature	Specification
Brand	Link2Home
Model Name	Smart Pan & Tilt Outdoor Camera
Item Model Number	LTHODRCAMPT
Connectivity Technology	Wireless (Wi-Fi)
Wireless Communication Technology	Wi-Fi (2.4GHz only)
Effective Video Resolution	1080 Pixels (1080p)
Special Feature	Night Vision
Pan Range	355 degrees
Tilt Range	10 to 75 degrees
Power Source	Corded Electric
Voltage	12 Volts
Power	5.5 Watts
Item Dimensions (L x W x H)	19.2 x 9 x 9 cm
Product Weight	440 grams
Upper Rated Temperature	50 Degrees Celsius
Mounting Type	Surface Mount
Compatible Devices	Tablet, Smartphone (iOS, Android)
Controller Type	Amazon Alexa, Google Assistant
Batteries Included	No
Batteries Required	No

8. SAFETY INFORMATION

- Do not attempt to disassemble or modify the camera.
- Use only the provided power adapter.

- Ensure the camera is securely mounted to prevent accidental falls.
- Keep the camera away from extreme temperatures, direct sunlight, and excessive moisture.
- This product is designed for outdoor use but should not be submerged in water.

9. SUPPORT

For further assistance or technical support, please refer to the Link2Home Pro app's help section or visit the official Link2Home website. Specific warranty information is not provided in this manual; please consult your purchase documentation or the manufacturer's website for details.

Related Documents - LTHODRCAMPT



Link2Home Pro Outdoor Camera Pan and Tilt User Manual

Comprehensive user manual for the Link2Home Pro Outdoor Camera (Model 8004H), covering setup, features, installation, and troubleshooting. Includes instructions for connecting, registering, and using the camera's functions.



Link2Home Zigbee Outdoor Neon Strip RGB White and Music Sync Quick Guide

Quick guide for the Link2Home Zigbee Outdoor Neon Strip (L2H-5MODRSTRIP), covering setup, app connection, features like RGB White and Music Sync, troubleshooting, and technical specifications.



<u>Link2Home Wireless Remote Control Outlet Indoor 2+5 Instruction Manual</u>

Instruction manual for the Link2Home Wireless Remote Control Outlet Indoor 2+5, covering setup, operation, and warranty information.



Link2Home Wireless Remote Control Outlets - Instruction Manual EM-1001

Instruction manual for Link2Home Wireless Remote Control Outlets (EM-1001), detailing setup, operation, safety guidelines, specifications, battery replacement, grounding, and warranty information.



<u>Link2Home Wireless Remote Control Outlet Outdoor 1+1 Instruction Manual</u>

Comprehensive instruction manual for the Link2Home EM-OR650B Wireless Remote Control Outlet Outdoor 1+1. Covers specifications, setup, operation, battery replacement, warranty information, and safety warnings.



Link2Home L2H-BellWired Smart Video Doorbell Datasheet

Discover the Link2Home L2H-BellWired, a smart video doorbell offering 1080P HD video, 2-way audio, motion detection, and compatibility with Alexa and Google Assistant. Learn about its features, technical specifications, and dimensions.