Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

W-KING D9-1

W-KING D9-1 Portable Bluetooth Speaker Instruction Manual

Model: D9-1

Brand: W-KING

Product Overview

The W-KING D9-1 is a powerful and durable portable Bluetooth speaker designed for both indoor and outdoor use. It features 100W peak all-round HD sound with booming bass, thanks to its unique 7.2-inch large passive radiator and four drivers (two subwoofers and two tweeters). With IPX6 waterproof and dustproof capabilities, a long-lasting battery, and multiple connectivity options, it's built to deliver exceptional audio performance in various environments.



Figure 1: W-KING D9-1 Portable Bluetooth Speaker.



Figure 2: Internal components of the W-KING D9-1 speaker, highlighting the woofers, tweeters, and passive bass radiator for powerful sound delivery.



Figure 3: The W-KING D9-1 speaker demonstrating its IPX6 waterproof and dustproof design, suitable for outdoor use.

Setup

1. Unboxing & Initial Inspection

Carefully remove all contents from the packaging. Ensure all items listed below are present and in good condition:

- W-KING D9-1 Portable Loud Bluetooth Speaker
- 3.5mm Audio Cable
- User Manual
- Type-C Charging Cable

Video 1: An unboxing video of the W-KING D9-1 Bluetooth Speaker, showcasing its contents and initial appearance.

2. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's DC 5V port and the other end to a 5V 2A power adapter (not included). A full charge typically takes 4-7 hours. The speaker can also function as a power bank to charge your smart devices via its USB-A port.



Figure 4: The W-KING D9-1 speaker being used as a power bank to charge a smartphone, highlighting its versatile charging capabilities.

3. Powering On/Off

Press and hold the power button (usually marked with a power symbol) on the control panel to turn the speaker on or off. A sound prompt will indicate the power status.

4. Bluetooth Pairing

To pair your device with the W-KING D9-1 speaker:

- Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED.

- On your device (smartphone, tablet, etc.), enable Bluetooth and search for

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KZJFC2F

More documents and user manuals: **https://manuals.plus/**