

[Manuals.plus](#) /

› [MAG](#) /

› MAG TM-606 Digital Timer Instruction Manual

MAG TM-606

MAG TM-606 Digital Timer Instruction Manual

Model: TM-606

INTRODUCTION

Thank you for purchasing the MAG TM-606 Digital Timer. This device is designed to provide clear time management with its large digital display, offering both a countdown timer and a clock function with temperature and humidity readings. Its silent operation makes it ideal for various environments, including offices, classrooms, and homes. Please read this manual thoroughly before use to ensure proper operation and to maximize the product's lifespan.

会議や業務の残り時間を 「見える化」!



タイマーモードで
効率アップ

温度湿度モードで
空調管理

Image: Front view of the MAG TM-606 Digital Timer, showcasing its large digital display and analog clock face.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping the device or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.
- Use only the specified battery type (AA alkaline batteries).

PACKAGE CONTENTS

Please check that all items are present in the package:

- MAG TM-606 Digital Timer Unit

- Instruction Manual (This document)

Note: 4 AA alkaline batteries are required and sold separately.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the unit.
2. Open the battery compartment cover.
3. Insert 4 AA alkaline batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image: Rear view of the MAG TM-606 Digital Timer, highlighting the battery compartment and control buttons.

2. Placement Options

The MAG TM-606 offers versatile placement options:

- **Wall Mounting:** Use the hanging holes on the back of the unit to mount it securely on a wall.
- **Tabletop Stand:** Extend the built-in stand on the back for stable placement on a desk or table.
- **Magnetic Attachment:** The unit features strong magnets, allowing it to be attached to metallic surfaces like whiteboards or refrigerators.



「MAG(マグ)」は、1982年の誕生から
40年以上時計を中心に「ハカル」をテーマに
モノ作りを続けてきた歴史を持つブランドです。



開発・製造現場と連携し、 安定した品質を

お届けする製品の品質安定をお約束するため、
現地製造現場と日本国内の2か所それぞれで
品質レベル向上を目指して専任担当者による
品質検査を日々実施しています。

MAG



Image: Side view of the MAG TM-606 Digital Timer, showing the integrated stand in an extended position for tabletop use.



Image: The MAG TM-606 Digital Timer wall-mounted in a classroom setting, demonstrating its visibility.

OPERATING INSTRUCTIONS

1. Switching Display Modes (Timer / Clock with Environment)

The MAG TM-606 can display either the countdown timer or the clock with temperature and humidity. Use the "Time On/Off" button () on the back of the unit to switch between these modes.




Image: A visual comparison showing the MAG TM-606 in Timer Mode (left) and Clock with Temperature/Humidity Mode (right).

2. Setting the Clock

In clock display mode:

1. Press and hold the "Time Setting" button () until the time digits begin to flash.
2. Use the adjustment buttons (usually located near the setting button, refer to the back panel image) to set the hour and minute.
3. Press the "Time Setting" button again to confirm and move to the next setting (e.g., 12/24 hour format, date, year).
4. Continue adjusting and confirming until all settings are complete.

3. Using the Countdown Timer (60 Minutes)

In timer display mode:

1. The timer can be set for up to 60 minutes.
2. Use the adjustment buttons to set the desired countdown time.
3. Press the "Start/Stop" button (usually integrated with the setting buttons) to begin the countdown.
4. The timer will visually decrease by one scale mark for every minute that passes.
5. A 3-minute prior notice alarm will sound before the timer reaches zero.
6. When the timer reaches zero, the main alarm will sound.
7. To pause the timer, press the "Start/Stop" button during the countdown. Press again to resume.

8. To reset the timer, press the "Reset" button () on the back.



Image: The MAG TM-606 Digital Timer in use, displaying a countdown timer on a desk in an office environment.

4. Adjusting Alarm Volume

The alarm sound can be switched between Large, Small, and Mute. Use the "Volume" button () on the back of the unit to cycle through these options.

5. Environmental Guidelines

In clock mode, the display provides temperature and humidity readings. It also includes environmental guidelines, such as warnings for flu risk and heatstroke risk, based on these readings. Pay attention to these indicators for a healthier indoor environment.

MAINTENANCE

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** When the display becomes dim or the unit functions erratically, replace all 4 AA

batteries with new ones. Do not mix old and new batteries.

- **Storage:** If storing the unit for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Batteries are low or incorrectly installed.	Replace with new AA alkaline batteries, ensuring correct polarity.
Timer does not start or stops unexpectedly.	Timer not set correctly or batteries are low.	Ensure the timer is set to a value greater than zero. Check and replace batteries if needed.
Alarm sound is not audible.	Volume is set to Mute or Small.	Press the "Volume" button to cycle through volume settings (Large, Small, Mute).
Incorrect time or date displayed.	Time/date not set or reset due to battery change.	Re-set the clock using the "Time Setting" button.

SPECIFICATIONS

- **Model:** TM-606
- **Product Size (H x W x D):** Approximately 22.9 x 36.8 x 2.9 cm (9.0 x 14.5 x 1.1 inches)
- **Weight:** Approximately 960 g (2.12 lbs)
- **Material:** Resin, Glass
- **Display Type:** Digital (with analog-style visual timer)
- **Power Source:** 4 AA alkaline batteries (sold separately)
- **Functions:**
 - Countdown Timer (max 60 minutes)
 - Timer Pause Function
 - Volume Switching (Large, Small, Mute)
 - 3-Minute Prior Notice Alarm
 - Clock Display (12/24 hour)
 - Temperature Display
 - Humidity Display
 - Calendar Display
 - Environmental Guidelines (Flu and Heat Warning)
 - Mounting Options: Magnet, Stand, Wall Hanging



MAG

Image: Diagram illustrating the dimensions (height, width, depth) and weight of the MAG TM-606 Digital Timer.

WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your original packaging for specific terms and conditions, including warranty period and coverage details. Keep your purchase receipt as proof of purchase for warranty claims.

For information regarding extended protection plans, please refer to your retailer or the product's purchase page.

CUSTOMER SUPPORT

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact your retailer or the MAG customer support service. Contact details can typically be found on the manufacturer's official website or on your product packaging.

When contacting support, please have your product model number (TM-606) and purchase information ready.

© 2023 MAG. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08L2ZK4XJ>

More documents and user manuals: <https://manuals.plus/>