



Manuals.plus /

› iClever /

› iClever GK03 Wireless Keyboard and Mouse Combo User Manual

## iClever GK03

# iClever GK03 Wireless Keyboard and Mouse Combo

User Manual

## INTRODUCTION

---

Thank you for choosing the iClever GK03 2.4G Wireless Keyboard and Mouse Combo. This manual provides detailed instructions for setting up, operating, and maintaining your new device. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.

## PACKAGE CONTENTS

---

- 1 x iClever GK03 Wireless Keyboard
- 1 x Wireless Mouse
- 1 x 2.4G USB Receiver
- 1 x USB-C Charging Cable (for keyboard)
- 1 x User Manual

## PRODUCT OVERVIEW

---

The iClever GK03 combo features a slim, full-size QWERTZ keyboard and a comfortable wireless mouse, designed for efficiency and quiet operation. The keyboard is made from aluminum and high-quality ABS, offering a premium feel and portability. The mouse features adjustable DPI settings for precise control.



Image: The iClever GK03 wireless keyboard and mouse, along with the compact USB receiver.



Image: The iClever GK03 keyboard and mouse combo in a typical desktop setup, demonstrating its compact and sleek design.

## SETUP

---

### 1. Charging the Keyboard

Before first use, ensure the keyboard is fully charged. Connect the provided USB-C charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter).

- **Battery Capacity:** 280 mAh
- **Charging Time:** Approximately 2 hours
- **Standby Time:** Up to 90 days



Image: The iClever GK03 keyboard being charged via its USB-C port.

## 2. Installing Mouse Batteries

The mouse requires 2 AAA batteries (not included). Open the battery compartment on the underside of the mouse, insert the batteries according to the polarity indicators, and close the compartment.

## 3. Connecting the 2.4G USB Receiver

Locate the 2.4G USB receiver. Plug the receiver into an available USB-A port on your computer (desktop, laptop, etc.). The system should automatically detect and install the necessary drivers.



Image: The compact 2.4G USB receiver, which connects both the keyboard and mouse to your device.

# Kompatibel mit folgenden Geräten

- ✓ Alle Windows-PCs und Laptops
- ✓ Mac/iMac-Modelle mit USB-A-Anschluss



Windows laptop



MacBook



iMac



Windows PC

## Hinweis für Mac/iMac-Nutzer:

Bitte prüfen Sie vor dem Kauf, ob Ihr Gerät über einen USB-A-Anschluss verfügt.



**USB-A-Anschluss** ✓

**USB-C-Anschluss** ✗

### Kompatible Modelle (mit USB-A-Anschluss):

**iMac:**  
Retina 5K, 27 Zoll (2020, 2019, 2017)  
Retina 4K, 21,5 Zoll (2019, 2017)

**MacBook Air:**  
Baujahr 2017 oder älter

**MacBook Pro:**  
Baujahr 2015 oder älter

Image: Compatibility diagram showing various devices (Windows laptops, MacBooks, iMacs, Windows PCs) that support the USB-A connection.

## 4. Powering On

Turn on the keyboard and mouse using their respective power switches. The devices should automatically connect to the receiver. No pairing is required.

## OPERATING INSTRUCTIONS

### Keyboard Functions

The keyboard features a full 99-key QWERTZ layout, including a numeric keypad for efficient data entry. It is designed for quiet typing with its unique scissor-switch mechanism.



Image: The keyboard features a standard German QWERTZ layout for familiar and efficient typing.

**Operating System Compatibility:** The keyboard supports both Windows and macOS. Use the dedicated "Win | Cmd" and "Alt | Option" keys to switch between operating system layouts as needed.



Image: The keyboard's "Win | Cmd" and "Alt | Option" keys allow seamless switching between Windows and macOS functions.

### Mouse DPI Adjustment

The mouse offers 3 adjustable DPI levels (1000-1200-1600) to suit your preference for cursor sensitivity and precision. Press the DPI button on the mouse to cycle through the settings.



Image: The mouse features quiet clicks and adjustable DPI settings for customized sensitivity.

## Power Saving Feature

To conserve battery life, the wireless keyboard and mouse will enter sleep mode after 10 minutes of inactivity. To wake them up, simply press any key on the keyboard or click a mouse button and wait for approximately 3 seconds for reconnection.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For the mouse, remove batteries if the device will not be used for an extended period. For the keyboard, recharge regularly to maintain battery health.

## TROUBLESHOOTING

---

Problem	Solution
Keyboard/Mouse not responding	<ol style="list-style-type: none"> <li>1. Ensure the USB receiver is securely plugged into a working USB-A port.</li> <li>2. Check if the keyboard and mouse are powered on.</li> <li>3. For the keyboard, ensure it is charged. For the mouse, check/replace AAA batteries.</li> <li>4. Move the devices closer to the receiver to ensure they are within the 10-meter range.</li> <li>5. Try plugging the receiver into a different USB port.</li> </ol>
Lag or intermittent connection	<ol style="list-style-type: none"> <li>1. Reduce interference by moving other 2.4GHz wireless devices away.</li> <li>2. Ensure there are no large metal objects between the devices and the receiver.</li> <li>3. Recharge the keyboard or replace mouse batteries.</li> </ol>
Mouse cursor erratic or not moving smoothly	<ol style="list-style-type: none"> <li>1. Clean the mouse sensor.</li> <li>2. Try a different surface for the mouse.</li> <li>3. Adjust the DPI setting on the mouse.</li> </ol>

## SPECIFICATIONS

Feature	Detail
Brand	iClever
Model Number	GK03
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Keyboard Layout	QWERTZ (German)
Number of Keys (Keyboard)	99
Keyboard Battery	280 mAh Rechargeable (USB-C)
Mouse Battery	2 x AAA (not included)
Mouse DPI Levels	1000-1200-1600
Operating System Compatibility	Android, Windows (8/10/11), macOS, Chrome OS
Compatible Devices	Personal Computer, Laptop, Smartphone, Tablet
Wireless Range	Up to 10 meters (33 feet)
Color	Grey
Special Features	Programmable Button (mouse), Ergonomic, Lightweight, Rechargeable (keyboard)

# Kompaktes und schlankes Design



Image: Dimensions of the iClever GK03 keyboard and mouse for reference.

## WARRANTY AND SUPPORT

iClever products come with a standard manufacturer's warranty. For specific warranty details, technical support, or any inquiries regarding your iClever GK03 Wireless Keyboard and Mouse Combo, please refer to the warranty card included in your package or visit the official iClever website. Contact information for customer support is typically available on the product packaging or the brand's official online channels.