

[Manuals.plus](#) /

› [GEOYEAO](#) /

› GEOYEAO 1080P Blu-ray DVD Player User Manual

GEOYEAO GEOYEAO 1080P Blu-ray Player

GEOYEAO 1080P Blu-ray DVD Player User Manual

Model: GEOYEAO 1080P Blu-ray Player

INTRODUCTION

Thank you for purchasing the GEOYEAO 1080P Blu-ray DVD Player. This compact and versatile media player is designed to provide high-quality audio and video playback for your home entertainment system. It supports Blu-ray discs, DVDs, CDs, and media files from USB drives, offering full HD 1080P resolution with advanced image and color correction. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Image: The GEOYEAO 1080P Blu-ray DVD Player shown with its included remote control.

SETUP

Follow these steps to connect your Blu-ray DVD player to your television or display device.

1. Power Connection

- Connect the power cable to the player's power input port.
- Plug the other end of the power cable into a standard electrical outlet.

2. Connecting to TV via HDMI

For the best video and audio quality, use an HDMI cable to connect the player to your TV.

- Locate the HDMI OUT port on the back of the Blu-ray DVD player.
- Connect one end of the HDMI cable (included) to the HDMI OUT port on the player.
- Connect the other end of the HDMI cable to an available HDMI IN port on your television. Note the HDMI input number (e.g., HDMI 1, HDMI 2) on your TV.
- Turn on your TV and select the corresponding HDMI input using your TV's remote control.

HDMI 端子

最高の1080p画質を実現できる



HDMIケーブル

Image: The Blu-ray player connected to a display via an HDMI cable, illustrating the HDMI terminal for 1080p output.

3. Connecting to TV via AV Output (Composite)

If your TV does not have an HDMI input, you can use the AV (composite) output for video and audio.

- Locate the AV OUT ports (typically yellow for video, white for left audio, red for right audio) on the back of the Blu-ray DVD player.
- Connect the corresponding colored plugs of an AV cable (not included) to the AV OUT ports on the player.
- Connect the other end of the AV cable to the matching AV IN ports on your television.
- Turn on your TV and select the AV input (sometimes labeled 'Video In' or 'Component In') using your TV's remote control.

AV端子出力

AV接続のみのテレビもお気軽
にご利用できます



Image: The Blu-ray player connected to a television using AV output terminals, suitable for TVs with AV connections only.

OPERATING INSTRUCTIONS

1. Disc Playback

1. Ensure the player is powered on and connected to your display.
2. Gently open the disc tray cover.
3. Place a Blu-ray disc, DVD, or CD onto the disc spindle with the label side facing up.
4. Close the disc tray cover. The player will automatically begin reading the disc.
5. Use the remote control to navigate menus and control playback (Play, Pause, Stop, Skip, etc.).

2. USB & HDD Playback

The player supports playback of video, image, and MP3 files from USB memory sticks and mobile hard drives (up to 32GB USB / 8TB HDD).

- Insert your USB flash drive or external hard drive into the USB port on the player.

- The player should detect the device and display a menu for file selection. If not, use the remote to select the USB input source.
- Navigate through your folders and files using the remote control's arrow keys and OK button.
- Select the desired file to begin playback.



Image: The Blu-ray player highlighting its USB and HDD connection capabilities, supporting playback of video, image, and MP3 files.

3. Audio Features (Dolby & DTS)

Experience immersive sound with built-in Dolby Digital and DTS sound effects. Ensure your audio system is properly connected to take advantage of these features.

Dolby & DTS

高音質の鑑賞体験で映画館のような臨場感があります



Image: The Blu-ray player displaying Dolby and DTS logos, indicating support for high-quality audio formats for a cinematic experience.

4. Region Compatibility

This player supports Blu-ray discs from Region A and Region 1, and is region-free for standard DVD formats (PAL/NTSC compatible).

リージョンA/1

リージョンA、リージョン1ブルーレイディスク & リージョンフリーの通常DVDフォーマットをサポート



Image: The Blu-ray player indicating support for Region A and Region 1 Blu-ray discs, and region-free standard DVD formats.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Blu-ray DVD player.

- **Cleaning the Unit:** Use a soft, dry cloth to wipe the exterior of the player. Do not use liquid cleaners or aerosol sprays, as they may damage the finish or internal components.
- **Disc Care:** Handle discs by their edges. Keep discs clean and free of scratches, dust, and fingerprints. Use a soft, lint-free cloth to wipe discs from the center outwards.
- **Ventilation:** Ensure adequate ventilation around the player. Do not block any ventilation openings. Avoid placing the player in enclosed spaces or on soft surfaces that may obstruct airflow.
- **Storage:** When not in use for extended periods, disconnect the power cable and store the player in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your player, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active.	Ensure power cable is securely connected to player and a working outlet.
No picture/sound	Incorrect input selected on TV; Loose HDMI/AV cables; Disc is dirty or damaged.	Select correct TV input. Check all cable connections. Clean or replace disc.
Disc does not play or skips	Disc is dirty, scratched, or incompatible format; Player lens is dirty.	Clean disc. Ensure disc format is supported. Try a different disc. Consider a lens cleaning disc.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and player; Remote not aimed correctly.	Replace batteries, ensuring correct polarity. Remove obstructions. Aim remote directly at the player's sensor.
Noise during playback (e.g., from car use)	Electrical interference; Ground loop issues.	Ensure proper grounding. Use a noise filter if necessary, especially in vehicle installations.



Image: Illustration of the player's smart chip features, including error correction, high-speed reading, and noise cancellation, designed to enhance playback quality.

SPECIFICATIONS

Feature	Detail
Brand	GEOYEAO

Feature	Detail
Model	1080P Blu-ray Player
Supported Media Types	Blu-ray Disc, DVD, CD, USB Memory, External HDD
Resolution	1920 x 1080 (1080P Full HD)
Connectivity	HDMI, USB, Coaxial 2.0, AV Output
Audio Output Mode	Surround (DTS, Dolby Digital compatible)
Blu-ray Region Compatibility	Region A / Region 1
DVD Region Compatibility	Region Free
Video Input Compatibility	NTSC, PAL
Dimensions (approx.)	30 x 30 x 9 cm
Weight (approx.)	1.42 kg
ASIN	B08L3DLFZN
UPC	850023413048

WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or service, please refer to the warranty card included with your product or visit the official GEOYEAO website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 GEOYEAO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08L3DLFZN>

More documents and user manuals: <https://manuals.plus/>