

[Manuals.plus](#) /

› [HEANTTV](#) /

› HEANTTV PC Soundbar User Manual

HEANTTV 009

HEANTTV PC Soundbar User Manual

Model: 009

INTRODUCTION

Thank you for purchasing the HEANTTV PC Soundbar. This manual provides essential information for setting up, operating, and maintaining your new soundbar. Please read this manual thoroughly before use to ensure proper functionality and to maximize your listening experience.

SAFETY INFORMATION

- Do not expose the device to water or excessive moisture.
- Avoid placing the soundbar near heat sources or in direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the specified power supply (USB 5V).
- Keep out of reach of children.

PACKAGE CONTENTS

- HEANTTV PC Soundbar (Model: 009)
- USB Power Cable
- 3.5mm Auxiliary Audio Cable
- User Manual (this document)

PRODUCT OVERVIEW

The HEANTTV PC Soundbar is designed to deliver powerful stereo sound for your desktop computer, laptop, and other smart devices. It features a sleek design with an integrated volume control knob and LED lighting.



Front view of the HEANTTV PC Soundbar, showcasing its sleek design and blue LED light strip.



Diagram illustrating the dimensions of the HEANTTV PC Soundbar: 32cm (12.6in) length, 6.4cm (2.36in) depth, and 6cm (2.52in) height.

2.0 STEREO SOUND EFFECT

Designed with 2*5 w drivers, delivers a rich and powerful stereo sound. By using the enclosed low-frequency aid design, while enjoying music which makes you feel like you are there.



Illustration demonstrating the 2.0 stereo sound effect produced by the HEANTTV PC Soundbar, designed with 2x5W drivers for rich and powerful audio.

SETUP

Wired Connection (USB Power + 3.5mm AUX)

1. Connect the USB power cable from the soundbar to an available USB port on your computer or a 5V USB power adapter.
2. Connect the 3.5mm auxiliary audio cable from the soundbar's AUX input to the audio output (headphone jack) of your computer or device.
3. The soundbar will power on automatically.

Bluetooth Connection

1. Ensure the soundbar is powered on.

2. Short press the control knob once to switch to Bluetooth mode. You will hear an audible prompt indicating Bluetooth mode is activated.
3. On your device (smartphone, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "HEANTTV Soundbar" (or similar name) from the list to pair. Once paired, you will hear a confirmation sound.

WIDE COMPATIBILITY BEYOND YOUR IMAGINATION

The 3.5mm universal audio jack makes the speaker a computer audio, compatible with 99% of smart devices on the market.



Adator



Power Bank



PC Laptop




PC



mp3



iPhone



Tablet



PC Laptop



PC

Diagram illustrating the wide compatibility of the HEANTTV PC Soundbar with various devices including adapters, power banks, PCs, laptops, smartphones, tablets, and MP3 players, via 3.5mm audio jack and USB.

OPERATING INSTRUCTIONS

Control Knob Functions

SIMPLE CONTROL



Turn the knob
increase or decrease the volume



Short press
Bluetooth/AUX switch



Short press twice
turn LED on or off



Long press for three seconds
turn on or off



Visual guide to the simple control functions of the HEANTTV PC Soundbar's knob: turning for volume, short press for Bluetooth/AUX switch, short press twice for LED on/off, and long press for three seconds to turn on/off.

- **Turn the knob:** Rotate clockwise to increase volume, counter-clockwise to decrease volume.
- **Short press once:** Switches between Bluetooth mode and AUX mode.
- **Short press twice:** Toggles the LED light on or off.
- **Long press for three seconds:** Turns the soundbar on or off.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the cables excessively to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound	Power not connected; Volume too low; Incorrect input mode; Device not connected properly.	Ensure USB power is connected. Increase volume on soundbar and connected device. Short press knob to switch input mode (Bluetooth/AUX). Reconnect 3.5mm AUX cable or re-pair Bluetooth.
Sound distortion	Volume too high; Poor audio source quality; Interference.	Lower the volume. Try a different audio source. Move soundbar away from other electronic devices.
Bluetooth pairing failure	Soundbar not in pairing mode; Device Bluetooth off; Too far from device.	Short press knob to ensure soundbar is in Bluetooth mode. Enable Bluetooth on your device. Move device closer to the soundbar (within 10 meters).
LED light not working	LED light turned off.	Short press the knob twice to toggle the LED light on.

SPECIFICATIONS

Feature	Detail
Model Name	009
Brand	HEANTTV
Speaker Type	Soundbar
Connectivity Technology	Auxiliary, USB, Bluetooth
Audio Output Mode	Stereo
Maximum Speaker Output Power	6 Watts
Input Voltage	5 Volts
Controller Type	Button
Color	Black + 3.5mm
Material	Plastic
Product Dimensions (L x W x H)	32 x 6.4 x 6 cm (12.6 x 2.52 x 2.36 inches)
Item Weight	480 Grams
Recommended Uses for Product	For computer

Feature	Detail
Compatible Devices	Computer, laptop, desktop computer, tablet, microphone, smartphone, projector, MP3, MP4, CD player
Special Feature	Portable

WARRANTY AND SUPPORT

HEANTTV provides an 18-month hassle-free replacement policy for this product, along with lifetime customer service. For any issues or inquiries, please refer to the contact information provided with your purchase or visit the official HEANTTV support website.

© 2025 HEANTTV. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question