Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kastar NOCAR-0B-LPE5-A

Kastar AC Wall Battery Charger User Manual

Model: NOCAR-0B-LPE5-A

Introduction

Thank you for purchasing the Kastar AC Wall Battery Charger. This charger is designed to provide efficient and reliable power for your compatible camera batteries. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan. Keep this manual for future reference.

Important Safety Information

- Do not expose the charger to rain or moisture.
- To reduce the risk of electric shock, do not disassemble the unit. Refer servicing to qualified service personnel only.
- Use the charger only with compatible battery models as specified in this manual.
- Avoid using the charger in extremely hot or cold environments.
- Unplug the charger from the power outlet when not in use.
- Keep out of reach of children.

Package Contents

Verify that all items are present in your package:

- 1 x Kastar AC Wall Battery Charger




Kastar
Kastar
Kastar
Convenience of Life
Battery charger
Kastar
BATTERY CHARGER
CHARGE
EASY
PLUG
For digital camcorder/video battery charger series
For digital camera battery charger series
Product
Voltage
Digital Camera
Digital Camcorder
3.6/3.7V
7.2/7.4V
High Cap
2 Hours
2 Hours
2 Hours
3.5 Hours
2 Hours
2.5 Hours
4 Hours

Image: The Kastar AC Wall Battery Charger shown within its retail box, indicating typical packaging.

Product Overview

The Kastar AC Wall Battery Charger is a compact and efficient device designed for charging specific Canon camera batteries. It features a foldable flat pin for convenient storage and portability.




Image: Front view of the Kastar AC Wall Battery Charger, showing the battery slot and the LED charge indicator.



Image: Back view of the Kastar AC Wall Battery Charger, displaying the product name, input/output specifications, and safety warnings.

Key Features:

- Foldable flat pin for easy storage and travel.
- LED indicator for charging status: Red for charging, Green for standby or full-charge.
- Wide input voltage range (AC 100-240V) for international use.

Setup

Follow these steps to prepare your charger for use:

1. Unfold the AC prongs from the charger body.
2. Ensure the battery you intend to charge is compatible with this charger (refer to the Compatibility section).



Image: The Kastar AC Wall Battery Charger with its foldable AC prongs extended, ready to be plugged into a wall outlet.

Operating Instructions

Charging your battery is a simple process:

1. Insert the compatible battery into the charger's battery slot, ensuring it is seated correctly.
2. Plug the charger into a standard AC wall outlet (100-240V).
3. Observe the LED indicator:
    - A **RED** light indicates that the battery is currently charging.
    - A **GREEN** light indicates that the battery is fully charged or the charger is in standby mode (no battery inserted or charging complete).
4. Once the LED turns green, the battery is fully charged. Unplug the charger from the wall outlet and remove the battery.

Compatibility

This charger is designed for use with the following battery and camera models:

Compatible Battery Models:

- Canon LP-E5 / LPE5

Compatible Charger Models (for reference, this product replaces these):

- Canon LC-E5
- Canon LC-E5C
- Canon LC-E5E

Compatible Camera Models:

- Canon EOS Rebel XSi
- Canon EOS Rebel XS
- Canon EOS Rebel T1i
- Canon EOS 450D
- Canon EOS 500D
- Canon EOS 1000D
- Canon EOS Kiss F
- Canon EOS Kiss X2
- Canon EOS Kiss X3

Maintenance

To ensure the longevity and optimal performance of your charger:

- Keep the charger clean and dry. Use a soft, dry cloth to wipe its surface.
- Do not use liquid cleaners or abrasive chemicals.
- Store the charger in a cool, dry place when not in use.
- Avoid dropping the charger or subjecting it to strong impacts.

Troubleshooting

If you encounter issues with your charger, refer to the following table:

Problem	Possible Cause	Solution
Charger LED does not light up.	No power from outlet; charger not plugged in correctly; faulty outlet.	Check wall outlet with another device; ensure charger is fully plugged in.
LED remains green when battery is inserted.	Battery already fully charged; battery not inserted correctly; incompatible battery.	Ensure battery is properly seated; verify battery compatibility; try a different battery.
Battery does not charge or charges slowly.	Battery is faulty or at end of life; charger is faulty.	Try charging a different, known-good battery; if issue persists, contact customer support.

Specifications

Model Number	NOCAR-0B-LPE5-A
Input	AC 100-240V, 50/60Hz
Output	DC 8.4V, 600mA
Dimensions	2 x 1.5 x 3 inches (approx.)
Weight	2.4 ounces (approx.)
Manufacturer	Kastar
Country of Origin	China

Warranty and Support

Kastar products are manufactured to high quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Kastar website. Please retain your proof of purchase for any warranty claims.
For further assistance, you may also refer to theKastar Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08L4NRX33

More documents and user manuals: **https://manuals.plus/**