

Ankuka AKBT035ALB

Ankuka AKBT035ALB Wireless Karaoke Microphone User Manual

Model: AKBT035ALB

INTRODUCTION

Thank you for choosing the Ankuka AKBT035ALB Wireless Karaoke Microphone. This device combines a microphone, speaker, and music player into one portable unit, offering versatile entertainment. This manual provides essential information for safe and effective use, including setup, operation, and maintenance instructions.





Figure 1: The Ankuka AKBT035ALB Wireless Karaoke Microphone, showcasing its compact design and integrated LED lights.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Keep out of reach of small children to prevent choking hazards from small parts.
- Use only the provided charging cable or a certified equivalent.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Ankuka Wireless Karaoke Microphone
- USB Charging Cable
- Audio Cable (Note: Audio cable for recording may not be included and needs to be purchased separately.)
- User Manual (This document)



Figure 2: Detailed view of the microphone's control panel and connection ports.

Control Panel Functions:

- **ON/OFF Button:** Press and hold to power on/off. Short press to switch modes.

- **Mic Volume (+/-):** Adjusts the microphone's input volume.
- **Echo (+/-):** Adjusts the echo effect level.
- **Music Volume (+/-):** Adjusts the volume of the connected music source.
- **Previous Song:** Skips to the previous track.
- **Play/Pause:** Plays or pauses the current track.
- **Next Song:** Skips to the next track.
- **Original Sing/Accompaniment:** Toggles between original vocal track and instrumental accompaniment.
- **LED Light/Magic Sound:** Short press to change LED light modes. Long press to cycle through magic voice effects.

Connection Ports:

- **Charging Port (Micro USB):** Connect the USB charging cable here to charge the device.
- **Audio Output Port (3.5mm):** Connect an audio cable for recording or external audio output.
- **TF Card Slot:** Insert a TF (MicroSD) card (up to 64GB, not included) to play music directly.
- **USB Port:** For additional connectivity options (e.g., USB drive for music playback).

SETUP

1. Charging the Microphone

1. Connect the Micro USB end of the charging cable to the Charging Port on the microphone.
2. Connect the USB-A end of the charging cable to a USB power adapter (5V/1A recommended) or a computer's USB port.
3. The Charging Indicator light will illuminate during charging and turn off when fully charged. A full charge typically takes 2-3 hours and provides 4-6 hours of continuous use.

2. Bluetooth Connection

1. Press and hold the ON/OFF button to power on the microphone. A voice prompt will indicate that Bluetooth mode is active.
2. On your smartphone or other Bluetooth-enabled device, open the Bluetooth settings and search for available devices.
3. Select "AK-868" from the list to pair. A voice prompt will confirm successful connection.
4. Once connected, you can play music from your device through the microphone's speaker.

Widely compatible

Compatible with Most APPs and Devices



Figure 3: The microphone demonstrating Bluetooth connectivity with various smart devices.

3. TF Card Playback

1. Insert a TF (MicroSD) card with MP3 music files into the TF Card Slot.
2. The microphone will automatically switch to TF card playback mode. Use the Previous/Next Song and Play/Pause buttons to control music playback.

OPERATING INSTRUCTIONS

1. Singing with Music

1. Ensure the microphone is powered on and connected to your music source (Bluetooth or TF card).
2. Play your desired music track.
3. Adjust the Mic Volume, Music Volume, and Echo levels to your preference using the respective buttons on the control panel.
4. Sing into the microphone.

2. Voice Changing Effects

The microphone features multiple voice-changing effects for added fun:

- Long press the **LED Light/Magic Sound** button to cycle through different voice effects (e.g., baby voice, monster voice, male voice, female voice, original vocal).
- A voice prompt will announce the activated effect.

3. LED Lights

The integrated LED lights enhance the karaoke experience:

- Short press the **LED Light/Magic Sound** button to change the LED light patterns or turn them off.
- The lights will also react to the music volume, becoming brighter with louder sound.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the features and usage of the Ankuka Wireless Karaoke Microphone, including its various color options and control functions.

MAINTENANCE

- Clean the microphone with a soft, dry cloth. Do not use abrasive cleaners or liquids.
- Store the device in a cool, dry place away from direct sunlight when not in use.
- Avoid blocking the speaker grille to maintain optimal sound quality.

Three-layer noise reduction

Rechargeable battery working time up to 6-8 hours



Figure 4: Illustration highlighting the three-layer noise reduction technology and powerful speaker for clear audio output.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Microphone does not power on.	Low battery.	Charge the microphone fully.
No sound from speaker.	Volume too low; device not connected.	Increase Music Volume. Ensure Bluetooth or TF card is properly connected.
Cannot connect via Bluetooth.	Bluetooth not enabled; device too far; interference.	Ensure microphone is in Bluetooth mode. Move device closer. Restart both devices.
Echo effect not working.	Echo level set to minimum.	Increase the Echo level using the '+' button.

SPECIFICATIONS

Feature	Detail
Model Number	AKBT035ALB
Connectivity	Bluetooth, USB, TF Card
Power Source	Battery Powered
Battery Life	4-6 hours (continuous use)
Compatible Devices	Smartphone (iOS & Android)
TF Card Support	Max 64GB (not included)
Item Weight	14.4 ounces
Product Dimensions	3.94 x 5.51 x 4.72 inches

WARRANTY AND SUPPORT

Ankuka products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or the official Ankuka website. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question