



Manuals.plus /

› Calypso /

› Calypso K5801/1 Digital Quartz Watch User Manual

## Calypso K5801/1

# Calypso K5801/1 Digital Quartz Watch User Manual

Model: K5801/1

## 1. PRODUCT OVERVIEW

---

The Calypso K5801/1 is a versatile digital quartz watch designed for daily use and sports activities. It features a durable plastic strap, a robust polycarbonate case, and is water-resistant up to 100 meters. Key functions include a stopwatch, timer, alarm, and backlight for visibility in low light conditions.



Image 1.1: Front view of the Calypso K5801/1 Digital Quartz Watch, displaying the digital screen and control buttons.



1. From Timekeeping Mode, press **MODE** once to enter Alarm Mode.
2. Press and hold **SET/ADJ** until the alarm hour flashes.
3. Use **ST/LAP/RFL** to adjust the hour. Press **MODE** to move to minutes.
4. Use **ST/LAP/RFL** to adjust the minutes.
5. Press **SET/ADJ** to confirm and exit.
6. To turn the alarm ON/OFF, press **ST/LAP/RFL** while in Alarm Mode (not setting mode). An alarm icon will appear/disappear.

### 4.3 Stopwatch Mode

1. From Timekeeping Mode, press **MODE** twice to enter Stopwatch Mode.
2. Press **ST/LAP/RFL** to start the stopwatch.
3. Press **ST/LAP/RFL** again to stop it.
4. To reset the stopwatch, press **SET/ADJ** while the stopwatch is stopped.
5. To record lap times, press **SET/ADJ** while the stopwatch is running. The lap time will display briefly, and the stopwatch continues running in the background. Press **ST/LAP/RFL** to stop, then **SET/ADJ** to reset.

### 4.4 Timer Mode

1. From Timekeeping Mode, press **MODE** three times to enter Timer Mode.
2. Press and hold **SET/ADJ** until the timer hour flashes.
3. Use **ST/LAP/RFL** to adjust the hour. Press **MODE** to move to minutes, then seconds.
4. Use **ST/LAP/RFL** to adjust the minutes and seconds.
5. Press **SET/ADJ** to confirm the timer setting.
6. Press **ST/LAP/RFL** to start the countdown.
7. Press **ST/LAP/RFL** again to pause/resume the countdown.
8. When paused, press **SET/ADJ** to reset the timer to its initial set value.
9. An alarm will sound when the timer reaches zero.

### 4.5 Backlight Function

Press the **LIGHT** button to illuminate the display for a few seconds, improving visibility in dark environments.

## 5. MAINTENANCE

---

### 5.1 Cleaning

Wipe the watch case and strap regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly. Avoid using harsh chemicals or abrasive materials.

### 5.2 Water Resistance (100 Meters / 10 ATM)

The Calypso K5801/1 watch is water-resistant up to 100 meters (10 ATM). This means it is suitable for swimming, showering, and snorkeling. However, it is **not** suitable for high-impact water sports, diving, or hot water activities like saunas or hot tubs, as steam and rapid temperature changes can compromise the seals. Always ensure the crown (if present, though digital watches typically don't have one in the traditional sense) and buttons are not operated while the watch is wet or submerged.

### 5.3 Battery Replacement

When the display becomes dim or functions become erratic, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery (recommended by a professional).
Time is incorrect.	Time not set correctly or accidental adjustment.	Refer to Section 3.2 "Setting Time and Date" to reset.
Buttons are unresponsive.	Watch may be in a locked mode (unlikely for this model) or internal malfunction.	Try a soft reset by removing and reinserting the battery (professional service recommended). If issue persists, contact support.
Water inside the watch.	Seals compromised due to impact, age, or button operation underwater.	Immediately take the watch to a professional for inspection and repair to prevent further damage.

## 7. SPECIFICATIONS

- **Model Number:** K5801/1
- **Brand:** Calypso
- **Display Type:** Digital
- **Movement Type:** Quartz
- **Case Material:** Polycarbonate / Plastic
- **Band Material:** Plastic
- **Dial Window Material:** Plastic
- **Case Diameter:** 36 Millimeters
- **Case Thickness:** 16 Millimeters
- **Band Width:** 14 Millimeters
- **Clasp Type:** Pin Buckle
- **Water Resistance Depth:** 100 Meters (10 ATM)
- **Special Features:** Alarm, Chronograph (Stopwatch), Light Function, Timer
- **Power Source:** Battery Powered
- **Item Weight:** 65 Grams
- **Product Dimensions:** 20 x 20 x 20 cm (approximate packaging dimensions)

## 8. WARRANTY AND SUPPORT

Specific warranty details for the Calypso K5801/1 watch are not provided in the product information. Please refer to the warranty card included with your purchase or contact your retailer for warranty terms and conditions. For technical support or service inquiries, please contact Calypso customer service or an authorized service center.