

Manuals.plus /

> [HCDZ](#) /

> HCDZ Replacement Remote Control for JVC Stereo Systems (Models: CA-MXJ950R, RM-SMXJ950R, MX-J950R, CA-MXJ950RB, MX-J950RB)

HCDZ RM-SMXKC2J

HCDZ Replacement Remote Control User Manual

Model: RM-SMXKC2J

INTRODUCTION

This manual provides instructions for the HCDZ Replacement Remote Control, model RM-SMXKC2J. This remote is designed as a direct replacement for various JVC Compact Component Stereo Systems, including models CA-MXJ950R, RM-SMXJ950R, MX-J950R, CA-MXJ950RB, and MX-J950RB. No programming is required for operation; simply insert batteries to begin use.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.



Image: Back view of the remote control, illustrating the location of the battery compartment.



Image: The remote control with its battery compartment open, ready for battery insertion.

Note: Batteries are not included with the remote control. Use new alkaline batteries for optimal performance.

OPERATING INSTRUCTIONS

Once batteries are correctly installed, the remote control is ready for immediate use. No additional programming or setup is required.

- Point the remote control directly towards the infrared sensor on your JVC Compact Component Stereo System.
- Press the desired function button (e.g., Power, Volume Up/Down, Play, Stop) to control your stereo system.
- Ensure there are no obstructions between the remote control and the stereo system's sensor.

MAINTENANCE

- **Battery Care:**
 - Do not mix new batteries with old ones.
 - If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent potential damage from leakage and corrosion.
 - Dispose of used batteries responsibly according to local regulations.
- **Environmental Conditions:**
 - Do not leave the remote control in extremely hot or humid environments.
 - Avoid exposing the remote control's infrared sensor to direct sunlight or strong artificial lighting, as this may interfere with its operation.
- **Cleaning:**
 - Clean the remote control with a soft, dry cloth.
 - Do not use abrasive cleaners, solvents, or chemical agents, as these can damage the surface or internal components.

TROUBLESHOOTING

If the remote control does not function as expected, please check the following:

- **No Response from Stereo System:**
 - Ensure batteries are inserted correctly with the proper polarity.
 - Replace old batteries with new ones.
 - Verify that there are no obstructions between the remote control and the stereo system's infrared sensor.
 - Confirm that the remote control is pointed directly at the stereo system's sensor.
 - Check if the stereo system itself is powered on and functioning correctly.
- **Intermittent Operation:**
 - This could indicate low battery power. Replace batteries.
 - Ensure the remote sensor on the stereo system is not exposed to strong light sources (e.g., direct sunlight, fluorescent lights), which can interfere with the infrared signal.

SPECIFICATIONS

Brand	HCDZ
Model Number	RM-SMXKC2J
Compatible Devices	JVC Compact Component Stereo Systems (CA-MXJ950R, RM-SMXJ950R, MX-J950R, CA-MXJ950RB, MX-J950RB)
Connectivity Technology	Infrared (IR)

Special Feature	No programming needed
Controller Type	Button Control
Maximum Range	10 Meters (approximately 33 feet)
Battery Type	2 x AAA Alkaline Batteries (not included)
Max Number of Supported Devices	1

WARRANTY INFORMATION

This HCDZ Replacement Remote Control comes with a **90-day warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, concerns, or technical assistance regarding your HCDZ Replacement Remote Control, please contact the seller directly through the platform where the purchase was made. You may also visit the official HCDZ store on Amazon for more information:

[HCDZ Amazon Store](#)

© 2024 HCDZ. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08L5VPJ7Y>

More documents and user manuals: <https://manuals.plus/>