

KYODOLED GT-KB-60SM-Black

KYODOLED 60-Key Storage Lock Box with Combination Lock
User Manual

Model: GT-KB-60SM-Black
Brand: KYODOLED

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your KYODOLED 60-Key Storage Lock Box. Please read these instructions carefully before use to ensure proper functionality and security.

The KYODOLED 60-Key Storage Lock Box is designed for organizing and securing up to 60 keys. It features a durable steel construction and a 3-digit combination lock for secure access. Its wall-mountable design makes it suitable for various environments, including homes, offices, and commercial settings.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- KYODOLED 60-Key Storage Lock Box
- 60 Key Rings
- Identification Tags and Key Labels
- Installation Package (3 screws, 3 wall anchors)
- Instruction Manual



Image: The KYODOLED 60-Key Storage Lock Box shown with its included accessories: screws, wall anchors, key tags, and instruction manual.

SETUP

1. Wall Mounting

The key box is designed for secure wall mounting. Follow these steps for installation:

1. Choose a suitable location on a sturdy wall. Ensure the wall material can support the weight of the lock box and its contents.
2. Hold the key box against the wall at the desired height and mark the positions for the mounting holes. Use a level to ensure it is straight.
3. Drill pilot holes at the marked positions using an appropriate drill bit for your wall type.
4. Insert the provided wall anchors into the drilled holes.
5. Align the key box with the anchors and secure it to the wall using the provided screws. Tighten firmly but do not overtighten.




Image: The KYODOLED 60-Key Storage Lock Box securely mounted on a brick wall, demonstrating its intended use in a practical environment.

2. Setting the 3-Digit Combination Lock

The default combination for the lock box is **0-0-0**. To set your personal combination, follow these steps:

1. Step 1: Open the Lock Box

Adjust the dials to the default "0-0-0" position and twist the button to the "unlock" position to open the lock box door.



Image: Close-up of the combination lock showing dials set to 0-0-0 and the unlock button twisted.

2. Step 2: Engage the Reset Mechanism

With the door open, locate the small lever or slot on the inside of the lock mechanism. Use your fingers to move the lock slot from position **A** to position **B**. *Do not push directly from A to B; move it to the side first, then up.*




Image: Internal view of the lock mechanism, highlighting the reset lever moved to position B.

3. Step 3: Set Your New Combination

While the reset mechanism is engaged, set your desired 3-digit code by rolling the dials. For example, "321". Ensure all numbers are centered in the display window.



Image: Close-up of the combination lock dials showing a new code, such as 3-2-1, being set.

4. Step 4: Disengage the Reset Mechanism

Move the lock slot back from position **B** to position **A** to complete the code setting. Your new password is now active. Remember your new combination.



Image: Internal view of the lock mechanism, showing the reset lever returned to its original position A.

To reset the password again: Use the currently set password as the initial password, then repeat steps 1-4.

OPERATING INSTRUCTIONS

Opening and Closing the Lock Box

1. To open, dial your 3-digit combination (default is 0-0-0, or your custom code) and twist the knob to the unlock position.
2. To close, ensure the door is fully shut, scramble the dials to a random combination, and twist the knob to the lock position.

Using Key Hooks and Labels

- Attach individual keys or keychains to the provided key rings.
- Slide the key rings onto the numbered key tags.
- Hang the key tags onto the corresponding hooks inside the lock box for organized storage.
- Use the included key labels to write down information about each key for easy identification.



Image: The KYODOLED 60-Key Storage Lock Box open, displaying keys neatly arranged on numbered hooks with identification tags.

Note: The hooks and depth of the cabinet may not accommodate bulky car keys with remote fobs effectively.

MAINTENANCE

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lock Mechanism:** The combination lock is designed for durability. Avoid forcing the dials or the knob. If the mechanism feels stiff, a small amount of graphite lubricant can be applied, but this is rarely necessary.
- **Regular Checks:** Periodically check the wall mounting screws to ensure they remain tight and secure.

TROUBLESHOOTING

- **Cannot open the lock box:**
 - Ensure the correct 3-digit combination is entered.
 - Verify that the knob is twisted fully to the unlock position.
 - If you forgot your combination, there is no master key or override. You will need to try known combinations or contact customer support for potential solutions, though typically a forgotten combination

cannot be recovered without destructive entry.

- **Dials are stiff or difficult to turn:**
 - Ensure the lock mechanism is clean and free of debris.
 - Apply a small amount of dry lubricant (e.g., graphite powder) to the dials if necessary.
- **Lock box feels loose on the wall:**
 - Check and tighten the mounting screws.
 - If the wall anchors are damaged, consider relocating the lock box or using new anchors suitable for your wall type.

SPECIFICATIONS

Brand	KYODOLED
Model Number	GT-KB-60SM-Black
Color	Black Combination Lock
Product Dimensions	2.5"D x 10.2"W x 12.1"H
Item Weight	4.4 pounds
Material Type	Metal (Heavy-duty steel)
Lock Type	3-digital combination lock
Key Capacity	60 Keys
Mounting Type	Wall Mount



Image: A diagram illustrating the dimensions (depth, width, height) of the KYODOLED 60-Key Storage Lock Box.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official KYODOLED website. Keep your purchase receipt as proof of purchase.

© 2025 KYODOLED. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08L63NQZG>

More documents and user manuals: <https://manuals.plus/>