

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SelfieShow](#) /
- › [Selfie Stick Tripod Instruction Manual](#)

### SelfieShow LDP-K07

# SelfieShow All-in-One Extendable & Portable Selfie Stick Tripod with Wireless Remote

Model: LDP-K07

Brand: SelfieShow

## INTRODUCTION

Thank you for choosing the SelfieShow All-in-One Extendable & Portable Selfie Stick Tripod. This versatile device combines the functionality of a selfie stick and a stable tripod, complete with a detachable wireless remote for convenient photo and video capture. Its compact and lightweight design makes it an ideal companion for travel, group photos, vlogging, and various social activities.



The SelfieShow Selfie Stick Tripod offers multiple modes for capturing photos and videos, including handheld selfie stick, tabletop tripod, and extended tripod.

## SETUP

### Unboxing and Components

Upon unboxing, ensure all components are present:

- Selfie Stick Tripod Unit
- Detachable Wireless Remote Shutter
- USB Charging Cable (for optional light, if included)
- Extra Lithium Metal Battery (for remote)



All essential components are included for immediate use of your selfie stick tripod.

## Pairing the Wireless Remote

The wireless remote uses Bluetooth for connectivity. Follow these steps to pair it with your smartphone:

1. Ensure the remote is charged (if applicable) and has a working battery.
2. Turn on the remote by pressing and holding its power button until an indicator light flashes.
3. On your smartphone, go to Bluetooth settings.
4. Search for new devices. The remote should appear as "SelfieShow" or a similar identifier.
5. Select the device to pair. The indicator light on the remote will typically turn solid or stop flashing once successfully paired.

## OPERATING INSTRUCTIONS

## Extending and Folding the Selfie Stick

The SelfieShow Selfie Stick features a hidden retractable design, making it extremely compact when folded (only 7.6 inches / 19.4 cm). To extend, simply pull the top section upwards. It can extend up to 40.6 inches (103 cm), allowing for a wider field of view for selfies and group photos.

# MULTI-FUNCTION SELFIE STICK



Angle Adjustment



Wireless Remote



Stable Tripod



The multi-function design allows for easy transition between compact storage and extended use.

# PORTABLE DESIGN



**150g / 0.33lb**

Product Weight



**19.4cm / 7.64in**

Storage Length



**103cm  
(40.55in)**

Its portable design ensures it fits easily into a handbag for convenient carrying.

## Using as a Tripod

To convert the unit into a phone stand or tabletop tripod, release the three legs located at the bottom end of the handle. For optimal stability, especially on flat surfaces, it is recommended to keep the extension shorter. This provides a steady, balanced tripod for hands-free selfies, video calls, and recording.



The tripod mode is perfect for capturing stable group photos and videos in various outdoor settings.

### **Adjusting Phone Holder Angle**

The phone holder features a 360° rotatable design and a 235° rotation head. This allows you to freely adjust and find the best photo or video angle, enabling wider camera angles and more diversified compositions. It is suitable for both indoor and outdoor activities, including family gatherings, friends reunions, trips, hiking, and sports.

# ROTARY ADJUSTMENT



Achieve the perfect shot with flexible angle adjustments for both horizontal and vertical orientations.

## Using the Remote Shutter

The detachable remote shutter has an effective distance of up to 10 meters (33 feet). This feature is ideal for capturing photos and videos without relying on a self-timer or asking strangers for assistance. Simply set up your tripod, position your phone, and click the remote to capture the moment.

# DETACHABLE REMOTE



V5.2



can go  
on planes



Replaceable  
Battery




The remote allows for convenient hands-free operation, perfect for capturing distant shots.

## Compatibility

The phone holder is designed to fit most smartphones with a width between 65-95mm. The wireless remote is widely compatible with both iPhone (including iPhone 13 Mini/13/13 Pro/13 Pro Max/12 Pro Max/12 Pro/12/11/XS MAX/XR/XS/X/8/8 Plus series) and Android phones (such as Samsung Galaxy S21/Note 20 series, and most other smartphones).

# WIDELY COMPATIBLE



The universal phone holder and remote ensure broad compatibility with most mobile devices.

## MAINTENANCE

### Cleaning

To maintain the longevity and appearance of your selfie stick tripod, wipe it regularly with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish or internal components.

### Battery Replacement (for remote)

The wireless remote uses a Lithium Metal battery. If the remote's performance degrades or it fails to power on, replace the battery with a new one of the same type. Refer to the remote's compartment for specific battery size and replacement instructions.

## TROUBLESHOOTING

### Remote Not Connecting

- Ensure the remote is powered on and fully charged/has a fresh battery.
- Disable and re-enable Bluetooth on your smartphone.
- Forget the device in your phone's Bluetooth settings and attempt to re-pair.
- Ensure the remote is within the 10m effective range of your smartphone.

### Tripod Stability Issues

- Ensure the tripod legs are fully extended and locked into position on a flat, stable surface.
- For maximum stability, especially with heavier phones, minimize the extension length of the stick when in tripod mode.
- Avoid placing the tripod on uneven or soft surfaces like sand without additional support.

## SPECIFICATIONS

Feature	Detail
Model Number	LDP-K07
Product Dimensions	1.57 x 1.3 x 7.68 inches
Item Weight	5.3 ounces (150 Grams)
Material	Stainless Steel
Maximum Height	40.6 inches (103 Centimeters)
Minimum Height	7.64 Inches
Folded Size	7.6 inches
Weight Limit	2.2 Pounds
Compatible Devices	Most iPhones and Android smartphones (65-95mm width)
Remote Battery Type	1 Lithium Metal battery (included)

## WARRANTY INFORMATION

This SelfieShow product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for any warranty claims. For specific warranty terms and conditions, refer to the product packaging or contact customer support.

## CUSTOMER SUPPORT

For any questions, technical assistance, or support regarding your SelfieShow Selfie Stick Tripod, please visit the official SelfieShow store on Amazon or contact their customer service team through the Amazon platform. You can find the brand store link on the product's Amazon page.

**SelfieShow Brand Store:** [Visit Store](#)