

Manuals.plus /

› SOGO /

› SOGO 3-in-1 Espresso Capsule Machine CAF-SS-5675-R User Manual

## SOGO CAF-SS-5675-R

# SOGO 3-in-1 Espresso Capsule Machine CAF-SS-5675-R User Manual

Model: CAF-SS-5675-R

## 1. INTRODUCTION

---

Thank you for choosing the SOGO 3-in-1 Espresso Capsule Machine, model CAF-SS-5675-R. This versatile coffee machine is designed to provide a rich and aromatic espresso experience using three different systems: Nespresso capsules, Dolce Gusto capsules, and ground coffee. With its compact design, 0.6L water tank, and 1450W power, it ensures quick and efficient brewing. Please read this manual carefully before use to ensure proper operation and maintenance.

## 2. SAFETY INSTRUCTIONS

---

- Read all instructions before operating the appliance.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- This appliance is for household use only. Do not use outdoors.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Always unplug the appliance from the power outlet before cleaning and when not in use.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance out of reach of children.
- Avoid contact with hot surfaces. Use handles or knobs.
- Never open the brewing chamber during operation to avoid scalding.
- Use only cold, fresh water in the water tank.

### 3. PRODUCT OVERVIEW

The SOGO 3-in-1 Espresso Capsule Machine is designed for ease of use and versatility. It features a sleek, compact red and black design, making it suitable for various kitchen spaces.



Image 3.1: Front view of the SOGO 3-in-1 Espresso Capsule Machine, showing a cup of freshly brewed coffee.

The machine comes with interchangeable adapters to accommodate different coffee formats.



Image 3.2: The SOGO espresso machine with its various adapters for Nespresso, Dolce Gusto, and ground coffee.

### 4. SETUP

1. **Unpacking:** Carefully remove the machine and all accessories from the packaging. Retain packaging for future transport or storage.
2. **Initial Cleaning:** Before first use, wash the water tank, drip tray, and all capsule adapters with warm soapy water. Rinse thoroughly and dry.
3. **Positioning:** Place the machine on a stable, flat, heat-resistant surface, away from water sources and heat.
4. **Fill Water Tank:** Remove the water tank from the back of the machine, fill it with fresh, cold water up to the MAX line, and place it back securely.
5. **First Use Cycle (Priming):**
  - Ensure the water tank is filled.
  - Place an empty cup under the coffee outlet.
  - Plug the machine into a grounded power outlet. The power indicator light will illuminate.
  - Press the brew button. Water will flow through the system and into the cup. Repeat this process 2-3 times to clean and prime the machine.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Using Nespresso Compatible Capsules

1. Ensure the Nespresso compatible capsule adapter is inserted into the brewing chamber.
2. Lift the lever, insert a Nespresso compatible capsule into the adapter, and close the lever firmly.
3. Place a cup on the drip tray.
4. Press the desired brew button (e.g., small cup for espresso, large cup for lungo). The machine will start brewing.
5. Once brewing is complete, lift the lever to eject the used capsule into the internal collection bin.

### 5.2. Using Dolce Gusto Compatible Capsules

1. Ensure the Dolce Gusto compatible capsule adapter is inserted into the brewing chamber.
2. Lift the lever, insert a Dolce Gusto compatible capsule into the adapter, and close the lever firmly.
3. Place a cup on the drip tray.
4. Press the brew button. The machine will start brewing.
5. Once brewing is complete, lift the lever to remove the used capsule.

### 5.3. Using Ground Coffee

1. Ensure the ground coffee adapter is inserted into the brewing chamber.
2. Lift the lever, add ground coffee to the filter basket within the adapter (do not overfill or tamp too hard).
3. Close the lever firmly.
4. Place a cup on the drip tray.
5. Press the brew button. The machine will start brewing.
6. Once brewing is complete, lift the lever and carefully remove the ground coffee adapter for cleaning.

## 6. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the lifespan of your coffee machine.

- **Daily Cleaning:**
  - Empty and rinse the drip tray and used capsule container (if applicable) after each use.
  - Wipe the exterior of the machine with a damp cloth.
  - Rinse the water tank daily and refill with fresh water.
- **Capsule Adapters:** After each use, remove and rinse the capsule adapter under running water. Ensure no coffee residue remains.
- **Water Tank:** Clean the water tank weekly with mild detergent and rinse thoroughly.
- **Descaling:** Depending on water hardness and frequency of use, descaling should be performed every 2-3 months. Use a suitable descaling solution designed for coffee machines and follow the product's instructions.
- **Dishwasher Safety: Note:** The machine components are NOT dishwasher safe. Hand wash only.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on	No power supply	Check if the power cord is securely plugged into a working outlet.
No coffee is dispensed	Water tank empty; machine not primed; clogged nozzle	Fill water tank; perform priming cycle; descale the machine.
Coffee is too weak or watery	Incorrect capsule/ground coffee amount; machine needs descaling	Ensure correct capsule type or ground coffee quantity; descale the machine.
Water leaks from machine	Water tank not properly seated; damaged seal	Ensure water tank is correctly positioned; contact customer support if seals are damaged.

## 8. SPECIFICATIONS

- **Model Number:** CAF-SS-5675-R
- **Brand:** SOGO
- **Manufacturer:** SOGO Human Technology
- **Dimensions (L x W x H):** 11 x 26.8 x 26 cm
- **Weight:** 2.67 kg
- **Water Tank Capacity:** 600 Millilitres
- **Power:** 1450 Watts
- **Voltage:** 240 Volts
- **Material:** BPA-free Plastic
- **Operating Mode:** Fully automatic
- **Special Feature:** Compatibility with 3 types of pods (Nespresso, Dolce Gusto, Ground Coffee)
- **Filter Type:** Reusable

- **Control Type:** Buttons
- **Country of Origin:** China

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official SOGO Human Technology website. Keep your proof of purchase for any warranty claims.