

Falk 2046AB

FALK X-Tractor Pedal Tractor with Trailer

Model: 2046AB

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Adult supervision is required at all times when the product is in use.

- **Age Recommendation:** Suitable for children aged 2 to 5 years.
- **Weight Limit:** Maximum user weight is 30 kg (66 lbs).
- **Adult Supervision:** Always ensure an adult is present to supervise the child during play.
- **Assembly:** Assembly must be performed by an adult.
- **Usage Environment:** Use on flat, stable surfaces away from roads, steep inclines, stairs, and swimming pools.
- **Protective Gear:** Consider using protective gear such as a helmet for added safety.



Image 1.1: The Falk X-Tractor highlighting the recommended age of 2+ years and a maximum weight capacity of 30 kg.

2. PRODUCT OVERVIEW

The Falk X-Tractor is a pedal-powered toy tractor designed for young children. It features a functional opening hood and an attachable trailer, encouraging imaginative play and outdoor activity. This product is manufactured in France and contains at least 50% recycled plastic.

Key Features:

- **Pedal-Powered:** Easy for children to operate and develop motor skills.
- **Opening Hood:** Allows access to a simulated engine compartment for interactive play.
- **Detachable Trailer:** For transporting small items like sand, leaves, or toys.
- **Directional Steering Wheel:** Equipped with a horn for realistic play.
- **Durable Construction:** Built to withstand outdoor play.



Image 2.1: A child happily riding the Falk X-Tractor with its attached trailer, demonstrating the product in use.

3. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Falk X-Tractor requires adult supervision and tools (not included). Please follow these general steps. Refer to the detailed assembly manual included in the product packaging for specific instructions and diagrams.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components are present according to the parts list in your manual.
2. **Attach Wheels:** Securely attach the front and rear wheels to the tractor chassis using the provided axles and fasteners. Ensure wheels spin freely but are firmly attached.
3. **Install Steering Column:** Assemble the steering column and attach the steering wheel. Ensure the steering mechanism operates smoothly.
4. **Mount Seat:** Fix the seat onto the tractor body.
5. **Assemble Pedals:** Connect the pedal mechanism to the drive axle. Test the pedal function to ensure smooth rotation.
6. **Assemble Trailer:** If the trailer is not pre-assembled, follow the instructions to put it together.
7. **Attach Trailer:** Connect the trailer to the rear hitch of the tractor.

8. **Final Check:** Before first use, ensure all screws, nuts, and bolts are tightened, and all parts are securely in place.

4. OPERATING INSTRUCTIONS

The Falk X-Tractor is designed for simple and intuitive operation by young children under adult supervision.

4.1 Driving the Tractor

- **Pedaling:** The child sits on the seat and uses their feet to push the pedals in a circular motion to move the tractor forward.
- **Steering:** The steering wheel controls the direction of the front wheels. Turn the wheel left to go left, and right to go right.
- **Horn:** The steering wheel may include a functional horn for added play realism.

4.2 Using the Opening Hood

The tractor features an opening hood for interactive play. To open the hood, gently lift it from the front. To close, push it down until it clicks into place.

4.3 Attaching and Detaching the Trailer

- **Attaching:** Align the trailer hitch with the attachment point at the rear of the tractor. Push the trailer tongue onto the hitch until it is securely connected.
- **Detaching:** To remove the trailer, lift the trailer tongue off the tractor's hitch.



Image 4.1: Visual guide demonstrating the directional steering wheel, the opening hood feature, and the detachable trailer.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your Falk X-Tractor.

- **Cleaning:** Clean the tractor with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all parts for wear, damage, or loose fasteners. Pay close attention to wheels, pedals, steering, and trailer connections.
- **Tighten Fasteners:** If any screws or bolts are loose, tighten them securely. Do not overtighten.
- **Storage:** Store the tractor in a dry, sheltered area when not in use to protect it from weather elements.
- **Recycling:** This toy contains at least 50% recycled plastic. Please consider proper recycling at the end of its life cycle.

6. TROUBLESHOOTING

If you encounter any issues with your Falk X-Tractor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Tractor does not move when pedaled.	Pedal mechanism disconnected or jammed.	Check pedal connections and ensure no debris is obstructing the mechanism.
Steering is stiff or unresponsive.	Steering column loose or obstructed.	Inspect the steering column for loose parts or obstructions. Ensure all connections are secure.
Trailer detaches easily.	Trailer not properly hitched or hitch mechanism worn.	Ensure the trailer is fully engaged with the tractor's hitch. If worn, contact customer support for replacement parts.
Unusual noises during operation.	Loose parts or friction.	Inspect all moving parts and fasteners. Tighten any loose components.

7. SPECIFICATIONS

Detailed specifications for the Falk X-Tractor Pedal Tractor Model 2046AB.

- **Model Number:** 2046AB
- **Brand:** Falk
- **Recommended Age:** 24 months - 10 years (Manufacturer's recommendation)
- **Maximum User Weight:** 30 kg
- **Product Dimensions (L x W x H):** 138 cm x 42 cm x 53 cm (54.3 x 16.5 x 20.9 inches)
- **Item Weight:** 6.3 Kilograms (13.9 lbs)
- **Material:** Plastic, Metal (at least 50% recycled plastic)
- **Country of Origin:** France
- **Assembly Required:** Yes



Image 7.1: The Falk X-Tractor with its key dimensions (length, width, height) clearly indicated.

8. WARRANTY AND SUPPORT

For warranty information, spare parts availability, or customer support, please refer to the documentation included with your product or contact Falk customer service directly. Keep your proof of purchase for any warranty claims.

© 2026 Falk. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question