Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mattel HCK57

Mattel Jurassic World Extreme Chompin' Spinosaurus Dinosaur Action Figure Instruction Manual

Model: HCK57

Introduction

This manual provides essential information for the setup, operation, and maintenance of your Mattel Jurassic World Extreme Chompin' Spinosaurus Dinosaur Action Figure. Please read these instructions carefully to ensure proper use and to maximize your enjoyment of this product.



Image: Jurassic World brand banner.

Safety Information

- Recommended for ages 4 years and up.
- Keep away from small children due to potential choking hazards from small parts.
- Do not submerge the figure in water.
- Adult supervision is recommended during play.

Package Contents

The package includes the following:

- One (1) Jurassic World Extreme Chompin' Spinosaurus Dinosaur Action Figure.



Image: The Jurassic World Extreme Chompin' Spinosaurus figure displayed in its easy-open packaging.

Setup

Your Spinosaurus figure comes ready for action. No assembly is required. Remove the figure from its packaging carefully.

Articulated Joints

The figure features articulated head, arms, legs, and tail. These joints allow for various poses and dynamic play. Gently move each limb to position the dinosaur as desired. The legs are designed to click into different positions for stability.



Image: A side view of the Jurassic World Extreme Chompin' Spinosaurus action figure standing on all fours, showcasing its articulated design.

Operating Instructions

Chomping Action

To activate the Spinosaurus's signature 'Huge Bite' action, locate the push button on the back of its head/neck area. Press this button to open and close the dinosaur's jaw, revealing its large teeth and tongue.



Image: A hand pressing a button on the back of the Spinosaurus's head, demonstrating the mechanism that opens its mouth for the chomping action.



Image: The Jurassic World Extreme Chompin' Spinosaurus figure with its mouth wide open, showcasing its detailed teeth and tongue.

Head Movement

The Spinosaurus's head can also be moved side-to-side and up-and-down, allowing for dynamic posing and interaction during play.



Image: A hand gently manipulating the head of the Spinosaurus figure, illustrating its range of motion for posing.

App Integration (Jurassic World Facts App)

Enhance your play experience by downloading the Jurassic World Facts app (available on Android and iOS devices). This app allows you to scan the DNA code located on the figure to bring your dinosaur to life digitally.

Scanning the DNA Code

1. Download and open the Jurassic World Facts app on your smartphone or tablet.
2. Locate the DNA code on the underside of the Spinosaurus figure's foot.
3. Use the app's scanner feature to scan the code.
4. Once scanned, your Spinosaurus will appear in the app, allowing you to zoom in, hear roars, and learn facts.



Image: A close-up view of the DNA scanner code located on the underside of the Spinosaurus figure's foot, used for app integration.

Maintenance

- **Cleaning:** Wipe the figure with a damp cloth to remove dust and dirt. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent material degradation.

Troubleshooting

Chomping Mechanism Not Working

- Ensure the button on the back of the head is fully depressed.
- Check for any obstructions in the jaw mechanism.

Limb Articulation Issues

- Gently manipulate the joints. Avoid excessive force to prevent damage.

Specifications

Product Dimensions	21.95 x 9.9 x 6.99 inches
Item Weight	1.32 pounds
Item Model Number	HCK57
Manufacturer Recommended Age	4 years and up
Manufacturer	Mattel
Release Date	February 1, 2021

Official Product Videos

View the following videos for demonstrations of the Spinosaurus figure's features and playability:

Jurassic World Extreme Chompin' Spinosaurus Dinosaur Action Figure Overview

Video: An official overview of the Jurassic World Extreme Chompin' Spinosaurus Dinosaur Action Figure, demonstrating its key features and design.

Jurassic World Chompin' Spinosaurus Review

Video: A review showcasing the chomping action and overall play experience of the Jurassic World Spinosaurus figure.

Warranty and Support

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Mattel website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08L9NKT8T

More documents and user manuals: **https://manuals.plus/**