

## AIDITIYMI BN59-01006A

# AIDITIYMI BN59-01006A Replacement Remote Control User Manual

For Samsung Televisions

## 1. INTRODUCTION

Thank you for choosing the AIDITIYMI BN59-01006A Replacement Remote Control. This remote is designed to function as a direct replacement for various Samsung TV models, offering immediate usability without complex setup. This manual provides essential information on its features, installation, operation, and maintenance to ensure optimal performance.

## 2. PRODUCT OVERVIEW

The BN59-01006A is an infrared (IR) replacement remote control, engineered for compatibility with a wide range of Samsung televisions. It features a standard button layout for intuitive control of your TV's functions.



Figure 2.1: Front view of the AIDITIYMI BN59-01006A replacement remote control, showing all buttons and their labels.

### Key Features:

- **Infrared (IR) Technology:** Operates using standard infrared signals.
- **No Setup Required:** Functions immediately upon battery insertion.
- **Direct Replacement:** Designed to replicate the functionality of the original Samsung remote.
- **Ergonomic Design:** Comfortable to hold and use.

## 3. SETUP

To begin using your AIDITIYMI BN59-01006A remote control, you will need to install two AAA alkaline batteries (not included).

### Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Slide the battery cover back into place until it clicks securely.





**Figure 3.1:** Back view of the remote control, illustrating the open battery compartment for AAA battery insertion.

Once batteries are installed, the remote is ready for immediate use with your compatible Samsung TV. No programming or pairing is required.

## 4. OPERATING INSTRUCTIONS

The AIDITIYMI BN59-01006A remote control provides full functionality for your Samsung TV. Point the remote directly at your television's infrared receiver for best performance.



Figure 4.1: Angled view of the remote control, showing the arrangement of various function buttons.

## Common Functions:

- **POWER:** Turns the TV on or off.
- **SOURCE:** Selects input sources (HDMI, AV, Component, etc.).
- **Number Buttons (0-9):** Directly enter channel numbers.
- **VOL (+/-):** Adjusts the volume level.
- **CH (up/down):** Changes channels sequentially.
- **MUTE:** Mutes or unmutes the TV audio.
- **MENU:** Accesses the TV's main menu.
- **Directional Pad (Up/Down/Left/Right) & ENTER:** Navigates menus and confirms selections.
- **RETURN:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or function.
- **INFO:** Displays information about the current program or input.
- **Color Buttons (A, B, C, D):** Used for specific functions within certain TV menus or applications.

## 5. COMPATIBLE MODELS

This replacement remote control is compatible with numerous Samsung TV models. A partial list of known compatible models includes:

- LN32C350D1DXZA, LN26C450E1D, LN32C450E1D, LN19C450E1D, LN22C450E1D, LN32D403E4DXZA
- PN59D530, PN59D530A3F, PN51D530, PN51D530A3F, PN51D530A3, PN51D530A3FXZA
- LN19C350D1D, LN32C350, LN26C350D1DXZA, LN26C350, LN26C350D1D, LN32C350D1D
- LN19C350D1D, LN22C350D1D, LN19C350D1DXZA, LN22C350, LN22C350D1DXZA, LN19C350, LN22C350
- UN40D5003BF, LN32D4003, LN32D5003, LN32D403, LN32D403E4D, UN32D4003BDXZA
- UN40D5003BFXZA, UN22D5003BFXZA, UN26D4003BDXZA, UN32D4005BD, UN40D5005BF
- LN32D403E2DXZA, UN19D4003BD, UN26D4003BD, UN32D4003BD, LN32D403E2D, UN22D5003BF, LN32D405E3D

If your specific Samsung TV model is not listed, but uses the original remote model BN59-01006A, this replacement remote should be compatible.

## 6. MAINTENANCE

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as this can damage internal components.

## 7. TROUBLESHOOTING

If you experience issues with your remote control, try the following steps:

- **Remote Not Responding:**

- Check if the batteries are inserted correctly with the correct polarity (+/-).
- Replace old batteries with new AAA alkaline batteries.
- Ensure there are no obstructions between the remote and the TV's IR receiver.
- Confirm you are pointing the remote directly at the TV.

- **Intermittent Functionality:**

- This could indicate low battery power; replace batteries.
- Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.

- **Specific Buttons Not Working:**

- Clean the remote's surface, especially around the problematic buttons, to remove any dirt or debris.
- If cleaning and battery replacement do not resolve the issue, the remote may be faulty.

## 8. SPECIFICATIONS

|  |   |
|--|---|
| <b>Model Number</b>                    | BN59-01006A                               |
| <b>Power Source</b>                    | 2 x AAA Alkaline Batteries (Not Included) |
| <b>Product Dimensions</b>              | 7 x 2 x 0.6 inches (17.8 x 5.1 x 1.5 cm)  |
| <b>Item Weight</b>                     | 2.46 ounces (70 grams)                    |
| <b>Color</b>                           | Black                                     |
| <b>Compatible Devices</b>              | Samsung Televisions                       |
| <b>Max Number of Supported Devices</b> | 1   |

## 9. SUPPORT

If you have any questions regarding the compatibility or functionality of your AIDITIYMI BN59-01006A replacement remote control, please contact the seller or manufacturer for assistance. Providing your specific TV model number can help expedite support.