

Cecotec 05521

Cecotec Fast&Furious 5055 Pro 2600W Steam Iron User Manual

Model: 05521



Image: Front view of the Cecotec Fast&Furious 5055 Pro steam iron, showcasing its teal water tank, silver accents, and black handle.

1. INTRODUCTION

Thank you for choosing the Cecotec Fast&Furious 5055 Pro 2600W Steam Iron. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.

1.1. Safety Instructions

- Always ensure the iron is unplugged before filling or emptying the water tank, and before cleaning.
- Do not leave the iron unattended while it is switched on or connected to the mains supply.
- Keep the iron and its cord out of reach of children and individuals with reduced physical, sensory, or mental capabilities.
- The iron must be used and rested on a stable, heat-resistant surface.

- Never immerse the iron, cord, or plug in water or any other liquid.
- Do not operate the iron if it has been dropped, if there are visible signs of damage, or if it is leaking. Contact customer support.
- Use only tap water for ironing. Distilled water is recommended in areas with very hard water to prevent limescale buildup.
- The soleplate and steam emitted are very hot and can cause burns. Handle with care.

2. PRODUCT OVERVIEW

The Cecotec Fast&Furious 5055 Pro is a powerful steam iron designed for efficient and effective garment care. It features a ceramic soleplate for smooth gliding and various steam functions.

2.1. Key Features

- **Power:** 2600 Watts for rapid heating.
- **Soleplate:** Ceramic TurboSlide soleplate for optimal glide and even heat distribution.
- **Continuous Steam:** Up to 55 g/min for effective wrinkle removal.
- **Steam Shot:** Powerful 255 g/min steam boost for stubborn creases.
- **Temperature Control:** 5 adjustable temperature levels for different fabric types.
- **Anti-Drip System:** Prevents water stains on garments at low temperatures.
- **Anti-Calc Protection:** Integrated system to reduce limescale buildup.
- **Precision Tip:** Designed for reaching difficult areas like collars and buttons.
- **360° Rotating Cable:** Provides flexibility and ease of movement during ironing.

2.2. Components

Familiarize yourself with the main parts of your iron:

1. Water Spray Nozzle
2. Water Filling Inlet
3. Steam Control Selector
4. Spray Button
5. Steam Shot Button
6. Handle
7. Temperature Control Dial
8. Indicator Light
9. 360° Swivel Cord
10. Ceramic Soleplate with Precision Tip
11. Water Tank



Image: A close-up view of the iron's precision tip, designed to easily navigate around buttons and seams.

3. SETUP

3.1. Before First Use

- Remove any labels, protective film, or packaging from the iron.
- It is normal for a slight odor or smoke to be emitted during the first few minutes of use. This is due to the heating of manufacturing residues and will disappear.
- To clean the soleplate, iron an old damp cloth for a few minutes.

3.2. Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Set the steam control selector to the "Dry Ironing" position (no steam).
3. Open the water filling inlet cover.
4. Using a measuring cup, carefully pour tap water into the water tank up to the "MAX" level indicator. Do not overfill.
5. Close the water filling inlet cover securely.

4. OPERATING INSTRUCTIONS

4.1. Temperature Setting

Select the appropriate temperature for your fabric type using the temperature control dial. Refer to the garment's care label for guidance. The iron features 5 temperature levels.



Image: A close-up of the iron's temperature control dial, showing various fabric settings and the 'MAX' indicator.

- **Low Temperature:** Synthetics, Silk
- **Medium Temperature:** Wool
- **High Temperature:** Cotton, Linen

Plug the iron into a suitable power outlet. The indicator light will illuminate, indicating the iron is heating. Once the desired temperature is reached, the light will turn off. It will cycle on and off during ironing to maintain the temperature.

4.2. Dry Ironing

For dry ironing, ensure the water tank is empty or the steam control selector is set to the "Dry Ironing" position. Select the desired temperature and wait for the indicator light to turn off before beginning.

4.3. Steam Ironing

Steam ironing is effective for most fabrics, especially cotton and linen. Ensure the water tank is filled and the iron is heated to a high temperature (usually 3 dots or higher on the dial). Adjust the steam control selector to the desired steam level. The iron will produce continuous steam up to 55 g/min.



Image: A person is shown ironing a brown garment on an ironing board using the Cecotec steam iron, demonstrating typical use.



Image: A close-up shot of the iron's soleplate emitting steam while gliding over fabric, highlighting its steam function.

4.4. Steam Shot Function

For stubborn wrinkles, press the steam shot button. This releases a powerful burst of steam (255 g/min). Wait a few seconds between shots to allow the iron to reheat and build up steam pressure. This function can also be used for vertical steaming.



Image: A hand is shown pressing the steam shot button on the iron's handle, indicating the activation of the steam burst feature.

4.5. Spray Function

Press the spray button to lightly moisten fabrics, which can help in removing creases, especially during dry ironing.

4.6. Vertical Steaming

The steam shot function can be used for vertical steaming of hanging garments, curtains, or drapes. Hold the iron vertically a few centimeters away from the fabric and press the steam shot button periodically.

5. MAINTENANCE

5.1. Cleaning the Soleplate

- Always unplug the iron and allow it to cool completely before cleaning.
- Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary.
- Do not use metallic or abrasive scouring pads or chemical cleaners, as these can damage the soleplate.

5.2. Anti-Calc System

Your iron is equipped with an anti-calc system to reduce limescale buildup. However, regular maintenance is still recommended, especially in hard water areas.

- To prolong the life of your iron, periodically perform a self-cleaning cycle (refer to specific instructions if available in the product packaging, or generally by filling with water, heating to max, and flushing steam).
- If your iron has a self-clean button, use it as per instructions.

5.3. Storage

- After use, unplug the iron and allow it to cool down completely.
- Empty any remaining water from the tank to prevent limescale and leakage.
- Store the iron upright on its heel rest in a safe, dry place.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet fault; temperature dial set too low; internal fault.	Check power connection and outlet. Increase temperature setting. If problem persists, contact customer support.
No steam or insufficient steam.	Water tank empty; temperature too low; steam control set to dry ironing; soleplate clogged.	Fill water tank. Set temperature to steam-appropriate level (e.g., 3 dots). Adjust steam control. Perform self-cleaning.
Water leaking from soleplate.	Temperature too low for steam; water tank overfilled; anti-drip system malfunction.	Increase temperature. Do not overfill water tank. If leaking persists, contact customer support.
White flakes coming from soleplate.	Limescale buildup.	Perform anti-calc self-cleaning cycle. Use distilled water in hard water areas.

7. SPECIFICATIONS

Feature	Detail
Brand	Cecotec
Model Number	05521

Feature	Detail
Power	2600 Watts
Voltage	260 Volts
Continuous Steam	55 g/min
Steam Shot	255 g/min
Soleplate Material	Ceramic (TurboSlide)
Dimensions (L x W x H)	16.5 x 12.5 x 29.5 cm
Weight	1.1 Kilograms
Special Features	Anti-Drip, Anti-Calc, 360° Swivel Cord, Precision Tip
Energy Class	A to G

8. WARRANTY AND SUPPORT

Cecotec products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. The duration and terms of the warranty may vary by region. Please refer to the warranty card included with your product or visit the official Cecotec website for detailed information.

For technical assistance, spare parts, or warranty claims, please contact Cecotec customer support:


- **Website:** www.cecotec.com
- **Contact Information:** Refer to your product packaging or the official website for regional contact details.






Availability of spare parts: 10 Years (as per product specifications).



© 2025 Cecotec. All rights reserved.
This manual is for informational purposes only. Cecotec reserves the right to make changes to the product without prior notice.

Related Documents - 05521

	<p>Cecotec Fast&Furious 5055 Pro Steam Iron User Manual</p> <p>Comprehensive user manual for the Cecotec Fast&Furious 5055 Pro steam iron, covering safety instructions, parts and components, operation, cleaning, maintenance, technical specifications, and warranty information.</p>
---	--

	<p>Cecotec Iron Professional Steam Station User Manual</p> <p>Comprehensive user manual for the Cecotec Iron Professional Steam Station, covering safety instructions, operation, cleaning, maintenance, and technical specifications.</p>
	<p>Cecotec Fast&Furious 8060 Ultra Steam Generator Iron Manual</p> <p>Comprehensive user manual for the Cecotec Fast&Furious 8060 Ultra steam generator iron, covering safety instructions, operation, cleaning, maintenance, and technical specifications.</p>
	<p>Cecotec Fast&Furious: Інструкція з експлуатації парової станції</p> <p>Посібник користувача для парових станцій Cecotec Fast&Furious 8010 Vital, 8020 Force та 8030 Ultimate. Дізнайтеся про безпечне використання, експлуатацію, очищення та технічні характеристики.</p>
	<p>Cecotec Fast&Furious 9040 Absolute / 9050 X-Treme Steam Station User Manual</p> <p>Comprehensive user manual for the Cecotec Fast&Furious 9040 Absolute and 9050 X-Treme steam stations, covering safety instructions, parts and components, operation, cleaning, maintenance, technical specifications, and warranty information.</p>
	<p>Cecotec FAST&FURIOUS 5050 X-TREME Steam Iron User Manual</p> <p>Comprehensive user manual for the Cecotec FAST&FURIOUS 5050 X-TREME steam iron, covering safety instructions, parts and components, operation, cleaning and maintenance, technical specifications, disposal guidelines, and technical support information.</p>