

Cecotec BreezeCare 3000

Cecotec BreezeCare 3000 Humidifier User Manual

Model: BreezeCare 3000 (05611)

1. INTRODUCTION

Thank you for choosing the Cecotec BreezeCare 3000 Humidifier. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

The BreezeCare 3000 is designed to improve the air quality in your home by maintaining optimal humidity levels. Proper humidity can help alleviate dry eyes, respiratory irritation, and dry skin, contributing to a more comfortable living environment. This model offers a maximum humidification rate of 330 ml/h, totaling up to 8 liters of water per day.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the voltage specified on the appliance matches your local power supply before connecting.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the humidifier before filling, cleaning, or moving it.
- Keep the appliance out of reach of children and pets.
- Place the humidifier on a firm, flat, and water-resistant surface, away from walls and heat sources.
- Do not block the mist outlet or air inlet.
- Use only clean, cool tap water. Distilled or demineralized water is recommended to prevent mineral buildup.
- Do not add essential oils directly into the water tank unless the model specifically supports it with a dedicated aroma tray.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Cecotec BreezeCare 3000 Humidifier.



Figure 1: Front view of the Cecotec BreezeCare 3000 Humidifier, showing the main unit with its digital display and control buttons.

- **Water Tank:** Large 5.5-liter capacity for extended operation.
- **Mist Outlet:** Where the humidified air is released.
- **Control Panel:** Touch-sensitive buttons for power, timer, mist level, and humidity settings.
- **LED Display:** Shows current humidity, selected humidity, and timer settings.
- **Ceramic Filter:** Located within the unit, designed to filter out large particles like limescale and prevent odors.
- **Base Unit:** Contains the ultrasonic transducer and electronic components.



Figure 2: Close-up of the touch control panel and LED display, showing humidity level and function icons.

4. SETUP

1. **Unpack:** Carefully remove the humidifier from its packaging. Retain all packaging materials for future storage or transport.
2. **Placement:** Place the humidifier on a flat, stable, and water-resistant surface at least 15 cm (6 inches)

away from walls and furniture. Ensure it is not placed directly on carpet or near heat sources.

3. Fill Water Tank:



Figure 3: Illustrates the process of filling the humidifier's water tank from the top opening.

Remove the top cover and fill the 5.5-liter water tank with clean, cool tap water. Do not exceed the maximum fill line. Replace the top cover securely.

4. Connect Power:

Plug the power cord into a suitable electrical outlet (240V). The unit will enter standby mode.

5. OPERATING INSTRUCTIONS

The Cecotec BreezeCare 3000 features intuitive touch controls and an LED display for easy operation.

- Power On/Off:** Touch the **Power button** () on the control panel to turn the humidifier on or off. The LED display will illuminate when powered on.
- Adjust Mist Level:** Touch the **Mist Level button** (≡) repeatedly to cycle through different mist output levels (e.g., Low, Medium, High). The selected level will be indicated on the display.
- Set Humidity Level:** Touch the **Humidity Setting button** () to set your desired humidity level, ranging from 30% to 90%. The humidifier will automatically maintain this level, turning on and off as

needed. The current ambient humidity is also displayed.

4. **Set Timer:** Touch the **Timer button** () to set an operating duration. The humidifier will automatically shut off after the set time (e.g., 1 hour, 2 hours, etc.).



Figure 4: The humidifier in operation, visibly emitting a fine mist into the air.

The humidifier can cover an area of up to 30 m² at maximum speed and offers an autonomy of up to 24 hours at minimum speed with a full tank.

6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your humidifier.

- **Daily Maintenance:**

- Empty and rinse the water tank daily.
- Wipe the inside of the tank and the base unit with a clean cloth.

- **Weekly Maintenance:**

- Unplug the unit.
- Remove the water tank and ceramic filter.

- Clean the ceramic filter by rinsing it under running water. If heavily scaled, soak it in a 1:1 solution of white vinegar and water for 30 minutes, then rinse thoroughly.
- Clean the ultrasonic transducer (the small disc in the base unit) with a soft brush and a 1:1 solution of white vinegar and water to remove mineral deposits. Do not scrub aggressively.
- Rinse all components thoroughly with clean water and dry them before reassembling.
- **Storage:** If storing the humidifier for an extended period, ensure all parts are clean and completely dry. Store in a cool, dry place.

Note: Do not use harsh chemicals or abrasive cleaners, as these can damage the humidifier's components.

7. TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and solutions.

Problem	Possible Cause	Solution
No mist or very little mist.	<ul style="list-style-type: none"> • Low water level. • Mineral buildup on the ultrasonic transducer. • Mist outlet blocked. 	<ul style="list-style-type: none"> • Refill the water tank. • Clean the ultrasonic transducer as per maintenance instructions. • Ensure the mist outlet is clear.
Unpleasant odor from mist.	<ul style="list-style-type: none"> • Stagnant water or dirty tank. • Dirty ceramic filter. 	<ul style="list-style-type: none"> • Clean the water tank and refill with fresh water. • Clean or replace the ceramic filter.
Water leakage.	<ul style="list-style-type: none"> • Water tank not properly seated. • Damage to the tank or seals. 	<ul style="list-style-type: none"> • Ensure the water tank is correctly positioned and sealed. • Inspect the tank for cracks or damage. Contact support if damaged.
Unit does not power on.	<ul style="list-style-type: none"> • No power supply. • Power cord not properly connected. 	<ul style="list-style-type: none"> • Check if the power outlet is working. • Ensure the power cord is securely plugged into both the unit and the outlet.

8. SPECIFICATIONS

Feature	Detail
Brand	Cecotec
Model Name	BreezeCare 3000
Model Number	05611
Dimensions (L x W x H)	37 x 25 x 26.5 cm
Weight	1 Kilogram
Water Tank Capacity	5.5 Liters

Feature	Detail
Humidification Rate	330 ml/h (maximum)
Power	30 Watts
Voltage	240 Volts
Material	Plastic
Auto Shut-off Function	Yes
Noise Level	10 dB
Runtime	Up to 24 hours (at minimum speed)
Coverage Area	Up to 30 m ²
Special Features	Timer, Hygrometer, Ceramic Filter, Touch Control, LED Display

9. WARRANTY AND SUPPORT

Cecotec products are manufactured to high-quality standards. In the unlikely event of a defect, please refer to your purchase documentation for warranty terms and conditions.


Spare parts for the Cecotec BreezeCare 3000 Humidifier are available for up to 10 years from the date of purchase.

For further assistance, technical support, or warranty claims, please contact Cecotec customer service through their official website or the retailer where the product was purchased.

© 2025 Cecotec. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - BreezeCare 3000

	<p><u>Cecotec Pure Aroma 150 Yin: Aroma Diffuser & Humidifier Instruction Manual</u></p> <p>Comprehensive instruction manual for the Cecotec Pure Aroma 150 Yin aroma diffuser and humidifier. Learn about setup, operation, cleaning, maintenance, troubleshooting, and technical specifications.</p>
---	--

	<p><u>Manual de Instrucciones Cecotec PureAroma 500 Cordless: Humidificador y Difusor de Aromas</u></p> <p>Descubra cómo usar y mantener su Cecotec PureAroma 500 Cordless, el humidificador y difusor de aromas con 500 ml de depósito y batería. Guía completa de seguridad, funcionamiento y solución de problemas.</p>
	<p><u>Manual de Usuario Motocicleta Eléctrica Cecotec Halo</u></p> <ul style="list-style-type: none"> • Guía completa para la motocicleta eléctrica Cecotec Halo. Aprenda sobre su funcionamiento, seguridad, mantenimiento y especificaciones técnicas para un uso óptimo y seguro.
	<p><u>Cecotec Pure Aroma 300 Yang Aroma Diffuser and Humidifier Instruction Manual</u></p> <p>Comprehensive instruction manual for the Cecotec Pure Aroma 300 Yang aroma diffuser and humidifier. Covers setup, operation, safety, cleaning, troubleshooting, and technical specifications for the 300ml model.</p>
	<p><u>Manual de Usuario Cecotec ReadyWarm 2070 Max Force Black Termoventilador Instrucciones y Especificaciones</u></p> <p>Manual completo del termoventilador Cecotec ReadyWarm 2070 Max Force Black (modelo 08254). Incluye instrucciones de seguridad, funcionamiento, limpieza, mantenimiento y especificaciones técnicas para un uso óptimo y seguro.</p>
	<p><u>Cecotec Cecofry&Grill Smokin' 6500: Руководство пользователя для Цифровой мультипечи с двумя нагревательными элементами и коптильней</u></p> <p>Полное руководство пользователя для Cecotec Cecofry&Grill Smokin' 6500. Инструкции по эксплуатации, безопасности, чистке, уходу и технические характеристики мультипечи с функцией гриля и коптильни.</p>



[\[pdf\] User Manual Instructions Warranty](#)

BREEZECARE 3000 05611 humidificador breezecare manual ic01200703 online i citrus world files |||

BREEZECARE 3000 / /Humidifier Instruction manual 1. 3 2. 7 3. 7 4. 7 5 . . . 13

BREEZECARE 3000 7. : BreezeCare 3000 : 05611 : 220-249 - , 50-60 : 30 : 5,5 8. 2012/19 / eu ...

lang:en **score:48** filesize: 3.28 M page_count: 24 document date: 2021-03-26



[\[pdf\] User Manual Instructions Specifications](#)

BREEZECARE 3000 essere riparato dal Servizio di Assistenza Tecnica ufficiale Cecotec per evitare qualsiasi tipo pericolo Only pour aroma oil into the cotton Do 91twyJsVkal ref dp product quick view m media amazon images | |||

BREEZECARE 3000 Humidificador de agua/ Water humidifier Manual de instrucciones Instruction manual M . . . st bien instalada en la tapa. 6.

ESPECIFICACIONES TCNICAS Referencia del producto: 05611 Producto: BreezeCare 3000 220-240V 50/60 Hz Poder de humidificacin: 30 W Capacidad del deposito de agua: 5.5L ...


lang:it **score:37** filesize: 952.77 K page_count: 49 document date: 2020-07-03



[Cecotec Product Catalogue - February 2022](#)

Explore the comprehensive Cecotec product catalogue for February 2022, featuring a wide range of household appliances including robot vacuum cleaners, kitchen appliances, personal care items, and more. Discover innovative technology and value from Cecotec brands like Conga, Mambo, and Bongo.

lang:en **score:20** filesize: 137.82 M page_count: 1196 document date: 2022-03-07



[\[pdf\] Declaration of Conformity](#)

BreezeCare 3000 Referenz breezecare conformity declaration cdn cecotec cloud media files |||

...

lang:en **score:18** filesize: 2.89 M page_count: 6 document date: 2023-07-21



[Cecotec General Catalog February 2021](#)

Explore the comprehensive Cecotec General Catalog from February 2021, featuring a wide range of home appliances including vacuum cleaners, kitchen robots, coffee makers, and more. Discover innovative technology and quality products designed to enhance everyday living.

lang:es **score:12** filesize: 49.86 M page_count: 886 document date: 2021-03-31