

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iClever](#) /

› **iClever GK08 Wireless Keyboard and Mouse - Ultra Slim Keyboard and Mouse Combo, Full Size Design with Number Pad, 2.4G Stable Connection Slim Keyboard and Mouse for Windows, Mac OS Computer (Black)**

iClever GK08

iClever GK08 Wireless Keyboard and Mouse Combo User Manual

Model: GK08

INTRODUCTION

Thank you for choosing the iClever GK08 Wireless Keyboard and Mouse Combo. This ultra-slim, full-size keyboard and mouse set offers a stable 2.4G wireless connection, a comfortable typing experience, and broad compatibility with Windows and Mac OS computers. This manual provides detailed instructions to help you set up, operate, maintain, and troubleshoot your new device.



Image: The iClever GK08 Wireless Keyboard and Mouse Combo, featuring the full-size black keyboard, a matching black mouse, and the compact USB nano receiver.

WHAT'S IN THE BOX

- iClever GK08 Wireless Keyboard

- iClever Wireless Mouse
- USB-A Nano Receiver (stored under the mouse)
- USB-C Charging Cable
- Washable Dust Cover
- User Manual (this document)



Image: A flat lay showing the iClever GK08 keyboard, mouse, USB-C cable, USB receiver, and user manual, along with the included dust cover.

SETUP

1. Connecting the Receiver

1. Locate the USB-A nano receiver. It is conveniently stored in a compartment under the mouse.
2. Plug the nano receiver into an available USB-A port on your computer.
3. Turn on the keyboard and mouse using their respective power switches. The devices are plug-and-play and should connect automatically within seconds.

Note: A USB-C to USB-A adapter (not included) is required for newer Mac models or other devices with only USB-C ports.

Reliable 2.4 GHz Wireless

Plug-and-play receiver stays stable up to **33 ft**



Image: A close-up view showing the USB-A nano receiver being inserted into a laptop's USB-A port, with the keyboard and mouse in the foreground.

2. Initial Charging

The keyboard and mouse are USB-C rechargeable. For optimal performance, it is recommended to fully charge both devices before first use.

- Connect the included USB-C cable to the charging port on the keyboard and mouse, and then to a USB power source (e.g., computer USB port, USB wall adapter).
- A full charge takes approximately 2 hours and provides up to 45 days of use for both devices.

USB-C Fast Recharge

2-hour charge powers **40 days**
—no AA batteries needed



Keyboard



40
Days

Working
Time

Mouse



20
Days

Image: The iClever keyboard and mouse connected via USB-C cables to a power adapter, illustrating the fast recharge capability.


3. Compatibility

The iClever GK08 combo is designed for dual-layout compatibility, supporting both Mac and Windows operating systems. The keyboard features clearly printed legends for both Mac and PC functions, and automatically recognizes the OS to adapt.

800 / 1200 / 1600 DPI Modes


Smart DPI Switching: Optimize Precision for Every Task

800 DPI




Photoshop ▾

1200 DPI



Excel ▾

1600 DPI



Multi-screen Work ▾

Image: A diagram illustrating compatibility with Windows PCs and USB-A Mac models, including specific iMac and MacBook Air/Pro versions.

OPERATING INSTRUCTIONS

Keyboard Features

- **Full-Size 110-Key Layout:** Includes a dedicated numeric keypad and media shortcuts for enhanced productivity, especially for spreadsheets and coding.
- **Quiet Scissor-Switch Typing:** Low-profile keys produce less than 50 dB of sound, ensuring a quiet working environment.
- **Dual-OS Layout:** Easily switch between Mac and Windows layouts without relearning shortcuts.
- **Automatic Sleep Mode:** The keyboard enters a 10-minute auto-sleep mode to conserve battery life when not in use.



Image: A user typing on the iClever GK08 keyboard, with a graph illustrating the low noise level (under 50dB) compared to other keyboards.

Mouse Features

- **Silent-Click Design:** The mouse features silent clicks to complement the quiet keyboard, minimizing distractions.

- **Adjustable DPI:** Optimize precision for various tasks with 800, 1200, and 1600 DPI modes. The DPI button is located on the top of the mouse for easy switching.



Image: The iClever mouse with illustrations demonstrating its 800, 1200, and 1600 DPI modes for different applications like Photoshop, Excel, and multi-screen work.

MAINTENANCE

Charging

To ensure continuous operation, regularly charge your keyboard and mouse. The devices are designed for long battery life, but charging every few weeks, depending on usage, is recommended.

- Use the provided USB-C cable for charging.
- The keyboard and mouse can be used while charging.

Cleaning

The keyboard comes with a washable dust cover to protect it from spills and dust.

- To clean the keyboard, gently wipe it with a soft, damp cloth.
- The silicone dust cover can be removed and washed with mild soap and water. Ensure it is completely dry before placing it back on the keyboard.

Dustproof Silicone Cover

Guard Against Spills & Dust



Dustproof



Waterproof

Image: The iClever keyboard with its transparent dustproof silicone cover, highlighting its protection against spills and dust.

Storing the Receiver

When not in use or for travel, the USB-A nano receiver can be securely stored in a dedicated slot under the mouse to prevent loss.

TROUBLESHOOTING

If you encounter any issues with your iClever GK08 Wireless Keyboard and Mouse Combo, please refer to the following common solutions:

- **No Connection/Lag:**

- Ensure the nano receiver is securely plugged into a working USB-A port.
- Verify that both the keyboard and mouse are turned on.
- Move the devices closer to the receiver to rule out range issues (max 33 ft / 10 m).
- Try plugging the receiver into a different USB-A port on your computer.
- Recharge the keyboard and mouse to ensure sufficient battery power.

- **Keys Not Responding/Typing Errors:**

- Check for any debris under the keys.
- Ensure the dust cover is properly seated or remove it temporarily to test.
- Restart your computer.

- **Mouse Not Responding/Jumpy Cursor:**

- Ensure the mouse is on a clean, non-reflective surface.
- Try adjusting the DPI setting using the DPI button on the mouse.
- Recharge the mouse.

For more detailed troubleshooting steps and solutions, please refer to the official [Troubleshooting Guide \(PDF\)](#) available online.

SPECIFICATIONS



Image: A detailed diagram showing the dimensions of the iClever GK08 keyboard and mouse, along with a table of key features and descriptions.

Feature	Description
Model Number	GK08

Feature	Description
Brand	iClever
Connectivity Technology	2.4 GHz Wireless via USB-A Nano Receiver
Wireless Range	Up to 33 ft / 10 m
Power Source	Built-in Lithium Battery (USB-C Rechargeable)
Keyboard Layout	Full-size 110-key with Numpad and Media Shortcuts
Typing Noise Level	Below 50 dB (Scissor-Switch)
Mouse DPI Modes	800 / 1200 / 1600 DPI
Compatibility	Windows 10/11 PC & laptop; macOS desktops / notebooks with USB-A port (e.g., iMac Retina 4K/5K, MacBook Air/Pro ≤ 2017)
Product Dimensions (Keyboard)	17.24 x 5.08 x 0.79 inches
Item Weight	1.5 pounds
Color	Black

WARRANTY AND SUPPORT

iClever products are designed for reliability and performance. For any product-related inquiries, technical assistance, or warranty claims, please contact iClever customer support through their official website or the contact information provided with your product packaging.

Additional protection plans may be available for purchase through your retailer to extend coverage beyond the standard warranty period.