



Manuals.plus /

› OMOTON /

› OMOTON T5 Adjustable Tablet Stand User Manual

OMOTON T5

OMOTON T5 Adjustable Tablet Stand User Manual

Model: T5

1. INTRODUCTION

Thank you for choosing the OMOTON T5 Adjustable Tablet Stand. This manual provides essential information for the proper setup, operation, and maintenance of your new tablet stand. Please read these instructions carefully before use and retain them for future reference.



Figure 1: OMOTON T5 Adjustable Tablet Stand

2. PRODUCT FEATURES

- **Weighted & Durable Design:** Features a weighted base and durable aluminum alloy body for enhanced stability and security of your device on any flat surface.
- **Flexible Viewing Angles:** The dual-shaft design allows for easy adjustment to multiple viewing angles, providing optimal positioning for various activities such as watching videos, video calls, gaming, working, or following recipes.
- **All-Round Protection:** Equipped with a soft back pad to prevent scratches on devices and non-slip rubber feet on the base to keep the stand firmly in place on tables, countertops, and nightstands.
- **Wide Compatibility:** Compatible with a broad range of phones and tablets from 4.7 to 13 inches, including various iPad models (Pro, Air, Mini, 10th Gen), Kindle, and iPhone models.
- **Foldable and Portable:** Designed to fold completely flat for convenient portability, allowing it to be easily stored in a backpack or bag.

Never Falling Down



Figure 2: Stable design prevents accidental falls.

Double Rotating Shaft

Making it easier than ever to find a desired angle



Figure 3: Dual rotating shafts for flexible angle adjustment.

Protective Silicone Pads

Quality silicone pads in places to protect your device from scratches and shocks



Figure 4: Protective silicone pads for device safety and stability.

3. PACKAGE CONTENTS

- 1 x OMOTON T5 Adjustable Tablet Stand

4. SETUP AND OPERATION

4.1 Unfolding the Stand

1. Gently pull the top plate upwards from the base.
2. Adjust the two hinged arms to your desired height and angle.

3. Ensure the stand is stable on a flat surface before placing your device.

4.2 Placing Your Device

Place your tablet or phone onto the cradle of the stand. The silicone pads will secure your device and prevent scratches. The open design allows for charging while the device is on the stand.



Figure 5: Stand optimized for device charging.

4.3 Adjusting Viewing Angles

The dual-shaft design allows for precise angle adjustments. Hold the base firmly and gently push or pull the device holder to achieve your preferred viewing angle. The robust hinges will maintain the set position.

For Drawing And Writing



Figure 6: Ideal for drawing and writing with adjustable angles.

4.4 Folding for Portability

To fold the stand, gently push the device holder downwards until the arms are fully collapsed and the stand lies flat. This compact form factor makes it easy to transport.



Figure 7: Stand folds flat for convenient portability.

4.5 Video Demonstrations

Adjustable Tablet Stand Holder OMOTON iPad Stand Holder

Video 1: This video demonstrates the various adjustments and uses of the OMOTON T5 tablet stand, showcasing its flexibility and stability for different devices and scenarios.

Adjustable Tablet or iPad Stand - Is It Cheaply Made?

Video 2: A user review highlighting the build quality and features of the adjustable tablet stand, including its ability to hold various devices securely.

OMOTON Upgraded Adjustable Tablet Stand Holder, Foldable

Video 3: This video provides a detailed look at the OMOTON T5 stand, demonstrating its foldable design and how it can be adjusted for optimal viewing and portability.

5. MAINTENANCE

To ensure the longevity and optimal performance of your OMOTON T5 Adjustable Tablet Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the stand with a soft, damp cloth to remove dust and smudges. Avoid using abrasive cleaners or solvents, as these may damage the finish.
- **Storage:** When not in use, fold the stand flat and store it in a dry, cool place to prevent any potential damage.
- **Inspection:** Periodically check the hinges and rubber pads for any signs of wear or damage. If any components appear compromised, discontinue use and contact customer support.

6. TROUBLESHOOTING

If you encounter any issues with your OMOTON T5 Adjustable Tablet Stand, please refer to the following common troubleshooting tips:

- **Stand feels wobbly:** Ensure the stand is placed on a completely flat and stable surface. Check that the hinges are fully engaged and tightened.
- **Difficulty adjusting angles:** The hinges are designed to be stiff to hold your device securely. Apply firm, even pressure when adjusting. Do not force the hinges beyond their intended range of motion.
- **Device slipping:** Verify that the silicone pads on the cradle and base are clean and free from debris. If pads are worn, contact customer support for assistance.

If these steps do not resolve your issue, please contact OMOTON customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	OMOTON
Model Name	T5
Material	Aluminum
Color	Silver
Item Dimensions (LxWxH)	5.1 x 5.1 x 6.5 inches
Item Weight	395 Grams
Compatible Devices	4.7 - 13 inches tablets and phones (e.g., iPad Pro, Air, Mini, iPhone, Kindle, monitor)
Special Features	Adjustable, Foldable, Hands-Free



Figure 8: Product dimensions.

8. WARRANTY AND SUPPORT

OMOTON products come with a standard manufacturer's warranty. For specific warranty details, product support, or to report any issues, please refer to the contact information provided with your purchase or visit the official OMOTON website. Please have your model number (T5) and purchase information ready when contacting support.