

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [QPLAY](#) /

> [QPLAY Rito+ 3-in-1 Foldable Tricycle QP200.08 Instruction Manual](#)

## QPLAY QP200.08

# QPLAY Rito+ 3-in-1 Foldable Tricycle QP200.08 Instruction Manual

Model: QP200.08 | Brand: QPLAY

## PRODUCT OVERVIEW

The QPLAY Rito+ is an innovative 3-in-1 evolving tricycle designed to adapt to your child's growth from 6 months to 3 years. It features a foldable design for easy storage and transport, and promotes motor skill development and physical activity.

This manual provides essential information for assembly, operation, maintenance, and safety to ensure a safe and enjoyable experience for your child.

## SAFETY WARNINGS

- **Adult Supervision Required:** Always use this product under direct adult supervision.
- **Weight Limit:** Do not exceed the maximum supported weight of 11.3 kg (25 lbs).
- **Age Range:** Suitable for children aged 6 months to 3 years. Ensure the child's age and development stage are appropriate for the current tricycle configuration.
- **Assembly:** Ensure all parts are correctly assembled and securely fastened before each use.
- **Moving Parts:** Keep children's fingers and clothing away from moving parts during adjustment or folding.
- **Hazardous Locations:** Do not use near stairs, swimming pools, steep inclines, or busy roads.
- **Braking:** Always engage the brakes when the tricycle is stationary and the child is inside.

## PARTS LIST

Before assembly, ensure all components are present. Refer to the diagram below for identification.



Figure 1: Fully assembled QPLAY Rito+ Tricycle in parent-push mode, showing the parent handle, adjustable canopy, safety harness, and footrests.

- Main Frame (1)
- Front Wheel Assembly (1)
- Rear Wheel Assemblies (2)
- Seat Unit with Safety Harness (1)
- Parent Push Handle (1)
- Adjustable Canopy (1)
- Footrests (2)
- Pedals (2)
- Assembly Tools (if included)

## SETUP AND ASSEMBLY

---

The QPLAY Rito+ tricycle requires assembly. Follow these steps carefully.

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Frame Setup:** Unfold the main frame until it locks into place. Ensure all locking mechanisms are engaged.
3. **Wheel Installation:** Attach the front wheel assembly and rear wheels according to the instructions provided in the separate assembly guide (if applicable). Ensure wheels are securely fastened and rotate freely.
4. **Seat and Harness:** Install the seat unit onto the frame. Adjust the safety harness to fit your child snugly but comfortably.
5. **Parent Handle:** Insert the parent push handle into its designated slot at the rear of the tricycle and secure it.
6. **Canopy and Footrests:** Attach the adjustable canopy and footrests as needed for your child's age and comfort.
7. **Final Check:** Before first use, double-check all connections, bolts, and locking mechanisms to ensure they are secure.



Figure 2: The QPLAY Rito+ Tricycle in parent-push mode, demonstrating its use with a young child secured in the seat with a canopy for sun protection.

## OPERATING INSTRUCTIONS

The QPLAY Rito+ tricycle evolves with your child. Here are the main operating modes:

## Mode 1: Parent-Push Tricycle (6-18 months)

In this mode, the parent controls the tricycle using the push handle. The child is secured with the safety harness, and their feet rest on the footrests. The canopy provides sun protection.

- Ensure the parent handle is securely locked.
- Engage the safety harness around the child.
- Adjust the canopy for optimal shade.
- Use the footrests for the child's comfort.



Figure 3: A child enjoying the QPLAY Rito+ Tricycle, demonstrating the comfortable seating, safety harness, and protective canopy.

## Mode 2: Training Tricycle (18-24 months)

As your child grows, you can remove the canopy and footrests, allowing them to practice pedaling while still benefiting from the parent push handle for guidance and safety.

- Remove the canopy and fold away or remove the footrests.
- Ensure the pedals are engaged for the child to reach and practice.
- Maintain control with the parent handle.

## Mode 3: Independent Tricycle (24-36 months)

Once your child is confident in pedaling and steering, the parent push handle can be removed, allowing them to ride independently.

- Remove the parent push handle.
- Ensure the child can comfortably reach and operate the pedals and handlebars.
- Always supervise the child during independent use.



Figure 4: The QPLAY Rito+ Tricycle configured for independent riding, showing the handlebars, seat, and pedals without the parent handle or canopy.

## Folding for Storage/Transport

The QPLAY Rito+ features a convenient folding mechanism for compact storage and easy transport.

1. Ensure the child is removed from the tricycle.
2. Follow the specific folding instructions provided in your product's quick start guide or on the frame itself. Typically, this involves releasing safety latches and collapsing the frame.
3. Once folded, ensure all parts are securely latched to prevent accidental unfolding.



Figure 5: The QPLAY Rito+ Tricycle in its compact, folded configuration, ideal for storage or transport.

## MAINTENANCE

- **Cleaning:** Wipe down the frame with a damp cloth and mild soap. Do not use abrasive cleaners. Fabric parts (seat, canopy) can be spot cleaned or hand washed with mild detergent and air-dried.
- **Inspection:** Regularly check all bolts, screws, and locking mechanisms for tightness. Ensure wheels rotate smoothly and brakes function correctly.
- **Storage:** Store the tricycle in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Lubrication:** Moving parts may benefit from occasional lubrication with a silicone-based spray, avoiding contact with fabric or plastic surfaces.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Tricycle does not fold/unfold smoothly.	Locking mechanisms are engaged or obstructed.	Ensure all safety latches are released. Check for any debris obstructing the folding mechanism. Apply light lubricant if necessary.
Wheels are stiff or squeaky.	Dirt/debris in axles or lack of lubrication.	Clean around the wheel axles. Apply a small amount of silicone lubricant to the moving parts of the wheels.
Parent handle feels loose.	Not fully inserted or locking pin/screw is loose.	Re-insert the parent handle firmly until it clicks into place. Tighten any securing screws.

## SPECIFICATIONS

- **Model:** QP200.08

- **Brand:** QPLAY
- **Product Type:** 3-in-1 Foldable Evolving Tricycle
- **Color:** Grey
- **Recommended Age:** 6 months - 3 years (6-36 months)
- **Maximum Supported Weight:** 11.3 kg (25 lbs)
- **Product Dimensions (L x W x H):** 100 x 89 x 49 cm (39.4 x 35 x 19.3 inches)
- **Product Weight:** 10.39 kg (22.9 lbs)
- **Main Material:** Polyester
- **Assembly Required:** Yes
- **Batteries Required:** No

## WARRANTY AND SUPPORT

---

Specific warranty information for the QPLAY Rito+ Tricycle is not provided in the product details. Please refer to the retailer's return policy or contact QPLAY customer service for detailed warranty terms and support.

For assistance with assembly, parts, or any other inquiries, please contact your point of purchase or visit the official QPLAY website for customer support contact details.

- **Return Policy:** Typically 30 days (check with your retailer).
- **Spare Parts:** Information regarding the availability of spare parts is not provided.