

## Groov-e GVTW03BK

# Groov-e Music Buds True Wireless Earphones User Manual

Model: GVTW03BK

## 1. INTRODUCTION

Thank you for choosing Groov-e Music Buds True Wireless Earphones. These earphones are designed to provide a high-quality audio experience with the convenience of wireless connectivity. This manual will guide you through the setup, operation, and maintenance of your new earphones.



Image: Groov-e Music Buds True Wireless Earphones and their charging case.

## 2. PACKAGE CONTENTS

Please check the box for the following items:

- Groov-e Music Buds True Wireless Earphones (Left and Right)
- Portable Charging Case
- USB Charging Cable
- User Manual

### 3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Groov-e Music Buds.



Image: Close-up view of the Groov-e Music Buds, highlighting the charging contacts at the bottom of each earbud.



Image: The Groov-e Music Buds charging case with one earbud removed, showing the charging cradle.

### Earbud Components:

- **Touch Control Area:** For managing music playback, calls, and voice assistant.
- **Microphone:** For hands-free calls and voice assistant commands.
- **Charging Contacts:** Connects with the charging case for power.
- **LED Indicator:** Displays pairing, charging, and battery status.

### Charging Case Components:

- **Earbud Charging Cradles:** Securely holds and charges the earbuds.
- **USB Charging Port:** For connecting the charging cable to power the case.
- **Case LED Indicator:** Shows the charging status of the case.

## 4. SETUP

### 4.1 Charging the Earphones and Case

Before first use, fully charge both the earphones and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective cradles.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The LED indicators on the earbuds and case will show charging status. They will typically turn off or change color when fully charged.

A full charge provides approximately 11 hours of audio playback for the earbuds, with additional charges from the case extending total playback time.



Image: Hands demonstrating the placement of Groov-e Music Buds into their charging case.

### 4.2 Bluetooth Pairing

To connect your Groov-e Music Buds to your device:

1. Open the charging case. The earbuds will automatically enter pairing mode (LED indicators will flash).
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Search for available devices and select "Groov-e Music Buds" from the list.
4. Once connected, the earbud LED indicators will stop flashing or show a solid light. You will hear an audible confirmation.

The earphones will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

## 5. OPERATING INSTRUCTIONS

Your Groov-e Music Buds feature intuitive touch controls.




Image: A man wearing Groov-e Music Buds, illustrating key features such as Bluetooth Connectivity, Wireless Audio Playback, Comfortable Fit, Voice Assistant, and Charging Case Included.

### 5.1 Music Control

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.

### 5.2 Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

### 5.3 Voice Assistant

- **Activate Voice Assistant (Siri/Google Assistant):** Press and hold either earbud for 3 seconds.

## 6. MAINTENANCE

### 6.1 Cleaning

To maintain optimal performance and hygiene:

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or spray cleaners.
- Gently clean the charging contacts on both the earbuds and the case with a dry cotton swab if necessary.

## 6.2 Storage

When not in use, store the earphones in their charging case to protect them and keep them charged.

- Store in a cool, dry place, away from extreme temperatures and direct sunlight.
- Avoid storing in dusty or dirty environments.

## 7. TROUBLESHOOTING

If you encounter issues with your Groov-e Music Buds, try the following solutions:

Problem	Possible Solution
Earbuds not pairing with device	<p>Ensure earbuds are charged.</p> <p>Turn off and on Bluetooth on your device.</p> <p>Forget/remove "Groov-e Music Buds" from your device's Bluetooth list and re-pair.</p> <p>Place earbuds back in the case, close, then reopen to re-enter pairing mode.</p>
No sound or low volume	<p>Check volume levels on both the earbuds (via touch control) and your connected device.</p> <p>Ensure earbuds are properly seated in your ears.</p> <p>Reconnect the earbuds to your device.</p>
Earbuds not charging	<p>Ensure the charging cable is securely connected.</p> <p>Try a different USB port or power adapter.</p> <p>Clean the charging contacts on both earbuds and case.</p> <p>Ensure the charging case itself has power.</p>
Microphone not working	<p>Ensure the earbuds are connected and selected as the audio input device on your phone.</p> <p>Check for any obstructions on the microphone port.</p>

## 8. SPECIFICATIONS

Detailed technical specifications for your Groov-e Music Buds:

Feature	Specification
---------	---------------

Feature	Specification
Model Number	GVTW03BK
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Ear Placement	In-Ear
Form Factor	In-Ear
Material	Plastic
Color	Black
Control Type	Voice Control
Cable Feature	Cable-Free
Water Resistance Level	Not Water Resistant
Frequency Range	20 Hz - 20,000 Hz
Number of Units	2.0 Total
Special Features	Volume Control, Android Phone Control, Lightweight
Compatible Devices	Bluetooth compatible devices (mobile phones, TV, tablets, laptops, game consoles, desktops, smart speakers, phones)
Included Components	Musicbuds True Wireless Earphones; Charging Cable; Charging Case

## 9. WARRANTY AND SUPPORT

Groov-e products are designed and manufactured to the highest standards. For warranty information and customer support, please refer to the warranty card included in your package or visit the official Groov-e website.

Keep your purchase receipt as proof of purchase for any warranty claims.