

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LyxPro](#) /
- › [LyxPro Left Hand 39 Inch Electric Guitar and Starter Kit Instruction Manual \(Model EGLH39BL\)](#)

## LyxPro EGLH39BL

# LyxPro Left Hand 39 Inch Electric Guitar and Starter Kit

INSTRUCTION MANUAL - MODEL EGLH39BL

## INTRODUCTION

---

This manual provides essential information for the setup, operation, and maintenance of your LyxPro Left Hand 39 Inch Electric Guitar and Starter Kit. Please read these instructions carefully before using your new instrument to ensure proper function and longevity.



Figure 1: LyxPro Left Hand 39 Inch Electric Guitar in a studio setting.

## WHAT'S IN THE BOX

Your LyxPro Electric Guitar Starter Kit includes the following components:

- LyxPro Left Hand 39 Inch Electric Guitar
- 20 Watt Amplifier
- Guitar Cable (1/4 inch mono phone plug)
- Digital Clip-On Tuner
- Shoulder Strap
- 2 Guitar Picks
- Extra Set of Steel Strings
- Tremolo Bar
- Allen Wrenches

- Soft Case (Gig Bag)

## COMPLETE ALL-IN-ONE FULL GUITAR KIT

- CARRY BAG
- SHOULDER STRAP
- 20 W AMP
- PICKS
- DIGITAL TUNER
- GUITAR CABLE
- TREMOLO BAR
- EXTRA STRINGS
- ALLEN WRENCHES



Figure 2: All components included in the LyxPro Electric Guitar Starter Kit.

### PRODUCT OVERVIEW

#### Electric Guitar

- **Size:** 39 inches, full size, left-handed orientation.
- **Body Material:** Wood (Phoenix wood back).
- **Neck Material:** Maple.
- **Fretboard Material:** Maple Wood.
- **Number of Strings:** 6 (nickle steel).
- **Pickup Configuration:** S-S-S (Single-Single-Single).
- **Bridge System:** Tremolo.
- **Controls:** Volume/Tone knobs.



Figure 3: Overview of the LyxPro Left Hand Electric Guitar's dimensions and key components.

### 20 Watt Amplifier

- **Output Wattage:** 20 Watts.
- **Speaker Count:** 1.
- **Controls:** Gain, Bass, Treble, Volume, Grind.
- **Inputs/Outputs:** Instrument Input, AUX Input (for phone/MP3 player), Headphone Jack.

# COMES COMPLETE WITH A 20W AMP



Figure 4: Detailed view of the LyxPro 20 Watt Amplifier controls.

## SETUP

### 1. Attaching the Strap

Attach the guitar strap to the strap buttons located on the body of the guitar. Ensure it is securely fastened before playing.

### 2. Connecting the Amplifier

1. Ensure the amplifier is turned off and its volume is set to minimum.
2. Connect one end of the guitar cable to the input jack on your electric guitar.
3. Connect the other end of the guitar cable to the 'Input' jack on the 20 Watt Amplifier.
4. Plug the amplifier's power cord into a suitable electrical outlet.
5. Turn on the amplifier using the 'Power' switch.

### 3. Tuning the Guitar

Use the included digital clip-on tuner to accurately tune your guitar. Attach the tuner to the headstock of the guitar.



Figure 5: Digital clip-on tuner for accurate guitar tuning.

1. Pluck each string individually. The tuner will display the note being played.
2. Adjust the tuning pegs on the headstock until the tuner indicates the correct pitch for each string (E, A, D, G, B, E from thickest to thinnest).

## OPERATING

### Playing the Guitar

1. Once the guitar is tuned and connected to the amplifier, slowly increase the amplifier's 'Volume' knob to your desired level.
2. Experiment with the 'Gain', 'Bass', 'Treble', and 'Grind' knobs on the amplifier to shape your sound.
3. Use the guitar's 'Volume' and 'Tone' knobs to further adjust the output and tonal characteristics directly from the instrument.

- The S-S-S pickup configuration allows for versatile tonal options. Use the pickup selector switch to choose between individual pickups or combinations.
- The tremolo bar can be used to create vibrato effects by gently pushing or pulling it.

### Using the AUX Input and Headphone Jack

- To play along with music, connect your phone or MP3 player to the 'AUX Input' jack on the amplifier.
- For silent practice, plug headphones into the 'Phone' jack on the amplifier. This will mute the main speaker.

## MAINTENANCE

---

- Cleaning:** Wipe down the guitar body and neck with a soft, dry cloth after each use to remove sweat and grime.
- String Replacement:** Replace strings regularly, especially if they sound dull or show signs of wear. Use the included extra set of steel strings or suitable replacements.
- Storage:** Store the guitar in its soft case when not in use to protect it from dust, scratches, and environmental changes. Avoid extreme temperatures and humidity.
- Tuning Stability:** Regularly check and adjust the tuning. New strings may require more frequent tuning until they settle.

## TROUBLESHOOTING

---

- No Sound:**
  - Ensure the amplifier is powered on and plugged in.
  - Check that the guitar cable is securely connected to both the guitar and the amplifier.
  - Verify the guitar's volume knob is turned up.
  - If using headphones, ensure they are fully plugged into the 'Phone' jack.
- Buzzing/Humming:**
  - Check for loose cable connections.
  - Ensure proper grounding of the amplifier.
  - Try a different power outlet.
- Poor Tuning Stability:**
  - New strings stretch and require frequent tuning.
  - Ensure strings are properly wound around the tuning pegs.
  - Check for worn strings that may need replacement.

## SPECIFICATIONS

---

Item Weight	1.1 ounces
Product Dimensions	11.6 x 4 x 39 inches
Model Number	EGLH39BL
Hand Orientation	Left
Body Material	Wood (Phoenix wood back)

<b>Neck Material Type</b>	Maple
<b>Fretboard Material Type</b>	Maple Wood
<b>Number of Strings</b>	6
<b>String Material Type</b>	Nickle Steel
<b>Guitar Pickup Configuration</b>	S-S-S
<b>Output Wattage (Amplifier)</b>	20 Watts

## WARRANTY & SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your product or visit the official LyxPro website. Keep your purchase receipt as proof of purchase for any warranty claims.

Additional protection plans may be available for purchase. Please check with your retailer for details.