

- Manuals.plus /
- › ReplacementScrews /
 - › ReplacementScrews Wall Mount Screw Kit for LG 50UN6950ZUF TV

ReplacementScrews 50UN6950ZUF

ReplacementScrews Wall Mount Screw Kit Instruction Manual

Model: 50UN6950ZUF
Brand: ReplacementScrews

1. PRODUCT OVERVIEW

This ReplacementScrews wall mount screw kit is designed for securely mounting your LG 50UN6950ZUF television. The kit provides the necessary hardware to attach your TV to a VESA-compatible wall mount.

The kit includes four M6 x 25mm machine screws, flat washers, split lock washers, and eight nylon spacers. These components ensure a secure fit and offer flexibility for various wall mount designs, including providing space for cables if needed.

The screws feature a black oxide plating for corrosion resistance and a discreet appearance that blends with most TV and mount components. The split lock washers are included to maintain pressure and prevent screws from loosening due to vibrations.



Image 1.1: Complete set of wall mount screws, washers, and spacers.

2. SETUP AND INSTALLATION

Before beginning installation, ensure you have a VESA-compatible wall mount (not included) and consult your LG 50UN6950ZUF TV's instruction manual for specific VESA mounting hole locations and any additional requirements.

2.1. Kit Contents

- 4 x M6 x 25mm Machine Screws (Black Oxide Plated)
- 4 x Flat Washers
- 4 x Split Lock Washers
- 8 x Nylon Spacers (for optional use)



Image 2.1: Individual components of the screw kit.

2.2. Installation Steps

1. **Prepare the TV:** Carefully place your LG 50UN6950ZUF TV face down on a soft, clean surface to protect the screen. Locate the four VESA mounting holes on the back of the TV.
2. **Assemble the Screw:** For each mounting point, slide one flat washer onto an M6 screw, followed by one split lock washer.
3. **Add Spacers (Optional):** If your wall mount or TV design requires additional clearance, or if you need space for cables, place one or two nylon spacers onto the screw after the washers. Refer to your wall mount's instructions for guidance on spacer use.
4. **Attach to Mount:** Align the TV with your VESA-compatible wall mount. Insert the assembled screws through the wall mount's bracket holes and into the TV's mounting holes.
5. **Secure the Connection:** Using a Phillips head screwdriver, carefully tighten each screw. Ensure the screws are snug, but do not overtighten, as this can damage the TV or the screws. The split lock washers will help maintain a secure connection.

6. **Final Check:** Once all screws are tightened, gently test the stability of the TV on the mount before releasing it. Ensure there is no wobble or looseness.



Image 2.2: Screws with optional spacers and washers assembled.

3. OPERATING AND USAGE

Once installed, the screw kit functions to securely hold your LG 50UN6950ZUF TV to its wall mount. Proper installation ensures the TV remains stable.

It is recommended to periodically check the tightness of the mounting screws, especially after initial installation and any significant movement or adjustment of the TV or mount. This helps ensure continued security and prevents potential loosening over time.

4. MAINTENANCE

The screws are designed for durability and corrosion resistance due to their black oxide plating. No specific maintenance is typically required for the screws themselves.

- Keep the screws clean and free from dust or debris.
- Inspect the screws and washers for any signs of damage, wear, or corrosion during periodic checks of your TV mount. Replace any damaged components immediately.

5. TROUBLESHOOTING

- **Screws do not fit:** Ensure you are using the correct M6 x 25mm screws for your LG 50UN6950ZUF TV and wall mount. Always consult your TV and wall mount manuals for exact specifications.
- **TV feels loose after installation:** Carefully re-tighten all four screws. Ensure flat washers and split lock washers are correctly positioned. Do not overtighten. If the issue persists, verify the wall mount itself is securely fastened to the wall.
- **Insufficient clearance for cables:** Utilize the included nylon spacers to create additional space between the TV and the wall mount.

6. SPECIFICATIONS

Feature	Detail
Model Compatibility	LG 50UN6950ZUF (50UN6950ZUF.AUS)
Screw Size	M6 x 25mm
Thread Size	M6
Material	Metal (Stainless Steel)
Exterior Finish	Black Oxide
Head Style	Flat (Phillips or Flat/Slotted Drive)
VESA Compatibility	M6 VESA mounting pattern
Number of Screws	4
Number of Spacers	8 (Nylon)
Item Weight	1.92 Ounces

7. WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. Please refer to the seller or manufacturer's official website for any applicable warranty policies.

8. SUPPORT

For further assistance or inquiries regarding your ReplacementScrews product, please contact the manufacturer directly or visit their official store page.

Manufacturer: ReplacementScrews
Online Store: [ReplacementScrews Amazon Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08LGG5GQB>

More documents and user manuals: **<https://manuals.plus/>**