

[Manuals.plus](#) /

› [Lumisky](#) /

› Lumisky Beverly White H34CM Wireless LED Table Lamp User Manual

Lumisky BEVERLY WHITE

Lumisky Beverly White H34CM Wireless LED Table Lamp

User Manual

Model: BEVERLY WHITE | Brand: Lumisky

1. INTRODUCTION

The Lumisky Beverly White is a versatile wireless LED table lamp designed for both indoor and outdoor use. It features a warm white LED light with variable intensity, offering up to 5 hours of illumination on a full charge. Its elegant and modern design makes it suitable for various settings, from a bedside lamp to a decorative light for terraces.

Please read this manual carefully before using the product to ensure proper operation and longevity.



Image 1.1: The Lumisky Beverly White lamp providing ambient light on an outdoor table.

2. PACKAGE CONTENTS

Ensure all items are present and in good condition upon unpacking:

- 1 x Lumisky Beverly White LED Table Lamp (integrated LED unit)
- 1 x USB Charging Cable

3. PRODUCT OVERVIEW

The Beverly White lamp consists of a white plastic base, a white stem, and a translucent plastic lampshade housing the integrated warm white LED light source. The control interface is a touch-sensitive area located on the lamp.



Image 3.1: The Lumisky Beverly White lamp in daylight, showcasing its design.

4. SETUP

4.1 Initial Charging

1. Locate the USB charging port on the lamp.
2. Connect the provided USB charging cable to the lamp's port.
3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a powered USB port.
4. Allow approximately 4 hours for the lamp to fully charge. The charging indicator (if present) will change or turn off once charging is complete.

The lamp is ready for use once fully charged. It can be used while charging, but for optimal battery life, it is recommended to fully charge before first use.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Brightness Adjustment

The Beverly White lamp features a touch-sensitive control for operation.

1. **To Turn On:** Lightly touch the designated touch control area on the lamp. The lamp will illuminate at its lowest brightness setting.
2. **To Adjust Brightness:** Continue to lightly touch the control area. Each subsequent touch will cycle through the 4

available brightness levels (variable intensity).

3. **To Turn Off:** After cycling through all brightness levels, the next touch will turn the lamp off.

The lamp provides a warm white light suitable for various ambient lighting needs.



Image 5.1: The Lumisky Beverly White lamp providing light in an indoor setting.

6. MAINTENANCE

6.1 Cleaning

- Ensure the lamp is turned off and disconnected from the charging cable before cleaning.
- Wipe the lamp's surface with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or plastic components.
- Avoid submerging the lamp in water, despite its splash-resistant rating.

6.2 Storage

If storing the lamp for an extended period, ensure it is fully charged and store it in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

- **Lamp does not turn on:**
 - Ensure the lamp is fully charged. Connect it to the USB cable and charge for 4 hours.
 - Verify that the touch control area is being pressed correctly.
- **Lamp does not hold a charge:**
 - Check the USB cable for damage and ensure it is securely connected.
 - Try a different USB power adapter or port.
 - Battery life may degrade over time with extensive use.
- **Brightness adjustment is not working:**
 - Ensure you are lightly tapping the touch control area repeatedly to cycle through settings.

8. SPECIFICATIONS

Model Number	BEVERLY WHITE
Dimensions (DxWxH)	13 x 13 x 34 cm
Total Height	34 cm
Material	Plastic (Base, Lampshade)
Color	White
Light Source	Integrated LED (Warm White)
Luminous Flux	Over 100 Lumens
Intensity Levels	4 (Variable)
Power Source	Rechargeable Battery
Charging Time	Approx. 4 hours (via USB)
Operating Autonomy	Up to 5 hours
Control Method	Touch
Water Resistance	Splash-resistant (IP44)
UV Resistance	Yes
EU Energy Efficiency Label	A
GTIN	03760093546539



Image 8.1: The Lumisky Beverly White lamp integrated into an outdoor dining setup.



Image 8.2: EU Energy Efficiency Label for Lumisky Beverly White. For more details, visit eprel.ec.europa.eu/qr/2302922.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact Lumisky customer service directly. Keep your proof of purchase for any warranty claims.

© 2024 Lumisky. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question