

Itel it2173

Itel it2173 Mobile Phone User Manual

Model: it2173

INTRODUCTION

This user manual provides detailed instructions for the safe and efficient operation of your Itel it2173 mobile phone. Please read this manual thoroughly before using your device to ensure proper functionality and to avoid any damage.

WHAT'S IN THE BOX

Upon opening the package, please verify that all the following items are included:

- Mobile phone x 1
- Charger x 1
- User manual x 1
- Warranty card x 1
- Battery x 1

PRODUCT OVERVIEW


The Itel it2173 is a compact and user-friendly feature phone designed for essential communication and convenience. It features a 4.5cm (1.8 inch) display, a 1000mAh battery, and supports dual SIM functionality.



Image: Front view of the ITEL it2173 mobile phone, showing the display, keypad, and navigation buttons.



KingVoice



Function Shortcut
Keys



8 Indian languages
Support for Input



2000 Contacts
(with Photo)



Rear Camera



it2173



Wireless FM
with Recording



Big LED Torch



4.5cm(1.8)
QVGA Display



Vibration Mode



REPLACEMENT
100
DAYS
WITHIN
12 MONTHS
WARRANTY

Image: Overview of the Itel it2173 mobile phone highlighting key features such as KingVoice, Function Shortcut Keys, 8 Indian languages support, 2000 contacts, Rear Camera, Wireless FM with Recording, Big LED Torch, 4.5cm (1.8) QVGA Display, Vibration Mode, and 100 days replacement warranty.




Image: Rear view of the ITEL it2173 mobile phone, showing the camera module and textured back cover.

Key Features:

- 1.8 inch QVGA Display
- Kingvoice feature for voice assistance
- Dedicated Function keys
- 1000mAh Battery for extended standby time
- Support for 8 Indian input languages
- Dual SIM capability
- Expandable Memory
- Rear Camera
- Wireless FM with recording
- Big LED Torch
- Vibration Mode Support
- Auto Call Recorder

SETUP

1. Battery Installation

1. Remove the back cover of the phone by gently prying it open from the notch.
2. Align the battery contacts with the terminals inside the battery compartment.
3. Insert the battery firmly into place.
4. Replace the back cover, ensuring it clicks securely.

2. SIM Card Installation

1. With the back cover and battery removed, locate the SIM card slots. The Itel it2173 supports dual SIM cards.
2. Carefully insert your SIM card(s) into the designated slot(s) with the gold contacts facing down, following the orientation indicated on the phone.
3. Ensure the SIM card is fully seated.

3. Memory Card Installation (Optional)

1. Locate the memory card slot, usually adjacent to the SIM card slots.
2. Insert a microSD card into the slot until it clicks into place.

4. Charging the Device

1. Connect the charger to the charging port on your phone.
2. Plug the charger into a power outlet.
3. The battery indicator on the screen will show the charging status.
4. Once fully charged, disconnect the charger.

OPERATING INSTRUCTIONS

1. Power On/Off

- **To Power On:** Press and hold the Power/End Call key until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call key until the power off options appear, then select "Power off".

2. Basic Navigation

- Use the navigation keys (Up, Down, Left, Right) to move through menus.
- Press the Center/OK key to select an option.
- Press the Left Soft key to access options or confirm.
- Press the Right Soft key to go back or cancel.

3. Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the Call key (green button).
- **Receiving a Call:** When a call comes in, press the Call key (green button) to answer. Press the End Call key (red button) to reject or end a call.

4. Messaging

- Navigate to the "Messages" menu.
- Select "Write message" to compose a new SMS.
- Enter the recipient's number and type your message using the keypad.
- Press the "Send" option.

5. Kingvoice Feature

The Kingvoice feature provides voice assistance for various functions. To activate or use Kingvoice, refer to the specific menu option in your phone's settings or dedicated Kingvoice shortcut, if available.

6. Wireless FM

The phone supports Wireless FM radio. To use it, navigate to the FM Radio application in the multimedia menu. You do not need to connect headphones to listen to the radio.

7. Torch Light

To activate the built-in LED torch light, typically press and hold a dedicated key (often the center navigation key or a specific number key) or find the torch option in the tools menu.

8. Camera Usage

The phone is equipped with a rear camera. To take photos:

1. Go to the "Camera" application from the main menu.
2. Frame your shot using the display.
3. Press the Center/OK key or a dedicated camera button to capture the image.

9. Language Settings

To change the input or display language, navigate to "Settings" > "Phone settings" > "Language". The phone supports 8 Indian input languages.

MAINTENANCE

1. Cleaning Your Device

- Use a soft, dry cloth to clean the phone's surface.
- Avoid using liquid cleaners or aerosols, as they may damage the device.

2. Battery Care

- Do not expose the battery to extreme temperatures.
- Avoid overcharging the battery; disconnect the charger once the battery is full.
- If the phone will not be used for an extended period, charge the battery to about 50% before storing it.

3. Storage

- Store the phone in a cool, dry place away from direct sunlight and moisture.
- Keep the phone away from magnetic fields.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Phone does not power on	Low battery; Battery not installed correctly	Charge the battery; Reinstall the battery
Cannot make/receive calls	No network signal; SIM card not installed correctly; SIM card expired	Move to an area with better signal; Reinstall SIM card; Contact your service provider
Poor call quality	Weak signal; Obstructions	Move to an open area; Avoid using in basements or elevators
Battery drains quickly	Frequent usage; Old battery	Reduce usage; Consider replacing battery if old

SPECIFICATIONS

Feature	Detail
Model Number	it2173
Operating System	ThreadX
Display Size	4.5cm (1.8 inch)
Battery Capacity	1000 mAh Lithium Polymer
RAM	32 GB (Note: This typically refers to maximum expandable memory support, not internal RAM.)
Internal Memory	4 MB
Product Dimensions	11.9 x 5.1 x 1.4 cm
Item Weight	77 g
Wireless Communication	Cellular
Connectivity Technologies	USB (Note: While "WiFi USB" is listed, WiFi connectivity is uncommon for basic feature phones. USB is for charging/data transfer.)
Special Features	Dual SIM, Expandable Memory, Camera
Audio Jack	3.5 mm
Colour	Deep Blue

Feature	Detail
Phone Standby Time	177 Hours

WARRANTY AND SUPPORT

The Itel it2173 comes with a 100-day replacement warranty. For any issues or support, please refer to the warranty card included in your package or contact Itel customer service.
Manufacturer: S MOBILE DEVICES PRIVATE LTD