

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Philips Sonicare](#) /
- › [Philips Sonicare Power Flosser & Toothbrush System 7000 \(HX3921/40\) User Manual](#)

Philips Sonicare HX3921/40

Philips Sonicare Power Flosser & Toothbrush System 7000 (HX3921/40) User Manual

Brand: Philips Sonicare

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Philips Sonicare Power Flosser & Toothbrush System 7000. This system combines the Power Flosser with Quad Stream technology and the ExpertClean 7300 electric toothbrush for comprehensive oral care.



Image: The complete Philips Sonicare Power Flosser and Toothbrush System 7000, including the flosser unit, electric toothbrush, and accessories.

IMPORTANT SAFETY INFORMATION

This product is battery-powered. Keep it away from children and water. Consult with healthcare professionals for use if you have certain medical conditions. Always use the product according to the provided instructions for proper handling and maintenance.

PACKAGE CONTENTS

- Philips Sonicare Power Flosser 7000 unit
- Philips Sonicare ExpertClean 7300 Toothbrush
- Quad Stream nozzle (F3)
- Standard nozzle (F1)
- Comfort nozzle (F2)
- Nozzle storage case
- Brush head
- Travel case for toothbrush
- Charger
- User Manual

Video: An official overview of the Philips Sonicare Power Flosser & Toothbrush System 7000, showcasing its features and components.

SETUP

Initial Setup

1. Unpack all components from the box.
2. Place the Power Flosser unit on a stable, flat surface near an electrical outlet.
3. Fill the Power Flosser reservoir with water. Open the hinged lid and pour lukewarm water into the reservoir up to the MAX line. Close the lid.
4. Attach the desired nozzle (e.g., Quad Stream nozzle) to the Power Flosser handle.
5. Plug the Power Flosser into a power outlet.
6. Attach the brush head to the ExpertClean 7300 toothbrush handle.
7. Place the toothbrush on its charging dock to ensure it is fully charged before first use.

Larger reservoir



Image: A hand filling the large, clear reservoir of the Philips Sonicare Power Flosser with water.

Toothbrush, travel case, charger



Image: The Philips Sonicare ExpertClean 7300 electric toothbrush, its travel case, and charger, ready for use.

OPERATING THE POWER FLOSSER

Modes and Intensities

The Power Flosser offers 4 flossing modes and 10 intensity settings:

- **Clean Mode:** Standard cleaning.
- **Deep Clean Mode:** For a more intensive clean.
- **Sensitive Mode:** Gentle cleaning for sensitive gums.
- **Gum Care Mode:** Massages gums.

Adjust the intensity using the dial on the unit (settings 1-10).



Image: A close-up of the Power Flosser's control panel, highlighting the power button, mode selection, and intensity dial with settings from 1 to 10.

Quad Stream Technology

The unique Quad Stream nozzle creates an X-shaped stream of water that covers a larger surface area, reaching deep between teeth and along the gum line.

Innovative new **Quad Stream technology**





Image: A detailed view of the innovative Quad Stream nozzle in action, demonstrating its X-shaped water spray pattern for enhanced cleaning.

Pulse Wave Technology

Gentle pulses of water guide you from tooth to tooth, ensuring thorough coverage.

Up to **180% more effective** for healthier gums than floss*



*when used with Quad Stream nozzle on setting 8 with a manual toothbrush in patients with moderate to severe gingivitis vs. using manual toothbrush with string floss

Image: A visual representation of the Pulse Wave feature, showing arrows indicating how the flosser gently guides users from one tooth to the next.

Flossing Procedure

1. Direct the X-shaped stream of water between teeth.
2. Move the Power Flosser along the gum line, allowing the Pulse Wave technology to guide you from tooth to tooth.
3. Ensure the nozzle is positioned at a 90-degree angle to the gum line.

OPERATING THE ELECTRIC TOOTHBRUSH

Modes

The ExpertClean 7300 offers various brushing modes for different needs:

- **Clean:** For daily cleaning.
- **White:** For surface stain removal.
- **Gum Care:** Gently massages gums.
- **Deep Clean+:** For an invigorating deep clean.

Brushing Procedure

Apply a small amount of toothpaste to the brush head. Place the brush head against your teeth at a slight angle towards the gum line. Press the power button to start. Gently glide the brush across your teeth, allowing the sonic vibrations to clean. The toothbrush will pause to indicate when to move to the next section of your mouth.

MAINTENANCE

Power Flosser

After each use, empty any remaining water from the reservoir. The reservoir can be removed for easy cleaning. Wipe the unit and handle with a damp cloth.

Toothbrush

Rinse the brush head and handle after each use. Store the brush head in the provided nozzle storage case. Store the toothbrush in a dry place. Replace brush heads every 3 months or sooner if bristles are frayed.





Image: A clear plastic case designed to store multiple Philips Sonicare flosser nozzles, keeping them clean and organized.

TROUBLESHOOTING

Common Issues

- **No water flow:** Ensure the reservoir is filled and the nozzle is correctly attached. Check for any blockages in the nozzle.
- **Weak water pressure:** Adjust the intensity dial to a higher setting.
- **Toothbrush not charging:** Ensure the charger is properly connected to the power outlet and the toothbrush is correctly placed on the charging base.
- **Unusual noise:** If the device makes unusual noises, discontinue use and contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	8.62 x 7.48 x 10.43 inches; 3.27 Pounds
Item Model Number	HX3921/40
Brand	Philips Sonicare
Power Source	Battery Powered

Special Feature	Bluetooth Connectivity
Unit Count	1 Count
Flossing Modes	4 (Clean, Deep Clean, Sensitive, Gum Care)
Flossing Intensities	10
Water Flosser Technology	Quad Stream, Pulse Wave
Toothbrush Modes	Clean, White, Gum Care, Deep Clean+

WARRANTY AND SUPPORT

Warranty Information



Philips Sonicare products typically come with a manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Philips Sonicare website for detailed warranty terms and conditions.





Customer Support

For further assistance, product registration, or to purchase replacement parts, please visit the official Philips Sonicare website or contact their customer service.

© 2023 Philips Sonicare. All rights reserved.

Related Documents - HX3921/40

 <p>PHILIPS sonicare Philips Sonicare Power Flosser 7000 - często zadawane pytania</p> <p>Technologia</p> <p>Nowa generacja Philips Sonicare Power Flosser 7000</p> <p>Philips Sonicare Power Flosser 7000 to innowacyjny urządzenie do higieny jamy ustnej, które łączy w sobie funkcje flossingu i czyszczenia zębów. Dzięki swojej unikalnej technologii Quad Stream i Pulse Wave skutecznie usuwa zębinoskale, bakterie i resztki pokarmu z trudno dostępnych miejsc międzyzębowych i wokół dziąseł. Dzięki 4 trybom flossingu i 10 intensywnościom możesz dostosować poziom czyszczenia do swoich potrzeb. Philips Sonicare Power Flosser 7000 to idealne rozwiązanie dla osób, które chcą osiągnąć maksymalną higienę jamy ustnej i cieszyć się zdrowym uśmiechem.</p>	<p>Philips Sonicare Power Flosser 7000: Frequently Asked Questions and Guide</p> <p>Comprehensive FAQ and guide for the Philips Sonicare Power Flosser 7000, covering technology, usage, safety, cleaning, and model comparisons. Learn how this oral irrigator enhances gum health and interdental cleaning.</p>
 <p>PHILIPS sonicare</p> <p>Smart brushing for a personalized, gentle clean. Enjoy a new level of oral care.</p> <p>Philips Sonicare Brilliant Clean HX3792/21 to inteligentny szczoteczka do zębów, która oferuje personalizowane i delikatne czyszczenie jamy ustnej. Dzięki swojej unikalnej technologii Sonic Clean i C3 Premium Plaque Control skutecznie usuwa zębinoskale i bakterie. Dzięki 2 trybom czyszczenia (Clean i White) możesz dostosować poziom czyszczenia do swoich potrzeb. Philips Sonicare Brilliant Clean HX3792/21 to idealne rozwiązanie dla osób, które chcą osiągnąć maksymalną higienę jamy ustnej i cieszyć się zdrowym uśmiechem.</p>	<p>Philips Sonicare Brilliant Clean HX3792/21: Smart Electric Toothbrush Overview</p> <p>Explore the Philips Sonicare Brilliant Clean HX3792/21 sonic electric toothbrush. This document details its smart screen features, advanced sonic technology, C3 Premium Plaque Control brush head, multiple brushing modes (Clean, White), and technical specifications for a personalized and gentle oral care experience.</p>

	<p>Philips Sonicare For Kids HX6352/42: Interactive Bluetooth Electric Toothbrush for Children</p> <p>Explore the Philips Sonicare For Kids HX6352/42, an interactive electric toothbrush designed to make oral hygiene fun and effective for children. Features Bluetooth connectivity, an educational app, and key technical specifications.</p>
	<p>Philips Sonicare 7000 Power Flosser User Manual</p> <p>User manual for the Philips Sonicare 7000 Power Flosser and Power Flosser & Toothbrush System. Learn about features, intended use, safety precautions, and maintenance.</p>
	<p>Philips Sonicare DiamondClean 9000 Electric Toothbrush: Features, Benefits, and Specifications</p> <p>Explore the Philips Sonicare DiamondClean 9000 (HX9911/14), an advanced electric toothbrush offering superior plaque and stain removal, gum care, and personalized brushing experiences via app connectivity. Discover its key features, modes, and technical specifications.</p>
	<p>Philips Sonicare HX7108/03 Rechargeable Toothbrush: Advanced Cleaning and Whiter Teeth</p> <p>Explore the Philips Sonicare HX7108/03 rechargeable toothbrush. Features next-generation Sonicare technology for 7x more plaque removal, whiter teeth, a pressure sensor, SmartTimer, BrushPacer, 21-day battery life, and a travel case. Includes detailed specifications and benefits.</p>