

[Manuals.plus](#) /

› [KHOI1971](#) /

› KHOI1971 AC Adapter for Huffy Disney Lion King Simba Plush Ride-On 19049 (6V)

KHOI1971 KHOI1971-19049

KHOI1971 AC Adapter Instruction Manual

For Huffy Disney The Lion King Simba Plush Ride-on 19049 (6V-Volt Battery)

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your KHOI1971 AC Adapter. This adapter is specifically designed to charge the 6V-Volt battery of the Huffy Disney The Lion King Simba Plush Ride-on model 19049. It features a smart IC chip for automatic shut-off and an LED power indicator for operational status.

2. SAFETY INFORMATION

WARNING: Proposition 65 Warning. This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Read all instructions before use.
- Use this adapter only with the specified Huffy Disney The Lion King Simba Plush Ride-on model 19049 (6V-Volt battery). Using it with incompatible devices may cause damage or injury.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not attempt to open, modify, or repair the adapter. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Unplug the adapter from the wall outlet when not in use or during electrical storms.
- Ensure the wall outlet voltage matches the adapter's input specifications (110V-220V).

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x KHOI1971 AC Adapter with integrated barrel connector cable



Image 1: The KHOI1971 AC Adapter. This image displays the black AC adapter unit with its attached power cable, terminating in a yellow-tipped barrel connector. The adapter unit shows the KHOI1971 brand, model number, input/output specifications, and regulatory marks.

4. SETUP

Follow these steps to connect the AC adapter to your Huffy Disney The Lion King Simba Plush Ride-on:

1. **Locate the Charging Port:** Identify the charging port on your Huffy Disney The Lion King Simba Plush Ride-on. This port is typically located on the ride-on's body, often near the battery compartment or under a flap.
2. **Connect the Adapter:** Insert the barrel connector of the KHOI1971 AC Adapter firmly into the ride-on's charging port. Ensure a snug fit.
3. **Plug into Power Outlet:** Plug the AC adapter into a standard wall power outlet (110V-220V).



Image 2: The Huffy Disney The Lion King Simba Plush Ride-on. This image shows the plush ride-on toy, depicting Simba, with a green charging port visible on its underside, indicating where the adapter should connect.

5. OPERATING INSTRUCTIONS

Once connected, the KHOI1971 AC Adapter will begin charging the ride-on's 6V battery.

- **LED Indicator:** The adapter features an LED light power indicator. When the adapter is properly connected to a power source and charging, this LED will illuminate, providing visual confirmation of power on.
- **Smart IC Chip:** The integrated smart IC chip provides an auto shut-off feature. This function helps prevent overcharging, extending the battery life of your ride-on. The adapter will automatically stop charging once the battery reaches full capacity.
- **Charging Time:** Refer to your Huffy Disney The Lion King Simba Plush Ride-on's original manual for estimated charging times.

6. MAINTENANCE

To ensure the longevity and proper functioning of your AC adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the ride-on before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.

- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid wrapping the cable too tightly to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is observed, discontinue use immediately and replace the adapter.

7. TROUBLESHOOTING

If you encounter issues with your KHOI1971 AC Adapter, refer to the following table:

Problem	Possible Cause	Solution
Adapter LED not illuminating	No power from outlet; adapter not fully plugged in; faulty outlet.	Check wall outlet with another device; ensure adapter is fully plugged into outlet and ride-on.
Ride-on battery not charging	Adapter not connected correctly; ride-on charging port issue; battery issue.	Ensure barrel connector is securely inserted; consult ride-on manual for charging port troubleshooting; if battery is old, it may need replacement.
Adapter feels unusually hot	Overload; poor ventilation; internal fault.	Unplug immediately. Ensure adapter is in a well-ventilated area. If problem persists, discontinue use and replace.

8. SPECIFICATIONS

Model Number	KHOI1971-19049
Input Voltage	100-240V AC, 50-60Hz (0.35A)
Output	6V DC, 1A (12 Watts)
Connector Type	Barrel Connector
Compatible Devices	Huffy Disney The Lion King Simba Plush Ride-on 19049 (6V-Volt Battery)
Special Feature	Smart IC Chip for Auto Shut-off, LED Power Indicator, Travel-friendly (100-240V input)
Item Weight	8 ounces

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your KHOI1971 AC Adapter, please contact the manufacturer or your point of purchase. Keep your purchase receipt as proof of purchase.

Manufacturer: KHOI1971 ® CUSTOM MADE

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question